

<section-header></section-header>
-----------------------------------

# KE200 User manual

High performance vector control inverter

Model: KE200-DDG-TD

3AC 220V 2.2~75kW 3AC 380V 4~300kW

Please hand the manual to ultimate user, and keep it for future reference.

## Preface

Thank you for selecting KE200 series frequency inverter from Shenzhen Micno Electric Co., Ltd.

KE200 inverter is a series of high performance vector control frequency inverter with 4 kinds of control modes - V/F control without PG, V/F control with PG, open loop vector control, close-loop vector control. It has abundant advanced functions including slip compensation, torque compensation, dwell function, zero servo function, speed control and parameter autotuning. It is applicable in many situations which need accurate speed control, fast torque response speed and high start-torque.

This manual describes how to use KE200 series inverter properly. Please read it carefully before installation, operation, maintenance and inspection. Besides, please use the product after understanding the safety precautions.

### Precautions

- In order to describe the product's details, the drawings presented in this instruction are sometimes shown without covers or protective guards. When using the product, please make sure to install the cover or protective guard as specified firstly, and operate the products in accordance with the instructions.
- Since the drawings in this manual are represented examples, some are subject to differ from delivered products.
- This manual may be modified when necessary because of improvement of the product, modification or changes in specifications. Such modifications are denoted by a revised manual No..
- If you want to order the manual due to loss or damage, please contact our company agents in each region or our company customer service center directly.
- If there is still any problem during using the products, please contact our company customer service center directly.

Safety Precautions	1
Chapter 1 Product Information	2
1.1 Product Inspection	2
1.2 Model Description	2
1.3 Nameplate Description	3
1.4 Selection Guide	3
1.5 Technical Specifications	4
1.6 External & Installation Dimensions.	
Chapter 2 Installation	
Chapter 3 Wiring	
3.1 Wiring Diagram	15
3.2 Instructions of Main Circuit Terminals	
3.3 Function Description of Control Circuit Terminals	
3.4 Connection to Peripheral Devices	
4.1 Power on Inspection	
4.2 Mai Operation	23 27
Chapter 5 Control Mode Setting	
5 1 Four Control Modeo	20 20
5.1 Four Control Modes	
5.3 Frequency Command and Running Command Selection	
5.4 Autotuning Program	30
Chapter 6 Parameter Description	
A Initialization Parameters	35
B Application Parameters	
C Tuning Parameters	
D Reference Parameters	71
E Motor Parameters	79
F Option Parameters	90
H Control Circuit Terminal Parameters	
L Protection Parameters	
O Operator Parameters	
Chapter & Maintenance & Trouble Shooting	
8.1 Maintenance & Inspection	
8.2 Alarm & Fault Displays	
Appendix 1 Wiring of KE200 PG Card	
Appendix 2 Comparison Table of LED Display & English Letter	224

# Contents

# **Safety Precautions**

During the installation, operation and maintenance of the product, please make sure to follow the safety precautions.



Improper operations can cause dangerous, which may cause personal injuries or even deaths.

#### Danger



Improper operations can cause dangerous, which may cause equipment damage or personal injury.

#### Caution



Danger

- Do not touch PCB and other components before the charging indicator is off after power off.
- Prohibit wiring during power on, do not check the components and signals on PCB when inverter running.
- Do not disassemble or change the inside connection, wiring and components of the inverter without permission.
- The ground terminal must be connected to ground correctly. 220V class: the third ground connection, 380V class: special ground connection.



#### Caution

- Do not do withstand voltage test for the inverter's inside components, these semiconductor components will be damaged easily with high voltage.
- Never connect the U, V and W output terminals of inverters to AC power.
- Do not touch the main PCB, as IC on CMOS of PCB is affected and damaged easily by static.

caused.

# **Chapter 1 Product Information**



### **1.1 Product Inspection**

Checking the following items when receiving the inverter:

Confirmation Items	Method		
Confirm if the inverter is what you ordered	Check KE200 name plate		
Damaged or not	Inspect the entire exterior of the inverter to see if there are any scratches or other damage resulting from shipping		
Confirm if the fastening parts (screws, etc)	Check with a screw driver if necessary		
are loosing or not			
User's manual, certification and other spares	KE200 user's manual and the relative spares		

Please contact the local agent or our company directly if there is any damage on the inverter.

## **1.2 Model Description**



### **1.3 Nameplate Description**



## **1.4 Selection Guide**

Inverter Model	Motor		Rated Input Current	Rated Output	
inverter woder	kW	HP	(A)	Current (A)	
	:	BAC 220~240	V ±15%		
KE200-2R2G-T2	2.2	3	12	11	
KE200-004G-T2	3.7	5	18	17.5	
KE200-5R5G-T2	5.5	7.5	26	25	
KE200-7R5G-T2	7.5	10	34	33	
KE200-011G-T2	11	15	50	49	
KE200-015G-T2	15	20	66	64	
KE200-018G-T2	18.5	25	81	80	
KE200-022G-T2	22	30	98	96	
KE200-030G-T2	30	40	133	130	
KE200-037G-T2	37	50	166	160	
KE200-045G-T2	45	60	188	183	
KE200-055G-T2	55	75	211	224	
KE200-075G-T2	75	100	288	300	
	:	3AC 380~460	V ±15%		
KE200-004G-T4	4.0	5	9	8	
KE200-5R5G-T4	5.5	7.5	16	14	
KE200-7R5G-T4	7.5	10	21	18	
KE200-011G-T4	11	15	28	27	
KE200-015G-T4	15	20	38	34	

Table 1-1 KE200 Inverter Model and Technical Da
---

#### KE200 Inverter

KE200-018G-T4	18.5	25	43	41
KE200-022G-T4	22	30	51	48
KE200-030G-T4	30	40	68	65
KE200-037G-T4	37	50	84	80
KE200-045G-T4	45	60	98	96
KE200-055G-T4	55	75	124	128
KE200-075G-T4	75	100	155	165
KE200-090G-T4	90	125	181	195
KE200-110G-T4	110	150	218	224
KE200-132G-T4	132	175	260	270
KE200-160G-T4	160	210	292	302
KE200-185G-T4	185	250	330	340
KE200-220G-T4	220	300	440	450
KE200-300G-T4	300	420	580	605

# 1.5 Technical Specifications

Table 1-2 KE200 Inverter	Technical Specifications
--------------------------	--------------------------

	ltem	Specification
Input	Input voltage	220~240V±15%, 3AC 380~460V±15%
mput	Input frequency	47~63Hz
Output	Output voltage	0 $\sim$ input voltage
Output	Output frequency	0~400Hz
		V/f control (with/without PG)
feature	Control mode	Open loop vector control (SVC)
iouturo		Close loop vector control (VC)
	Operation command mode	Keypad control, terminal control, communication control
	Frequency reference source	Digital setting, analog setting, serial communication setting, multi-step speed setting, PID setting, etc. These frequency settings can be combinated and switched between different modes.
	Overload capacity	150% 60S, 180% 10S, 200% 3s
	Start torque	0Hz/150% (VC), 1Hz/150% (SVC)
	Speed adjustment range	1: 1000 (VC), 1: 100 (SVC)
	Speed control accuracy	±0.02% (VC), ±0.2% (SVC)
	Speed control response	<3.5ms (VC), <20m s(SVC)
	Torque limit	Available (parameter setting 4 modes)
	Torque control accuracy	±5%(VC)
	Torque control response	40Hz(VC), 20Hz(SVC)
	Frequency control range	0.1~400Hz

KE200 Inverter

	Frequency control	Digital reference: 0.01% (-10℃~40℃)				
	accuracy	Analog reference: 0.1% (25 $^\circ C$ $\sim$ 10 $^\circ C$ )				
	Frequency setting	Digital reference: ±0.01Hz				
	resolution	Analog reference: 0.03Hz/60Hz (11bit + code)				
	Output frequency resolution	0.01Hz				
	Frequency setting signal	-10~10V, 0~10V (20kΩ), 4~30mA				
	Acceleration/ deceleration mode	Linear/S curve, four kinds of acceleration/ deceleration time (range $0.01{\sim}6000.0S)$				
	Braking torque	20% (150% when equipped with braking resistor)				
	V/f curve	15 fixed types and random V/f curve setting				
	Fault protective function	Provide more than 30 kinds of fault protective functions, which are overcurrent, overvoltage, undervoltage, overheating, phase failure, overload, short circuit, etc. It can record the detailed state of inverter operation during failure and has fault automatic reset function.				
		Programmable DI: 8 on-off inputs (2 fixed)				
	Input terminal	2 Programmable AI: AI1: voltage -10 $\sim$ 10V,				
		Al2: voltage 0 $\sim$ 10V or current 0/4 $\sim$ 20mA				
Input/out		2 programmable open collector outputs				
put terminals	Output terminal	2 programmable analog outputs: -10 ~ 10V				
torrindio		1 relay output (normal open)				
		1 programmable relay output				
	Communication terminal	Offer RS485 communication interface, support MODBUS-RTU communications				
	Environmental temperature	-10 $^{\circ}C \sim 40 ^{\circ}C$ , when it exceeds 40 $^{\circ}C$ , inverters will be derated use. It must not exceed 50 $^{\circ}C$ maximum. Derating will be 4% when the temperature rise by every 1 $^{\circ}C$ .				
Environ-	Humidity	$\leq$ 90, no condensation				
ment	Altitude	$\leq$ 1000M: output rated power, $>$ 1000M: output derating				
Constraint	Storage temperature	-20°℃~60°℃				
	Storage environment	Indoor, without direct sunlight, dust, corrosive gas, combustible gas, oil mist, steam, water, salt, vibration				

## **1.6 External & Installation Dimensions**

#### 1.6.1 Parts Description





#### 1.6.2 External & Installation Dimensions

#### 3AC 220V inverter dimension





Power Range		External [ ( m	Dimension hm )		Installation ( m	Mounting Bolt Model	
Runge	w	H1	H2	D	Α	В	Bolt model
2.2~7.5kW	200	330	300	188.8	90	317	M4
11~15kW	255	440	403	229	140	423.6	M5
18.5~22kW	280	570	521	253	190	552	M6
30~37kW	320	600	552	330	230	582	M8
45~55kW	320	715	662	356	230	695.5	M8
75kW	480	790	725	385	360	768	M10

#### 3AC 380V inverter dimension



 $37 \sim 200 kW$  (including  $90 \sim 200 kW$  standard inverter)



90~200kW nonstandard inverter (with base)

Power Range		External I ( m	Dimension nm )		Installation ( m	Mounting Bolt Model	
	w	H1	H2	D	Α	В	
4∼5.5kW	150	280	253	206	90	266	M3
7.5~15kW	200	330	300	188.8	90	317	M4
18.5~30kW	255	440	403	229	140	423.6	M5
37~45kW	280	570	521	253	190	552	M6
55~75kW	320	600	552	330	230	582	M8
90~110kW (without base)	320	715	662	356	230	695.5	M8
90~110kW (with base)	320	992	962	356			
132~200kW (without base)	480	790	725	385	360	768	M10
132~200kW (with base)	480	1165	1125	385			

Note: Base is optional for 90~200kW inverters. Standard invertes are without base.



220 $\sim$ 315kW with base

KE200 Inverter

External DimensionPower Range(mm)					Install	ation Dim ( mm )	Mounting Bolt Model	
	W	H1	H2	D	A1	A2	В	Boit Model
220~315kW (without base)	700	970	900	408	160	480	946	M10
220~315kW (with base)	700	1390	1350	408				

### 1.6.3 Keypad External Dimension



# **Chapter 2 Installation**

## **Using Environment**

Be sure that the inverter is mounted in a location protected against the following conditions:

• Ambient temperature range: NEMA 1: -10 to 40°C (14 to 104°F)

Open Chassis: -10 to 45°C (14 to 113°F)

- Direct sunlight (not for use outdoors)
- Rain, moisture
- High humidity
- Oil sprays, splashes
- Salt spray
- Dust or metallic particles in the air
- Corrosive gases (e.g. sulfurized gas) or liquids
- Radioactive substances
- Combustibles (e.g. thinner, solvents, etc.)
- Physical shock, vibration
- Magnetic noise (e.g. welding machines, power devices, etc.)
- When mounting units in an enclosure, install a fan or other cooling device to limit the air temperature within the inverter to below 45°C.



(Correct distribution method)



(Incorrect distribution method)

KE200 Inverter



- Please make sure the inverter front is facing forward and the inverter top is facing upward for cooling when installation.
- The installation clearance must fit the following rules: When the inverter is installed in the cabinet or the surrounding is OK, the dustproof top cover can be removed for cooling.



## **Chapter 3 Wiring**

A terminal configuration diagram is placed in the inverter when shipping, as shown below. Please note the terminal numbers when wiring.

11	12	(G)	13	14	15	5	16	17	25	26	27	7	33	18	19	20	
1		2	3	4	:	5	6	7	8	2	1	22	23		9	10	

### 3.1 Wiring Diagram

The following inverter standard wiring diagram, if keypad operation, only use main circuit terminals. (R, S, T, input power; U, V, W, motor input)



**Note**: 1.  $\bigoplus$  shielded wire,  $\bigoplus_{P}$  shielded stranded wire.

- 2. The rated output of terminals 15 and 33 are +15V, -15V, 20mA.
- 3. The terminals 13 and 14 could not be used at the same time. If used at the same time, the frequency source is addition.
- 4. The multifunction analog output terminals are used for external "frequency/current" indicator.

### 3.2 Instructions of Main Circuit Terminals

Terminal	Description
R, S, T	Input terminal of three phase power supply
U, V, W	Output terminal of inverter
(+), (-)	Negative and positive terminals of DC bus
P1, (+)	Connection terminal of external DC reactor
(+) , PB	Connection terminal of brake resistor
	Earth terminal

### **3.3 Function Description of Control Circuit Terminals**

The table below outlines the functions of the control circuit terminals.

Classification	Terminal	Signal Function	Descrip	Signal Level	
	1	Forward run/stop	Forward run when closed, stop when o	open (2-wire configuration)	
	2	Reverse run/stop	Reverse run when closed, stop when o	open (2-wire configuration)	
	3	External fault input	Fault when closed, normal state when open		
Sequence Input Signal	4	Fault reset input	Reset when closed		
	5	Master/Aux. change Multi-step speed ref.1)	Aux. freq. ref. when closed	Multi-function contact inputs (H1-01 to H1-06)	Photo-coupler insulated Input: +24VDC, 8mA
	6	Multi-step speed ref.2	Effective when closed		
	7	Jog reference	Jog run when dosed		
	8	External baseblock	Inv. output baseblocked when closed		
	11	Sequence control input common terminal	Signal input when terminal 1~8 short-circuit		
	15	+15V Power supply output	For analog command +15V power supply		+15V (Allowable current 20mA max.)
-	33	-15V Power supply output	For analog command -15V power sup	-15V (Allowable current 20mA max.)	
	13	Master frequency ref. (voltage)	-10 to +10V/-100% to +100% 0 to +10V/100%		-10 to +10V (20k ), 0 to +10V/(20k )
Analog Input Signal	14	Master frequency ref. (current)	4 to 20mA/100%.	Multi-function analog input (H3- 08, H3-09, H3-10, H3-11)	4 to 20mA (250 )
	16	Multi-function analog input	-10 to +10V/-100% to +100% 0 to +10 V/100%	Multi-function analog input (H3- 04, H3-05, H3-06, H3-07)	-10 to +10V (20k ), 0 to +10V/(20k )
	17	Common terminal for control	Terminal 13, 14 speed command	—	
	12	Connection to shield sheath of signal lead	_	_	
	9				Dry contact
	10	During running (NO contact)	Closed when running	Multi-function output	Contact capacity: 250VAC, 1A or less 30VDC, 1A or less
Soguonoo	25	Zero speed detection	Activates at min. freq. (E1-09) or less	(12-01 10 112-03)	Open collector output
Output	26	Speed agree detection	Activates when the freq. reaches to ±1Hz of set freq.		48V, 50mA or less
orgridi	27	Open collector output common			_
	18		_		Dry contact
	19	Fault contact output	When faulted closed between terminal	ls 18 and 20 19 and 20	Contact capacity:
	20	(NO/NC contact)		19 010 20	30VDC, 1A or less
Analog	21	Frequency meter output	0 to ±10V/100% frequency	Multi-function analog	0 to ±11V Max. ±5%
Output	22	Common		monitor 1 (H4-01, H4-02, H4-03)	2mA or less
Signal	23	Current monitor	5V/inverter rated current	Multi-function analog monitor 2 (H4-04, H4-05, H4-06)	_

# 3.4 Connection to Peripheral Devices



- Do not install the capacitor or surge suppressor at the output side of the inverter, otherwise it may cause inverter failure or capacitor and surge suppressor damaged.
- The Inverter input / output (main circuit) contains harmonic components, it may interfere with inverter accessories communications equipment. Therefore, please install anti-interference filter to make minimize interference.
- The details of external devices and accessories selection refer to the manual of external devices.

Part Name	Installing Location	Function Description
Circuit breaker	Frontend of input circuit	Disconnect the power supply when the equipment at the lower part is over current.
Contactor	Between the circuit breaker and the inverter input side	Connection and disconnection of inverter. Frequent power-on and power-off operations on the inverter shall be avoided.
AC input reactor	Input side of the inverter	Improve the power factor of the input side; Eliminate the higher harmonics of the input side effectively and prevent other equipment from damaging due to distortion of voltage wave. Eliminate the input current unbalance due to unbalance between the power phases.
EMC input filter	Input side of the inverter	Reduce the external conduction and radiation interference of the inverter. Decrease the conduction interference flowing from the power end to the inverter and improve the anti-interference capacity of the inverter.
DC reactor	KE series inverter adopts DC reactor of more than 18.5kW as standard.	Improve the power factor of the input side; Improve the whole efficiency and thermal stability of the inverter. Eliminate the impact of higher harmonics of the input side on the inverter and reduce the external conduction and radiation interference.
AC output reactor	Between the inverter output side and the motor close to the inverter	The inverter output side generally has higher harmonics. When the motor is far from the inverter, since there are many distributed capacitors in the circuit, certain harmonics may cause resonance in the circuit and bring about the following two impacts: Degrade the motor insulation performance and damage the motor if long running. Generate large leakage current and cause frequent inverter protection. In general, the distance between the inverter and the motor exceeds 100 meters, installation of output AC reactor is recommended.

#### Using instruction of the external electrical parts

Please check the following items for external wiring & check if it is correct after finishing the connection (do not use the buzzer on the control circuit to check).

(A) The wiring of main power circuit must be kept away from other power cables with high voltage or big current to avoid noise interference. Please refer to the below figures.

• A separate power circuit for the inverter.



• The general noise filter is not very effective, so it is not recommended.



• Please install a noise filter or an isolation transformer if the power circuit is shared by the inverter and other machine.







Install a noise filter on the output of the main circuit to restrain the transmission interference. Please
install metal tube on the circuit & keep a distance longer than 30cm from signal cables of other control
machine.



• When the wiring distance between the inverter and motor is too long, please consider the voltage drop of the circuit, phase to phase voltage drop (V) =  $\sqrt{3}$  \* wire resistance ( $\Omega$ /km) \* wire distance (m) \* current \*  $10^{-3}$ , and adjust the carrier frequency according to the wiring distance.

Wiring distance between inverter and motor	Below 50M	Below 100M	Above 100M
Carrier frequency	15kHz or less	10kHz or less	5kHz or less
Setting value of parameter C6-01	15.0	10.0	5.0

(B) The wiring of the control circuit must be kept away from the main control circuit's control cable or other power cable with high voltage or big current to avoid noise interference.

- Wiring terminals 9, 10, 18, 19, 20 (contact output) of the control circuit must be wired separately from other terminals.
- Please use shielded cables as the control circuit's cables to avoid fault because of noise interference.
   The wiring distance of the control cable must be no longer than 50m.

(C) The inverter's ground terminal must be properly grounded, the third ground connection for 220V class, the special ground connection for 380V class.

- The ground wiring depends on electrical equipment technology (AWG), keep the ground wire as short as possible.
- Never ground the inverter together with welding machines, motors, or other high-current electrical equipments. Please make all ground wiring in a separate conduit.
- When several inverters are grounded together, please do not form a ground loop.



(D) The specifications of wires and the diameter specifications of wiring of main power circuit and control circuit is selected according to electrical standards, to ensure the safety.

(E) After finishing the wiring, please make sure that the wiring is correct, the wires are good, and the screws are tighten.

# **Chapter 4 Testing & Operation**

### 4.1 Power on Inspection

Inspection before power on:

- Check if the wiring of the main circuit is correct.
- Check if the screws are securely tightened.
- Check if the wiring is correct or there is short circuit caused by broken wires.
- Check if the load status is normal.

### 4.2 Trial Operation

- Please reconfirm the power supply voltage and the wiring are correct before power on.
- Please cut off the power if there is abnormal noise, smoke or abnormal smell after power on.
- Check if the motor runs smoothly, the motor rotation direction is correct and there is abnormal vibration on the motor.
- Check if the motor runs smoothly during acceleration and deceleration.
- Check if the load current is in the range of rated value.
- Check if the display and signal of the keypad are normal.
- The display of the keypad after power on is showed as follow:



# KE200 keypad function description:

Function Key	Name	Function Description			
	LOCAL/REMOTE	Switch key for keypad control and external terminal control			
MENU	MENU	Switch key for setting frequency and function code parameters			
ESC ESC Returns display t monitor paramete		Returns display to the previous status, switch operation or monitor parameters at stop status			
JOG	JOG	Jog key, the default jog frequency is 6Hz			
FWD REV	FWD/REV	Select forward or reverse running			
RESET	RESET	Selects a digit when setting value. As reset key at faults.			
$\bigtriangleup$	Increment key	Selects mode, group, function, parameter or setting value (Increase).			
$\bigtriangledown$	Decrement key	Selects mode, group, function, parameter or setting value (Decrease).			
	DATA/ENTER	Parameter confirmation key, the setting value is entered by pressing this key.			
RUN	RUN	Run inverter by pressing this key under keyboard control mode			
STOP	STOP	Stop inverter by pressing this key under keyboard control mode			

(1) Example of keypad operation: Reset KE200 default setting (two wire system) from the initialize interface after power on.

O FWD

O REV

 $\bigcirc$ 

DRIVE

O FWD

O REV

DRIVE

O FWD

O REV

O FWD

OREV

0

DRIVE

O FWD

O REV

DRIVE

O FWD

OREV



(2) Example of keypad operation: Set 10Hz by keypad, forward/reverse KE200, and test jog function.



## Safety precautions during trial operation

#### Danger

- Do not remove the front cover of the inverter during power on to keep away from electric shock.
- The motor will run automatically after stop if the auto restart function is set, please keep away from the machine to avoid danger.
- Kindly note, the function of stop switch is only valid after being set, which is different from the usage of the function of emergency stop switch.



#### Caution

- Do not touch the heating elements, such as radiator, braking resistor, etc.
- The inverter can run from low speed to high speed easily, please confirm the tolerance range of motor and machinery.
- Please pay attention to the relative setting when using the braking unit.
- Do not check signals on PCB during operation
- All inverter parameters have been preset at the factory. Do not change the settings unless it is required.

### Parameter access level and control mode setting:

5 kinds of KE200 access level: Special for monitor, Selection of customer usage, Quick-start, Basic, Advanced

4 control modes of KE200: V/F control without PG, V/F control with PG, Open loop vector control, close loop vector control

Function code	Name	Factory default	Frequency command selection
A1-01	Parameter access level	2	<ul> <li>0: Special for monitor (only the drive modes and environment parameters can be modified)</li> <li>1: Selection of customer usage (only A2-01—A2-32 can be read &amp; set)</li> <li>2: Quick-start (only read &amp; set 25 required parameters for start)</li> <li>3: Basic (can read &amp; set normal parameters)</li> <li>4: Advanced (can read &amp; set all parameters)</li> </ul>
A1-02	Control mode selection	2	0: V/F control without PG 1: V/F control with PG 2: Open loop vector control 3: Close loop vector control

## 4.3 Setting before Operation

Trial operation in advance without load to avoid damaging the machine because of misoperation. Please do pay attention to the safety of machine and person if trial operation with load is necessary.

# **Chapter 5 Control Mode Setting**

### **5.1 Four Control Modes**

KE200 series inverter provides four kinds of control mode:

- 0. V/F control without PG
- 1. V/F control with PG
- 2. Open loop vector control
- 3. Close loop vector control

Users can select the control mode via keypad accordingly. The factory default control mode is open loop vector control. Please set the control mode and motor parameters according to the following steps.



# **5.2 Specifications of Four Control Modes**

Control mode	V/f control without PG	V/f control with PG	Open loop vector control	Close loop vector control
Basic control	Voltage/frequency control (open loop)	Voltage/frequency control with speed compensation	Current vector control without PG	Current vector control with PG
Speed detector	Without	With PG	Without	With PG
Option of speed detection	Without	KE200-PGA2 KE200-PGD2	Without	KE200-PG2 KE200-PG3
Speed control range	1: 40	1: 40	1: 100	1: 1000
Starting torque	150%/3HZ	150%/3HZ	150%/1HZ	150%/0r/min
Speed control accuracy	±2%~±3%	±0.03%	±0.2%	±0.02%
Torque control	No	No	No	Possible
Low noise corresponding	Standard corresponding	Standard corresponding	Standard corresponding	Standard corresponding
Suitable application	<ol> <li>Drive several motors together</li> <li>Motor parameters are unknown</li> <li>Can not auto tuning</li> </ol>	The machinery with pulse generator	Situations require varying speed	<ol> <li>Simple servo drive</li> <li>High accuracy speed control</li> <li>Torque control</li> </ol>

# 5.3 Frequency Command and Running Command Selection

Function code	Name	Factory default		Description
B1-01	Frequency command selection	1	Setting value 0 1 2 3	Description Keypad Analog terminals Communication Option card
B1-02	Running command selection	1	Setting value 0 1 2 3	Description Keypad No. 1, 2 control terminal Communication Option card

## 5.4 Autotuning Program

#### 5.4.1 For Open loop vector control, please confirm the following items before auto tuning.

(1) Please confirm the load disconnects with the motor completely, otherwise it may cause danger and the auto tuning parameters inaccurate.

(2) Please run with factory default parameters if the load cannot be removed. Or consult the manufacturer to set motor parameters manually.

Please adopt V/F control mode for the situation which does not require high control accuracy and the load cannot be fully removed.

## Auto tuning procedure of sensorless vector control



#### 5.4.2 Countermeasure to the abnormal auto tuning when open loop vector control

When a fault happens during auto tuning, the following abnormal status will be showed & the motor will stop. Please check the following reasons and carry out the relative countermeasures. After the problem is solved, please restart auto tuning. Press "MENU" key to remove the abnormal display.

The motor parameters will restore to the original values if a fault happens. Please reset the parameters when restarting auto tuning.

Countermeasure to the abnormal auto tuning when open loop vector control							
Abnormal content	Reason	Countermeasure					
The set data is abnormal during auto tuning	The relationship between rated frequency, rated speed and motor pole number is abnormal	Revise according to the formula, rated speed<120*rated frequency/motor pole number					
	Load connects with motor	Disconnect the load with motor					
The actual load rate exceeds 20% during auto	The setting value is abnormal during auto tuning	Set the correct rated current					
tuning	Motor bearing is abnormal	Rotate the motor bearing manually when power off. Please change the motor if the rotation is not smooth.					
Torque command value	Motor's power line is broken	Check the wiring, repair the broken line					
auto tuning	Load connects with motor	Disconnect the load with motor					
Malaadaa	Torque limit function does not take action	Restore torque limit (L7-01-L7-04) to factory defaults					
in the set time.	The acceleration time is too short	Extend acceleration time (C1-01)					
	Load connects with motor	Disconnect the load with motor					
Rated slip can be not adjusted in the set time	Load connects with motor	Disconnect the load with motor					
Core saturation coefficient cannot be adjusted in the	Motor rated speed is set improperly	Set the proper value					
set time	Motor's power line is broken	Check the wiring, repair the broken line					
Line resistance cannot be adjusted in the set time,	Motor rated current is set improperly	Set the proper value					
there is no load current	Motor's power line is broken	Check the wiring, repair the broken line					
During auto tuning, torque command exceeds 100% and current without load	Rated voltage and rated frequency are set improperly	Set the proper values					
rated current	Load connects with motor	Disconnect the load with motor					

#### 5.4.3 For close loop vector control, please confirm the following items before auto tuning.

(1) Please confirm the load disconnects with the motor completely, otherwise it may cause danger and the auto tuning parameters inaccurate.

(2) Please confirm the encoder and PG card are installed well, and make sure their connection is correct.

## Auto tuning procedure of close loop vector control



#### 5.4.4 Countermeasure to the abnormal auto tuning when close loop vector control

Countermea	Countermeasure to the abnormal auto tuning of close loop vector control						
Abnormal content	Reason	Countermeasure					
The set data is abnormal during auto tuning	The relationship between rated frequency, rated speed and motor pole number is abnormal	Revise according to the formula, rated speed<120*rated frequency/motor pole number					
	Load connects with motor	Disconnect the load with motor					
The actual load rate exceeds 20% during auto	The setting value is abnormal during auto tuning	Set the correct rated current					
tuning	Motor bearing is abnormal	Rotate the motor bearing manually when power off. Please change the motor if the rotation is not smooth.					
Torque command value	Motor's power line is broken	Check the wiring, repair the broken line					
auto tuning	Load connects with motor	Disconnect the load with motor					
Motor doos not appolarato	Torque limit function does not take action	Restore torque limit (L7-01-L7-04) to factory defaults					
in the set time.	The acceleration time is too short	Extend acceleration time (C1-01)					
	Load connects with motor	Disconnect the load with motor					
Rated slip can be not adjusted in the set time	Load connects with motor	Disconnect the load with motor					
Core saturation coefficient can not be adjusted in the	Motor rated speed is set improperly	Set the proper value					
set time	Motor's power line is broken	Check the wiring, repair the broken line					
Line resistance can not be adjusted in the set time.	Motor rated current is set improperly	Set the proper value					
there is no load current	Motor's power line is broken	Check the wiring, repair the broken line					
PG fault	The connection between PG (A, B phase), the motor (U, V, W) and the inverter is not well	Check the wirings of PG and the motor, check the PG direction and F1-05.					
There is output from motor, but no input from PG pulse	PG is disconnected PG power line is broken	Check & repair the connection					
During auto tuning, torque command exceeds 100% and current without load	Rated voltage and rated frequency are set improperly	Set the proper values					
rated current	Load connects with motor	Disconnect the load with motor					
# **Chapter 6 Parameter Description**

# **KE200 Series Parameter Tree**

				Group	Function	Display	Access Level
Operation	U	Monitoring Items		U1	Status monitoring	Monitor	Q, B, A
Inverter operation is enabled.		Monitor	1	U2	Fault trace	Fault Trace	Q
Inverter status is displayed.			1 1	U3	Fault history	Fault History	Q
	·		-				
A Initialize				Al	Initialization	Initialize	Q
Language selection in LCD display				A2	User setting parameter	User Parameters	Α
Constant access levels, control method							
selection and initializing passwords.	В	Application	- 1	B1	Operation method selection	Sequence	Q, B, A
		Application		B2	DC injection braking	DC Braking	В
Programming				B3	Speed search	Speed Search	A
Parameters are set/read. Items to be set/	1			B4	limer function	Delay Timers	A
read vary depending on the access level				B3 D6	DWELL function	PID Control Reference Held	A
setting.				B0 B7	Dreen control	Droon control	A
				B8	Energy-saving control	Energy Saving	A
Auto-tuning				B0 B9	Zero Servo	Zero Servo	A
Motor parameters are automatically set	6	Tuning					
by inputting turning data (motor name-	L	Tuning	ı,	C1	Accel/decel time	Accel/Decel	0. B. A
plate values) when performing vector.		, annig	<u> </u>	C2	S-curve characteristics	S-curve Acc/Dec	A
	1	L	T	C3	Motor slip compensation	Motor-slip Comp	B. A
Modified Constants	1			C4	Torque compensation	Torque Comp	B, A
Only narameters that have been abound	1			C5	ASR	ASR Tuning	B, A
from the factory setting are set/read.	1			C6	Carrier frequency	Carrier Freq	BA
				C7	Hunting prevention	Hunting Prev	А
				C8	Factory-tuning constant	Factory Tuning	А
	D	Reference		D1	Frequency reference value	Preset Reference	Q, A
	H	Reference	-	D2	Upper/lower limits	Reference Limits	В
			]	D3	Jump frequency	Jump Frequencies	В
				D4	Sequence	Sequence	Α
				D5	Torque reference	Torque Control	A
	_				N//0	Mar Day	
	E	Motor Parameters	т 1	EI E2	V/I patiern	V/F Patiern	Q
		Motor		E2 E3	Motor 2 control method	Motor 2 Ctl Meth	Q, A
			1	F4	V/f nattern/2	V/f Pattern 2	A
				E5	Motor 2 constants	Motor 2 Setup	A
	F	Option		F1	PG speed control card	PG Option setup	Q, B, A
		Option	Ľ	F2	Analog reference card	A1-14 Setup	В
		-	1 1	F3	Digital input card	DI-08, 16 Setup	В
			1	F4	Analog monitor card	AO-08, 16 Setup	в
	1			F5	Digital output card	DO-02 Setup	В
	1			F6	Digital output card	DO-08 Setup	В
				F7	Pulse monitor card	PO-36F Setup	В
				F8	SI-F/G card	SI-F/G	В
				F9	DDS-B/SI-B card	DDSS/SI-B	В
	· .					D'ALL A	
	H	Control Circuit Terminals	יד	HI LP	Sequence mput	Digital Inputs	в
		Ierminal		H3	Analog input	Analog Inputs	B A
		l	1	H4	Analog output	Analog Outputs	B, A B
				H5	MODBUS communication (RS-485)	Serial Com Setup	A
	1			-	N ~ · · · /		
	L	Protection	1	L1	Motor electric thermal overload relay	Motor Overload	B L2
	$\vdash$	Protection	Ъ		Momentary power loss ride-through	PwrLoss Ridethru	B, A
		1	1 1	L3	Stall prevention	Stall Prevention	B, A, F
		<u>.</u>	•	L4	Frequency Detection	Ref Detection	B, A
	1			L5	Fault retry	Fault Restart	В
				L6	Overtorque detection	Torque Detection	B, A
				L7	Torque limit	Torque Limit	В
				L8	Hardware protection	Hdwe Protection	B, A
	0	Digital Operator	-, ı	01	Display selection	Monitor Select	B, A
		Operator		02	Key selection	Key Selections	B, A
			1				

A

#### KE200 Inverter

						V/f	V/f w/	PG Oper Ve	n Loop ector	Close Vec	Loop tor
Main	Me Initia	enu: Ini dization P	tialize <e Parameters</e 	NT	ER>						
<i>A1</i>	Init	ialization L	Set-up								
A1-00	Lan	guage Sele	ection		Select Language		Q	Q	Q		Q
	Select the language displayed on the digital operator according to the following table:										
			Setting		Description						
			0		English (factory default)						
A1-01	Par	ameter Acc	cess Level		Access Level		Q	Q	Q		Q
	This	s paramete	r allows the	"ma	sking" of parameters according to user leve	l. See	the fo	ollowi	ng tal	ole:	
		Settin	g		Description						
		0	Opera	tion	Only						
		1	User F	rogi	ram - Accesses parameters selected by OEM (A2	2-01 to	A2-32	<i>'</i> ).			
		2	Quick	Star	t Level (factory default) - For maintenance-level	orogra	mming				
		3	Basic	isic Level - For basic programming in most applications.							

Advanced Level - For advanced programming in special applications.

A1-02 Control Method Selection

4

Control Method

Q Q Q

Q

Select the control method best suited for your application.

Setting	Description
0	V/f Control - For general-purpose and multiple motor applications.
1	V/f with PG Feedback - For general-purpose applications requiring closed loop speed control.
2	Open Loop Vector <i>(factory default)</i> - For applications requiring precise speed control, quick response and higher torque at low speeds (150% torque below 1Hz).
3	Close Loop Vector - For applications requiring very precise speed and torque con- trol at a wide speed range including 0 speed. Uses encoder

micno		KE200 Inverter				
		V/f	V/f w/PG	Open Loop Vector	Close Loo Vector	р
A1-03 Operator Status	Init Parameters	Q	Q	Q	Q	

Use this parameter to reset the inverter to its factory default settings. Initialize the inverter after changing the control PCB, or after selecting language (A1-00), control method (A1-02), or inverter capacity (O2-04).

Setting	Description
0	No Initialization (factory default)
1110	User Initialization - resets the inverter to user-specified initial values. To set user-specified initial values, make all required changes to parameter settings, then set O2-03 to "1". The inverter will memorize all current settings as the user-specified initial values. Up to 50 changed parameters can be stored.
2220	2-Wire Initialization - terminal 1 becomes FWD run command and terminal 2 becomes REV run command. All other param- eters are reset to their original factory default settings.
3330	3-Wire Initialization - terminal 1 becomes run command, termi- nal 2 becomes stop command and terminal 3 becomes FWD/ REV run selection. All other parameters are reset to their orig- inal factory default settings.

A1-04 Password Entry

.

Enter Password

Q Q Q

Q

Parameter A1-04 is used to enter a password into the inverter, to be able to make adjustments to locked parameters.

Password protection is provided for: A1-01 Access Level A1-02 Control Method A1-03 Initialization A2-01 to A2-32 User Parameters (If selected)

V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------

#### A2 User's Parameters

The user can select up to 32 parameters for quick-access programming. By setting the user access level *(A1-01)* to "User Program", only the parameters selected in function A2 can be accessed by the user.

Parameter A1-01 must be set to 4 (advanced access level) to input parameter numbers into A2-01 through A2-32, and then A1-01 must be set to 1 (User Level) for only the user selected parameters to be viewed.

### Main Menu: Programming <ENTER>

#### **B** Application Parameters

#### B1 Sequence

<i>B1-01</i>	Frequency Reference Selection	Reference Source	Q	Q	Q	Q
<i>B1-02</i>	<b>Operation Method Selection</b>	Run Source	Q	Q	Q	Q

Frequency reference and run command can be set independently as shown below:

Setting	Description
0	Command from digital operator
1	Command from control circuit terminal (factory default)
2	Command from serial communication
3	Command from option card
4	EWS (Reference from CP-717)* <1110> This setting will be used with the CP-717 to run and change the reference through DP-RAM.

\* Setting parameter B1-01 or B1-02 to 4 allows reference and/or run source from CP-717 when either CP-916 or CP-216 option cards are installed.

By depressing the LOCAL/REMOTE key on the digital operator, the operation mode can be selected as shown below:

Local: Operation according to frequency reference and run command from digital operator.
 Remote: Operation according to frequency reference and run command set by *B1-01* and *B1-02*.

The digital operator is reset to remote operation when power is cycled.

micno						KE200	) Inverter	
			V/f	V/f V/f w/P		V/f w/PG Open Loop Vector		Close Loop Vector
<i>B1-03</i>	Stopping Method Selection	Stopping Method	C		Q	Q	Q	
This function selects the stopping method suitable for the particular application.								

Setting	Description
0	Ramp to stop (factory default)
1	Coast to stop
2	DC injection to stop
3	Coast to stop with timer

#### • Ramp to Stop (B1-03 = "0")



#### Figure 1 Stopping Method - Ramp to Stop

Upon removal of the FWD (REV) run command, the motor decelerates at a rate determined by the time set in deceleration time 1 (*C1-02*) and DC injection braking is applied after the minimum output frequency (E1-09) has been reached. If the deceleration time is set too short or the load inertia is large, an overvoltage fault (OV) may occur during deceleration. In this case, increase the deceleration time or install an optional braking transistor and/or braking resistor (braking transistors are provided as standard for units 230V 7.5kW and smaller, 460V 15kW and smaller).

Braking torque: without braking resistor, approx. 20% of motor rated torque with braking option, approx. 150% of motor rated torque



Figure 2 Stopping Method - Coast to Stop

Upon removal of the FWD (REV) run command, the motor starts to coast. After a stop command is given, a run command is accepted and operation will start after the minimum baseblock time (L2-03) elapses. If there is a possibility that a run command might be entered before the motor has come to a stop, the speed search function (B3) or Coast to Stop with Timer 1 (B1-03 = "3") should be employed.

• DC Injection Braking to Stop (B1-03 = "2")



Figure 3 Stopping Method - DC Injection Braking to Stop

Upon removal of the FWD (REV) run command, the motor brakes to stop, according to the DC injection braking time at stop set in *B2-04*. If this value is set to "0" *(factory default)*, DC injection braking is disabled, and the motor coasts to stop. When choosing this function, note that the actual stop time is the time set in *B2-04* multiplied by 10 (see Figure 3 above). This stopping method is disabled during close loop vector control. Braking duty cycle should allow excess motor heat to dissipate.

Close Loop

Vector

Open Loop

Vector

V/f w/PG

V/f

• Coast to Stop with Timer 1 (B1-03 = "3")



Figure 4 Stopping Method - Coast to Stop w/ Timer

After a stop command is given, a run command is not accepted while the coast to stop timer elapses (same as Decel 1). After the timer runs out, another run command must be given for the inverter to begin acceleration. This stopping method is disabled during close loop vector control.

*B1-04 Prohibition of Reverse Operation* 

Reverse Oper

B B B

В

A "reverse run disabled" setting does not allow a reverse run command from the control circuit terminal or the digital operator. This setting is used in applications where a reverse run command is undesirable.

Setting	Description
0	Reverse run enabled (factory default)
1	Reverse run disabled

micno			KE200	) Inverter	
	V/f	V/f w/PG	Open Loop Vector	Close Loop Vector	

<i>B1-05</i>	Operation Selection at Zero Speed	Zero Speed Oper	-	-	-	А
--------------	-----------------------------------	-----------------	---	---	---	---

During close loop vector control, select an operation mode to be employed when the frequency reference (ana- log input) drops below the minimum output frequency (*El* -09). During V/f or open loop vector control, baseblock is applied when the output frequency drops below the minimum output frequency (*El* -09).

Setting	Description		
0	E1 -09 disabled, run according to frequency reference (factory default)		
1 Baseblock			
2 Run at minimum output frequency ( <i>E1-09</i> )			
3 Zero-speed operation (internal speed reference is set to "0")			

B1-06 Input Scan Time

Cntl Input Scans

В В

В

В

А

А

А

А

This parameter selects the microprocessor scan time for reading sequence input data from the control circuit terminals.

Setting	Description	
0	2ms scan time for 2 scans	
1	5ms scan time for 2 scans (factory default)	

Set to "0" when a quicker response is needed from the control circuit terminals.

B1-07 Operation Selection After Switch to Remote Mode LOC/REM RUN Sel

Parameter b1-07 determines how the inverter will function when switching between local and remote operation. This function prevents the motor from running when switching between local/remote and the inverter is controlled from the digital operator.

Setting	Description
0	(Cycle Extrn RUN) - If the run command is closed when switching from local control to remote control,
	the inverter will not run. The run command must be cycled for the inverter to run. (factory default)
1	(Accept Extrn RUN) - If the run command is closed, when switching from local control to remote con- trol, the inverter will run.

#### KE200 Inverter

B1-08 Run Command Acceptance During Programming RUN CMD at PRG

A A A

А

As a safety precaution the drive will not respond to a change in the run command when the digital operator is being used to set or adjust parameters. This parameter will allow the drive to accept or reject a change in the run command when the digital operator is being used to change or adjust parameters. <a href="https://www.statuation.com"></a> eters. <a href="https://www.statuation.com"></a> eters. <a href="https://www.statuation.com"></a> eters.</a> <a href="https://www.statuation.com"></a> eters.</a>

-				
L	ah	0		•
r	au	IU.	1	•

Setting	Description
0	Run command is disabled when drive is in the programming mode. (factory default)
1	Run command is enabled when the drive is in the program mode

#### B2 DC Braking

B2-01 DC Braking Frequency (Zero Speed Level)

DCInj Start Freq

В	В	В	В

Setting Range:0.0 to 10.0HzFactory Default:0.5Hz

Sets the frequency at which DC injection braking (or initial excitation for close loop vector control) starts, in units of 0.1 Hz. When B2-01 < E1-09, DC injection braking starts from the minimum frequency refer- ence (E1-09).



Figure 5 DC Injection Braking at Starting

B2-02 DC Braking Current

DCInj Current

|--|

Setting Range:0 to 100%Factory Default:50%

DC injection braking current is set as a percentage of inverter rated current. In close loop vector control mode, initial excitation is performed according to the motor no-load current set in *E2-03*. This param- eter should not be set unnecessarily high or motor overexcitation may occur.

mic	סר						KE200	) Inverte
				V/f	V/fw/PG	3	Open Loop Vector	Close Loop Vector
			_					
<i>B2-03</i>	DC Braking Time	at Start	DCInj Time@Start	I	В	В	В	В
	Setting Range: Factory Default:	0.00 to 10.00s 0.00s						

DC injection braking at start can be used to stop a spinning motor (or when motor rotation direction is unknown) prior to running. DC injection braking time at start (or initial excitation for close loop vector con- trol) is set in units of 0.1 second. When B2-03 is set to "0", DC injection braking is disabled and accel-

eration starts from the minimum output frequency.

B2-04 DC Braking Time at Stop

DCInj Time@Stop



Setting Range: 0.00 to 10.00s Factory Default: 0.00s

DC injection braking time at stop (or initial excitation for close loop vector control) is set in units of 0.1 sec- ond. When B2-04 is set to "0", DC injection braking is disabled, and the inverter output shuts OFF.



Figure 6 DC Injection Braking Time at Stop

When coast to stop is selected as the stopping method (B1-03), DC injection braking at stop is disabled.

B2-08 Magnetic Close loop Compensation Level <1110>

FieldComp

-	-	А	А

0 to 500% Setting Range: Factory Default: 0%

This parameter allows the magnetizing motor close loop to be boosted when starting the motor. This parameter will facilitate a quick ramp-up of the torque reference and magnetizing current reference to reduce motor slip during start. A setting of 100% equals motor no-load current E1-09. This flux level will be applied below Minimum Output Frequency (E1-09) until the DC Injection Time at Start (B2-03) expires. This parameter is useful when starting motors that are relatively larger than the inverter, due to the requirement for increased magnetizing current. This parameter may also compensate for reduced starting torque due to motor circuit inefficiencies.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

#### B3 Speed Search

When starting into a coasting motor, use the speed search command or DC injection braking at start, to prevent a drive trip and motor burnout.

This function allows the restart into a coasting motor without the necessity to stop. It is useful during inverter bypass operation, when switching between the motor receiving power directly from the line and from the inverter. Two interlocking contactors must be employed for commercial power switchover to prevent line power from being applied to the inverter output terminals.

Set the multi-function contact input selection (H1-01 to H1-06) to "61" (start search command from maximum output frequency), "62" (start search command from the set frequency), or "64" (start search command from the SFS frequency when baseblock is applied).

*B3-01* Speed Search after Run Command

SpdSrch at Start

А

 Setting
 Description

 0
 Speed search disabled, the motor accelerates to the set frequency from the min. frequency reference after run command is given (factory default).

 1
 Speed search enabled after run command is given, according to multi-function contact input selection. When using an encoder, the motor accelerates/ decelerates to the set frequency from the motor speed.

Note: This parameter is disabled except when (A1-02=1) (V/F w/PG Fdbk) or 3 (Close loop vector)

*B3-02* Speed Search Detection Current Level

SpdSrch Current

A - A -

А

Setting Range:0 to 200%Factory Default:150%

After power loss and recovery, speed search begins to ramp the frequency down from a specified point in order to locate the frequency of the spinning motor. During initial speed search the inverter's output current exceeds the speed search detection current level. This level is set as a percentage of inverter rated current. When the inverter's output current is less than the speed search detection level, the frequency is interpreted as the speed agree level, and the inverter accelerates/decelerates to the specified frequency.

Note: Factory setting defaults to 150 when A1-02=0 (V/F Control). When A1-02=2 (Open Loop Vector), the default is 100.

#### KE200 Inverter

			V/t	V	/fw/PG	Open Loop Vector	Close Loop Vector
<i>B3-03</i>	Speed Search Deceleration Time	SpdSrch Dec Time	[	A	-	A	-

Setting Range:0.1 to 10.0sFactory Default:2.0s

Sets deceleration time during speed search in units of 0.1 second. When speed search deceleration time is set to 0.0 second, speed search is disabled. The speed search deceleration time should be set to be somewhat faster than the decel rate of coasting motor. Build an input sequence so that the speed search command is input at the same time or prior to the FWD (REV) run command. If the run command is input before the search command, the search command is not effective. Below is a timing diagram of the search command input:



Figure 7 Search Command Input Timing Diagram

#### B4 Delay Timers

The inverter input and output contacts can be used in place of an external timer. When multi-function contact input ( $H1-\_="18"$ ) is closed, a multi-function contact output ( $H2-\_="12"$ ) can be set to close after the On-delay time (B4-01) has expired. When multi-function contact input ( $H1-\_="18"$ ) is opened, a multi-function contact output ( $H2-\_="12"$ ) can be set to open after the Off-delay time (B4-01) has expired. This function operates independently of any action the inverter is performing.

B4-01 On-delay Timer

Delay-ON Timer A A A A

Setting Range: 0.0 to 100.0s Factory Default: 0.0s

Sets the ON-delay time in units of 0.1 second. The multi-function input must be "closed" for longer than the ON-delay timer for the multi-function output to close.

İ

#### KE200 Inverter

V/f V/f w/PG Open Loop Close Loop Vector Vector				
	V/f	V/f w/PG	Open Loop Vector	Close Loop Vector

84-02	Off-delay Timer		Delay-OFF Timer	А	A	А	А
	Setting Range: Factory Default:	0.0 to 100.0s 0.0s					

Sets the OFF-delay time in units of 0.1 second. The multi-function input must be "open" for longer than the OFF-delay timer for the multi-function output to open.



Figure 8 Timing Diagram of Timer Function

### B5 PID Control

The Proportional, Integral and Derivative (PID) control function provides closed-loop control and regulation of a system variable such as temperature or pressure. A control signal based on the difference (or proportion) between a feedback signal and a desired setpoint is produced. Integration and derivative calculations are then performed on this signal, based upon the PID parameter settings (*B5-01* to *B5-08*), to minimize deviation, for more precise control.

#### **Proportional - P**

PID refers to the type of action used to control modulating equipment such as valves or dampers. With **proportional** control, a control signal based on the difference between an actual condition and a desired condition is produced. The difference, such as that between an actual temperature and setpoint is the "error". The inverter adjusts its output signal related directly to the error magnitude.

#### Integral - I

The **integral** action is designed to minimize offset. An integrating term is used to observe how long the error condition has existed, summing the error over time. Once the system has stabilized, the offset would be minimized.

#### Derivative - D

Overshoot refers to a control loop tendency to overcompensate for an error condition, causing a new error in the opposite direction. **Derivative** action provides an anticipatory function that exerts a "braking" action on the control loop. When combined, the proportional integral, and **derivative** actions provide quick response to error, close adherence to the setpoint, and control stability.



#### KE200 Inverter

			V/f		V/f w/PG	Open Loop Vector	Close Loop Vector
<i>B5-01</i>	PID Control Mode Selection	PID Mode		A	А	А	A

To enable PID control, set PID control mode selection to "1" or "4", according to the description below. Also be sure to set terminal 16 function selection (*H3-05*) to PID feedback (setting: "B").

Setting	Description
0	PID disabled (factory default)
1	PID enabled (deviation signal is put through derivative control)
2	PID with feed forward (feedback signal is put through derivative control)
3 <1110>	Reference= Frequency reference + PID output, D is Feedback
4 <1110>	Reference= Frequency reference + PID output, D is feed-forward

Notes:

- 1. PID with feed forward applies control much quicker than normal PID, without waiting for the deviation signal to build up.
- 2. A PID inverse feedback signal can be selected by inverting the settings for terminal 16 gain and bias.

Then select the PID control intended value set point or detected feedback value set point as follows:

#### Intended Value Setting

The control circuit terminal 16 voltage signal (0 to 10V, -10 to 10V) or multi-step speed parameters HI-03 to HI-06 can be used to set the PID intended value.

Control circuit terminal 16 voltage signal: Set reference selection (*B1-01*) to "1".

Multi-step speed parameters (H1-03 to H1-06): Set reference selection (B1-01) to "0".

(combination of multi-step speed references and jog frequency reference)

#### Detected Value Setting (Feedback)

The control circuit terminal 14 current signal (4 to 20mA) or voltage signals (0 to 10V, -10 to 10V) can be used to set the PID detected value.

Control circuit terminal 14 current signal: Set terminal 14 signal selection (*H3-08*) to "2".

Control circuit terminal 14 voltage signal: Set terminal 14 signal selection (*H3-08*) to "0" or "1".

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

Notes:

- 1. I value is reset to "0" when operation stops.
- 2. The upper limit of the I value can be set by parameter *B5-04*. Increase the value of parameter *B5-04* to upgrade control capability by integration. If the control system vibrates and it cannot be stopped by adjusting the integral time, output delay time, etc., decrease the set value of parameter *B5-04*.
- 3. PID control can be canceled by a multi-function contact input signal. By setting any of parameters *H1-01* to *H1-06* to "19" and by closing the contact during running, PID control is disabled and the intended value signal itself is used as a frequency reference signal.

<i>B5-02</i>	PID Control Prope	ortional Gain	PID Gain	А	А	А	A
	Setting Range: Factory Default:	0.00 to 25.00 1.00					

The proportional gain is the value by which the deviation signal is multiplied to generate a new frequency reference.

<i>B5-03</i>	PID Control Integral Time	PID I Time	А	А	A	А	
--------------	---------------------------	------------	---	---	---	---	--

Setting Range:0.00 to 360.0 secondsFactory Default:1.00 seconds

The integral calculation sums the deviation over time, which eliminates the offset, thus achieving the intended value. The integral time determines how quickly the integral gain increase is added to the control loop.

PID I Limit

А

А

А

А

B5-04 PID Control Integral Limit

Setting Range:0.0 to 100.0%Factory Default:100.0%

The integral limit value eliminates oscillations and improves stability. This value is set as a percentage of maximum output frequency (*E1-04*).

<i>B5-05</i>	PID Control Derive	ative Time	PID D Time	А	А	А	А	
	Setting Range:	0.00 to 10.00 seconds						

Factory Default: 0.00 seconds

The derivative calculation attempts to control the remaining overshoot left over after the proportion and integral calculations. If the system is approaching the intended value very rapidly, the derivative control produces a strong braking action to prevent overshoot. If the system is already stable with very little deviation change, derivative control has very little effect. The derivative time is used to dampen oscillations and reduce overshoot, thus improving stability. Setting the derivative time to a larger number produces more braking action in the control system.

micr	סר					KE20	0 Inverter
				V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>B5-06 PII</i> Set Fac	PID Control LimitSetting Range:0.0 to 100.0%Factory Default:100.0%		PID Limit	A	A	A	A
	The PID limit per- centage of	value further eliminates oscillati f maximum output frequency (E.	ons and improves stab 1-04).	oility. Tł	is value	is set as	a
<i>B5-07</i>	PID Control O	ffset	PID Offset	А	A	А	A
	Setting Range: +100.0% Factor	-100.0% to ory Default: 0.0%					
	The PID offset	adds a bias to the calculated PII	O value, in order to rec	duce any	v offset.		
<i>B5-08</i>	PID Control O	utput Primary Delay Time	PID Delay Time	A	A	A	A

Setting Range:0.00 to 100.0 secondsFactory Default:0.00 seconds

The output delay time is used to delay changes in the calculated PID value, which can prevent oscilla- tions and improve stability.

Parameters *B5-04* and *B5-06* to *B5-08* are preset at the factory to optimum values for most applications, hence, do not need to be changed. When tuning a system, first adjust the proportional gain until oscillations are reduced. Then adjust the integral time so that minimal deviation is achieved as quickly

as possible, without oscillations. Finally, adjust the derivative time to reduce any overshoot at start-up.

B5-09 PID Output Selection <1110>

Output Level Sel A A A A

The PID output term for the inverter control can be either negative or positive output.

Setting	Description
0	PID Normal or Forward Output (factory default) Increase in the manipulated variable when the process variable is larger than the setpoint and decrease the manipulated variable when the process vari- able is smaller.
1	PID Reverse or Inverse Output Increase the manipulated variable when the process variable is smaller than the setpoint and decrease the manipulated variable when the process vari- able is larger than the setpoint.

micr	סר						KE200	) Inverter
				V/f	,	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>B5-10</i>	PID Output Gain	<1110>	Output Gain		А	А	А	A
	Setting Range:	0.0 to 25.0						
	Factory Default:	1.0						
	This parameter set	s the gain of the PID output	The PID output can be	mon	itor	ed by n	aramete	r 1/1_37

This parameter sets the gain of the PID output. The PID output can be monitored by parameter *U1-37 PID Output Monitor*. Refer to PID Block Diagram Figure 9.

<i>B5-11</i>	PID Output Reverse <1110>	Output Rev Sel	А	А	А	А
	1	1				

This parameter is used when the motor is required to change direction during PID operation in response to a negative PID output signal. The PID output can be monitored using parameter *U1-37 PID Output Monitor*.

Setting	Description
0	Zero limit ( <i>factory default</i> ) When PID output is negative, motor direction is not changed. The PID output is limited to 0.
1	Reverse When PID output is negative the motor will reverse direction.

Note: When Reverse Prohibit B1-04 is selected, reverse will not operate.

*B5-12* Loss of Feedback Action <1110>

Fb Los Det Sel

Α	А	A	А
---	---	---	---

This parameter is used to select what action the inverter will take on a loss of PID feedback. A loss of PID feedback occurs when the feedback signal falls below the *B5-13 Feedback Loss Detection Level* for the time set by *B5-14 Feedback Loss Detection Time*.

Setting	Description
0	Disabled <i>(factory default)</i> PID feedback missing detection is disabled.
1	Alarm PID feedback missing detection is enabled. Operation continues after loss of feedback. The text "Fbl" will be displayed on the digital operator.
2	Fault PID feedback missing detection is enabled. The inverter output to the motor is shut off (the motor is stopped) and "Fbl" is displayed on the digital operator.

KE200 Inverter

				V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>B5-13</i>	PID Feedback Loss Detection Level <1110>		Fb los Det Lvl	A	А	A	А
	Setting Range: Factory Default:	0 to 100% 1%					

This parameter sets the level at which a loss of PID feedback is detected. The PID feedback must be at or below this level for the time defined by B5-14 before a loss of feedback can be detected. A setting of 100% represents 100% of the feedback signal.

<i>B5-14</i>	PID Output Gain <1110>		Output Gain	А	А	А	А
	Setting Range: Factory Default:	0.0 to 25.0 1.0					

This parameter sets the gain of the PID output. The PID output can be monitored by parameter *U1-37 PID Output Monitor*. Refer to PID Block Diagram Figure 9.

#### B6 Reference Hold

The reference hold or dwell function is used to temporarily hold the output frequency at a set reference, for a set time, and then start it again. This function can be used when driving a permanent magnet motor, or a motor with a heavy starting load. This pause in acceleration allows the magnets in a permanent magnet motor to synchronize with the stator field of the motor, thus reducing traditionally high starting current.

*B6-01 Dwell Frequency Reference at Start* Setting Range: 0.0 to 400.0Hz

Factory Default: 0.0Hz

Sets the dwell frequency reference during acceleration in units of 0.1Hz.

*B6-02 Dwell Time at Start* 

Dwell Time@Start

Dwell Ref @Stop

Dwell Ref @Start

A A A

А

А

А

А

А

А

А

А

А

Setting Range:0.0 to 10.0sFactory Default:0.0s

Sets the amount of time that the frequency reference "dwells" during acceleration in units of 0.1s.

B6-03 Dwell Frequency Reference at Stop

Setting Range: 0.0 to 400.0Hz Factory Default: 0.0Hz

Sets the dwell frequency reference during deceleration in units of 0.1Hz.

micr	סר						KE200	Inverter
					V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>B6-04</i>	Dwell Time at Stop	)	Dwell Time @Sto	pp	Å	A A	A	A
	Setting Range: Factory Default:	0.0 to 10.0s 0.0s						
	Sets the amount of	time that the frequ	uency reference "dwells" during	dec	elera	tion in ı	units of 0	.1s.
<b>B</b> 7	<b>Droop Control</b> The Drooping func	ction reduces the m	notor speed based on the load to	rque	e of tl	ne motor		
<i>B7-01</i>	Droop Control Gau	in	Droop Quantity				-	A
	Setting Range: Factory Default:	0.0 to 100.0 0.0						
	Parameter b7-01 set torque. The actual torque and the max	ets the amount of n amount of motor s simum output frequ	notor speed reduction when the speed reduction is based on the uency (E1-04).	noto rati	or is p o of t	broducin he amou	ng 100% ant of mo	of rated otor
<i>B7-02</i>	Droop Control Del	lay Time	Droop Delay Tim	е			-	A
	Setting Range: Factory Default:	0.03 to 2.00 0.05						
	Parameter b7-02 se will cause the resp	ets the response tin onse to become qu	ne for the drooping function. D licker; however, instability may	ecre occi	asing ur.	g the dro	op delay	time,
<b>B</b> 8	Energy Saving							
	This feature can sa	ve energy during o	operation under lightly loaded co	ondi	tions	, by deci	reasing c	output

This feature can save energy during operation under lightly loaded conditions, by decreasing output voltage, energy-saving operation is made available. Energy saving control is enabled by a **multi-func-tion contact input**, when control mode selection (*A1-02*) is set to "0" (V/f Control) or "1" (V/f w/PG Fdbk).

Parameters B8-03, B8-04 and B8-05 are for energy savings in the vector modes. B8-01 and B8-02 are only functional in the V/f modes via a multi-function input command. Parameters B8-03, B8-04 and B8-05 are for automatic energy savings in the vector modes.

B8-01 Energy Saving Gain

Energy Save Gain A A

A A - -

Setting Range:0 to 100%Factory Default:80%

The output voltage during energy-saving operation is the product of the normal V/f settings (*El-03* to E1-10) and the energy saving gain. The output voltage decreases and recovers in the voltage recovery time (*L2-04*). As the energy saving gain increases, the output voltage increases also. This feature is only enabled by a multi-function contact input.

micr	סר						KE200	) Inverter
				V	V/f V/f w/PG		Open Loop Vector	Close Loop Vector
<i>B8-02</i>	Energy Saving Sta	rting Frequency	Energy Save Freq		А	А	-	-
	Setting Range: Factory Default:	0.0 to 400.0Hz 0.0Hz						
	After the multi-fur	nction contact input for e	energy-saving operation clos	es (.	H1	_, setti	ng: "63"	), the

After the multi-function contact input for energy-saving operation closes (*H1*-\_\_\_, setting: "63"), the output voltage is decreased when the output frequency reaches the energy-saving starting frequency. This feature is only enable by multi-function contact input.

 B8-03
 Automatic Energy Saving <1110>
 Energy Save Sel
 A
 A

This parameter is used to select if Automatic Energy Saving Mode is to be on or off. A multi-function contact input **is not** required to activate Automatic Energy Saving Mode. This mode of operation automatically searches for the optimum motor voltage required to save energy. This function is separate and not to be confused with parameters B8-01 and B8-02. The energy saving mode that utilizes B8-01 and B8-02 requires a multi-function input to be activated for operation. This Automatic Energy Saving Mode selection **does not** require a multi-function input to activate operation.

Setting	Description
0	Disabled (factory default)
	Energy saving mode will not be activated under light loads.
1	Enabled
	The energy saving mode will be activated under light loads.

B8-04 Energy Saving Control Gain

.

Energy Save Gain

Setting Range:0 to 10.0Factory Default:0.7

The output voltage during energy-saving operation is the product of the normal V/f settings (*El-03* to E1-10) and the energy saving gain. The output voltage decreases and recovers according to the *Energy-Saving Control Time Constant B8-05*. As the energy saving gain increases, the output voltage increases also.

Note: When the control mode A1-02=3, the default factory setting becomes 1.0

*B8-05* Energy Control Time-Constant

Energy Save F. T

- - A A

А

А

Setting Range:0.00 to 10.00Factory Default:0.50

Parameter *B8-05* sets the response time for the *Automatic Energy Saving* function. Decreasing the *Energy Control Time-Constant*, will cause the response to become quicker; however, instability may occur if this is decreased too much. Note: When control mode A1-02=3, the default factory setting becomes 0.01.

**KE200** Inverter

Close Loop

Vector

Open Loop

Vector

V/f

V/f w/PG



Figure 10 Timing Diagram of Energy Saving Function

#### **B9** Zero Servo

The zero servo function is enabled when the multi-function contact input is set to zero servo command  $(H1-\_="72")$ . The motor position is then memorized when motor speed feedback is less than the zero speed level (*B2-01*).

B9-01 Zero Servo Gain

Zero Servo Gain - - A

Setting Range: 0 to 100 Factory Default: 5

Sets the zero-servo position loop gain. When adjusting the gain, the higher the setting, the quicker the response. However, if the gain is set too high, it can cause overshoot and a possible runaway condition.



Figure 11 Zero Servo Position Loop

B9-02 Zero Servo Bandwidth

Zero Servo Count

-	-	-	А
---	---	---	---

Setting Range: 0 to 16383 pulses Factory Default: 10 pulses

Sets zero servo bandwidth in units of one pulse. During zero servo control, the multi-function contact output (H2-\_\_="33") is closed until the number of pulses (or bandwidth) is completed. Then the con-

tact output opens.

V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------



Figure 12 Timing Diagram of Zero Servo Function

Notes:

- 1. For multi-function contact input function selection, refer to parameters H1-01 to H1-06.
- 2. For multi-function contact output function selection, refer to parameters H2-01 to H2-03.
- 3. This function is only available during close loop vector control (Al-02 = "3").

#### **C** Tuning Parameters

#### C1 Accel/Decel

<i>C1-01</i>	Acceleration time 1	Accel Time 1	Q	Q	Q	Q
<i>C1-02</i>	Deceleration time 1	Decel Time 1	Q	Q	Q	Q
<i>C1-03</i>	Acceleration time 2	Accel Time 2	В	В	В	В
<i>C1-04</i>	Deceleration time 2	Decel Time 2	В	В	В	В
<i>C1-05</i>	Acceleration time 3	Accel Time 3	А	А	А	А
<i>C1-06</i>	Deceleration time 3	Decel Time 3	А	А	А	А
<i>C1-07</i>	Acceleration time 4	Accel Time 4	А	А	А	А
<i>C1-08</i>	Deceleration time 4	Decel Time 4	A	A	A	А

Setting Range: 0.00 to 6000.0s

Note: Setting range may be 0.00-600.0 or 0.0-6000.0 depending on the setting of parameter C1-10. Factory Default: 10.0s

Acceleration time sets the time necessary for the output frequency to accelerate from 0Hz to maximum output frequency. Deceleration time sets the time necessary for the output frequency to decelerate from the maximum output frequency to 0Hz.

#### KE200 Inverter



\* When "deceleration to stop" is selected (*B1-03* = "0")



When any of the multi-function contact input selections (H1-01 to H1-06) are set to "7" and "1A", up to four accel/decel times can then be selected by opening or closing the appropriate accel/decel time selection commands (terminals 3 to 8).

Accel/decel Time Selection 1 Multi-function Input Setting = "7"	Accel/decel Time Selection 2 Multi-function Input Setting = "1A"	Accel Time	Decel Time
Open or not set	Open or not set	C1-01	C1-02
Closed	Open or not set	C1-03	C1-04
Open or not set	Closed	C1-05	C1-06
Closed	Closed	C1-07	C1-08

C1-09 Fast-Stop Time

Fast Stop Time

B B B B

Setting Range: 0.00 to 6000.0s Factory Default: 10.0s

Fast-stop time is enabled when:

Multi-function contact input is set to fast-stop command (setting = "15"), and the contact closes. The default stopping method when a fault is detected is fast-stop.

Close Loop

Vector

Open Loop

Vector

V/f

V/f w/PG

							<u>.</u>
C1-10 Acc	el/Decel Time	Setting Unit	Acc/Dec Units	A	A	A	A
	Setting		Description				
	0	Accel/decel time (C1-01 Accel/decel time setting	to C1-09) setting range is in uni range: 0.00 to 600.00s	its of 0.01 s	econd.		
	1	Accel/decel time (C1-01 Accel/decel time setting	to C1-09) setting range is in uni range: 0.0 to 6000.0s (factory d	its of 0.1 se efault)	cond.		

If any of the parameters C1-01 to C1-09 is set to 600.1 seconds or more, C1-10 cannot be set to "0".

C1-11 Accel/Decel Time Switching Frequency Level

Acc/Dec SW Freq

A A A A	А
---------	---

Setting Range:	0.0 to 400.0Hz
Factory Default:	0.0Hz

Accel/decel times can be changed automatically, without using the multi-function contact inputs. Use accel/decel times set in parameters C1-01 and C1-02 when output frequency C1-11. Use accel/decel times set in parameters C1-07 and C1-08 when output frequency < C1-11. When multi-function contact inputs are set for accel/decel selection, this command has priority over automatic change of accel/decel.



Figure 14 Accel/Decel Switching Level Adjustment

#### C2 S-Curve Accel/Decel

An S-curve pattern is used to reduce shock and provide smooth transitions during machine acceleration and deceleration. S-curve characteristic time is the time from the output frequency to the set accel/ decel time.

- C2-01 S-Curve Time at Acceleration Start
- C2-02 S-Curve Time at Acceleration End
- C2-03 S-Curve Time at Deceleration Start
- C2-04 S-Curve Time at Deceleration End

Setting Range:0.00 to 2.50sFactory Default:0.20s

SCrv Acc @ Start
SCrv Acc @ End
SCrv Dec @ Start
SCrv Dec @ End

А	А	А	А
А	А	А	А
А	А	А	А
А	А	А	А



Time (Tsc)

Figure 15 S-curve Characteristic Timing Diagram

The following figure shows FWD/REV run switching during deceleration to stop.



Figure 16 S-curve Characteristics - FWD/REV Operation



V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------

#### C3 Motor Slip Compensation

As the load becomes larger, the motor speed is reduced and motor slip increases. The slip compensation function keeps the motor speed constant even under varying load conditions.

C3-01	Slip Compensation	n Gain	Slip Comp Gain	В	-	В	В
	Setting Range:	0.0 to 2.50					

Factory Default: 1.0

This function controls the output frequency in response to the load's torque demand. Increase the set value in one tenth (0.1) increments when operating at low speeds; decrease the set value as the motor speed increases.

During close loop vector control, this gain compensates for motor slip causes by changes in temperature. Normally, this setting does not have to be modified.

Note: Default factory setting will be 0.0 when parameter A1-02=0 [V/F mode]. When parameter A1-02=2 [Open Loop Vector] or 3 [Close loop vector] the default factory setting will be 1.0.

C3-02 Slip Compensation Primary Delay Time

Slip Comp Time

|--|

Setting Range:0 to 10000msFactory Default:200ms

Adjust the slip compensation delay time when motor speed is unstable or speed response is slow. Increase the set value in 10ms increments when operating at low speeds; decrease the set value as the motor speed increases.

#### C3-03 Slip Compensation Limit

Slip Comp Limit

A - A -

Sets the slip compensation limit as a percentage of motor rated slip (E2-02).



Figure 17 Slip Compensation Limit Adjustment

#### KE200 Inverter

							Open Loop Vector	Close Loop Vector
C3-04	Slip C	Compensation Di	ring Regeneration	Slip Comp Regen		A	- A	-
		Setting		Description				
		0	Slip compensation disabl	ed during regeneration (fac	tory defa	ault)		
		1	Slip compensation enable	ed during regeneration				
<i>C3-05</i>	Flux (	Calculation Meth	nod	Flux Select		-	- A	-
	Parameter C3-05 determines if the motor tor speed.		mines if the motor torq	ue characteristic is base	d on ou	tput free	quency or	motor

Setting	Description
0	Slip Included Motor torque characteristic is based on frequency. (factory default)
1	Slip Excluded Motor torque characteristic is based on motor speed.



When running the motor only in the constant torque region, leave parameter C3-05 set to 0 for the best performance.

When running the motor in the constant horsepower region, set parameter C3-05 to 1 because the larger flux will result in better motor stability.

#### **KE200** Inverter

А

Open Loop Close Loop V/f w/PG V/f Vector Vector

А

-

<i>C3-06</i>	Output Voltage Limit Operation Selection <1110>	Output V Limit
--------------	---	----------------

Setting	Description
0	Disabled (factory default) When this parameter is "0" slip compensation will be disabled when the motor is operating above its base speed. The motor voltage will not be reduced above base speed.
1	Enabled Open Loop Vector Mode: When this parameter is set to "1" the motor volt- age will be reduced slightly when the motor is operating above 90% base speed. Slip Compensation is enabled. Speed control accuracy is improved. This may prevent speed instabilities due to motor voltage saturation. This set- ting may improve speed regulation however motor torque/amp will be reduced by up to 10% due to motor voltage reduction above base speed. Close loop vector Mode: Torque linearity is improved

#### *C4* **Torque Compensation**

Motor torque can be adjusted by changing the V/f pattern (E1-03) or by adjusting the torque compensation gain. For details on setting the V/f pattern, see section E1, V/f Pattern Adjustment,.

Parameters C4-03, C4-04 and C4-05 are added for the OLV mode to help improve starting/breakaway response. Individual torque compensation settings are possible for forward (C4-03) and reverse (C4-04). The delay time (C4-05) is the time for which the internal torque reference will be increased. This torque compensation is much like inputting an analog torque reference via an analog input.

#### C4-01 Torque Compensation Gain

Torq Comp Gain

В В В

The motor torque requirement changes according to load conditions. Full-range automatic torque boost adjusts the voltage of the V/f pattern according to the required torque. The KE200 Series automatically adjusts the voltage during constant-speed operation as well as during acceleration.

The required torque is calculated by the inverter. This ensures tripless operation and power savings.

KE200	Inverter
-------	----------

 $Output \ voltage \quad \ Torque \ compensation \ gain \times Required \ torque$ 



Figure 18 Torque Characteristics

Normally, no adjustment is necessary for torque compensation gain. When more torque is needed, increase the torque compensation gain in one tenth (0.1) increments. When the wiring distance between the inverter and the motor is long, or when the motor generates excessive vibration, decrease the torque compensation gain.

Increasing torque compensation gain increases motor torque, but an excessive increase may cause the following:

- · Inverter fault trips due to motor overexcitation
- · Motor overheat or excessive vibration
- C4-02 Torque Compensation Time Constant

Torg Comp Time

А	А	А	-

Setting Range:0 to 10000msFactory Default:20ms

Increase the torque compensation time constant in 10ms increments when the motor output current is unstable, and decrease this value when speed response is slow.

*Note:* When A1-02=2 [Open Loop Vector] the factory default setting is 20 ms. When A1-02=1 or 3 [V/F or V/F w/PG] factory default setting is 200 ms.

C4-03 Forward Torque Compensation Value at Start<1110> F TorqCmp @ start - A -

Setting Range:0.0 to 200.0%Factory Default:0.0

This parameter may improve the motor performance during start. This feature functions only when starting a motor. Torque reference and motor flux can be ramped up quickly to improve speed response during start. A setting of 0.0 disables this feature.

KE200 Inverter

				V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>C4-04</i>	Reverse Torque Co	ompensation Value at Start<1110>	R TorqCmp @ sta	art		A	-
	Setting Range: Factory Default:	0.0 to 200.0% 0.0					
	This parameter ma starting a motor. The response during start	by improve the motor performance Forque reference and motor flux of art. A setting of 0.0 disables this	e during start. This can be ramped up q feature.	s featur uickly	re functio to improv	ns only v ve speed	vhen
<i>C4-05</i>	Torque Compensat	tion Time Constant@Start<1110>	TorqCmp Delay	T		A	-
	Setting Range: Factory Default:	0 to 200 ms 1 ms					

This parameter functions with C4-03 and C4-04. This parameter is the time delay that will be applied to the Torque Compensation parameters C4-03 and C4-04. A setting of less than 4 milliseconds (ms) causes this filter to be disabled.

#### C5 ASR Tuning

The automatic speed regulator (ASR) provides optimum performance during changes in motor speed or load, when speed feedback is provided.







Figure 20 ASR Block Diagram (Close loop vector Control)

KE200 Inverter

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

C5-01 ASR Proportional Gain 1

ASR P Gain 1

в - в

Setting Range:0.00 to 300.00Factory Default:20.00

The ASR proportional gain 1 adjusts the speed in response to speed deviation, and softens the effect of changes in load. Speed response increases as the proportional gain is increased. However, the load may become unstable if the ASR proportional gain is set too high.

*Note:* When parameter A1-02=1 [V/f w/PG] the factory default setting is 0.20. When parameter A1-02=3 the factory default setting is 20.00.

C5-02 ASR Integral Time 1

ASR I Time 1

-	В	-	В

Setting Range:0.000 to 10.000sFactory Default:0.500s

The ASR integral time 1 adjusts the inverter's response time to changes in load. Speed response increases as the integral time is decreased. However, the load may become unstable if the ASR integral time is set too low.

Note: When A1-02=1 [V/f w/PG] the factory default setting is .200. When A1-02=3 factory default setting is 0.500

When A1-02=1 [V/f w/PG] factory default setting is 0.20. When A1-02=3 factory default setting is 20.00. When A1-02=1 [V/f w/PG] factory default setting is 0.200. When A1-02=3 factory default setting is 0.500 When A1-02=1 [V/f w/PG] factory default setting is 0.02 When A1-02=3 factory default setting is 20.00.

C5-03 ASR Proportional Gain 2

ASR P Gain 2

в - в

Setting Range: 0.00 to 300.00 Factory Default: 20.00

The ASR proportional gain 2 is an additional proportional gain adjustment that can be enabled by a multi-function contact input (H1- = "77").



Figure 21 ASR Multi-function Input Timing Diagram

*Note*: When parameter A1-02=1 [V/f w/PG] factory default setting is .02 When A1-02=3 the factory default setting is 20.00.

micr	סר								KE200	Invert
					١	//f	V/f w/l	PG	Open Loop Vector	Close L Vecto
C5-04	ASR Integral Time 2			ASR I Time 2		-		В	-	В
	Setting Range: ( Factory Default: (	).000 to 10.000s ).500s								
	The ASR integral tim	ne 2 is an additio	onal integral t	ime adjustment.						
C5-05	ASR Limit			ASR Limit	[	-		A	-	-
	Sets ASR frequency function is enabled w	compensation lin then V/f control	nit as a perce with PG feed	entage of maximum lback is selected as	outp the c	out f onti	reque rol me	ency etho	( <i>El -04)</i> d ( <i>A1-0</i> 2	). This 2).
C5-06	ASR Output Primary	Delay Time		ASR Delay Time		-		-	-	A
	Setting Range: ( Factory Default: (	).000 to 0.500s ).004s								
	Mechanical backlash rotor. This condition used to control these	in an applicatio can prevent the secondary curre	n causes secc adjustment o nt (I <sub>2</sub> ) referer	ondary current $(I_2)$ ref ASR parameters. The variations.	efere The	nce outp	varia out de	tion lay	s in the time cor	motor <sup>÷</sup> istant i
C5-07	ASR Switching Frequ	ency Level		ASR Gain SW Fre	q	-		-	-	A
	Setting Range: ( Factory Default: (	).0 to 400.0Hz ).0Hz								
	Sets frequency to cha close loop vector con	nge ASR propor ntrol is selected.	tional gain a	nd integral time con	stant	in t	units c	of 0.	1Hz who	en
	P gain · I time		C5-01 C5-02 C5-03 C5-04	$f_{FB} = \frac{P \cdot N}{120}$ where: P = Number of Motor N = Motor RPM	Poles	3				
	0	: C5-07 or E1-04	f <sub>FB</sub> Motor Speed	* When <i>C5-07</i> ="0",   and integral time 1 (	propor (C5-02	tional ) are	l gain 1 selecte	(C5-) ed.	01)	
		Figure 22 A	SR Switching	Frequency Level						
	Notes: 1.When C5-02 2. During V/f of	7 =""0", proportio	onal gain 1 <i>(C</i> feedback ( <i>A</i> )	(5-01) and integral $(-02 = (1))$ the freq	time	1 (C v sv	75-02 vitchi	) are	e selecte evel bec	d.

micn

During V/f control with PG feedback (A1-02 = "1"), the frequency switching level becomes the maximum output frequency (E1-04).

micno					KE200	Inverter
			V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
C5-08 ASR Integral Limit	ŕ	ASR I Limit			-	A
Setting Range: Factory Default:	0 to 400% 400%				I	

.Parameter C5-08 adjusts the amount of Integral control of the automatic speed regulator in the Closed Loop Vector control mode. Setting parameter C5-08 to zero will make the ASR control proportional. Setting C5-08 to 400% will make the ASR control proportional and integral.



#### C6 Carrier Frequency

This function sets the inverter output transistor switching frequency (carrier frequency). Increase the carrier frequency to reduce motor noise and decrease it to reduce leakage current.

- C6-01 Carrier Frequency Upper Limit
- C6-02 Carrier Frequency Lower Limit

Setting Range:0.4 to 15.0kHzFactory Default:15.0Hz\*

CarrierFreq Max CarrierFreq Min

В	В	В	В
A	A	-	-

For constant carrier frequency operation, set the gain (C6-03) to "0", and set the upper limit (C6-01) and lower limit (C6-02) to the same value.

\* Factory defaults vary depending on drive rating. See the following table for more details:

### KE200 Inverter

V/f V/f w/PG Open Loop Vector Close Loop Vector

<b>Carrier Fr</b>	equency	Factory	Defaults
-------------------	---------	---------	----------

Model No.	Upper Limit C6-01 Setting	Lower Limit C6-02 Setting	Gain C6-03 Setting	Model No.	Upper Limit C6-01 Setting	Lower Limit C6-02 Setting	Gain C6-03 Setting
			220~2	240V	•		
KE200-2R2G-T2	15.0	15.0	0	KE200-022G-T2	10.0	15.0	0
KE200-004G-T2	15.0	15.0	0	KE200-030G-T2	10.0	15.0	0
KE200-5R5G-T2	15.0	15.0	0	KE200-037G-T2	10.0	10.0	0
KE200-7R5G-T2	15.0	15.0	0	KE200-045G-T2	10.0	10.0	0
KE200-011G-T2	15.0	15.0	0	KE200-055G-T2	10.0	10.0	0
KE200-015G-T2	15.0	15.0	0	KE200-075G-T2	10.0	10.0	0
KE200-018G-T2	15.0	15.0	0				
			380~4	460V			
KE200-004G-T4	15.0	15.0	0	KE200-055G-T4	6.0	8.0	0
KE200-5R5G-T4	15.0	15.0	0	KE200-075G-T4	6.0	8.0	0
KE200-7R5G-T4	12.5	15.0	0	KE200-090G-T4	5.0	6.0	0
KE200-011G-T4	12.5	15.0	0	KE200-110G-T4	5.0	6.0	0
KE200-015G-T4	10.0	15.0	0	KE200-132G-T4	5.0	6.0	0
KE200-018G-T4	10.0	15.0	0	KE200-160G-T4	5.0	6.0	0
KE200-022G-T4	8.0	15.0	0	KE200-185G-T4	2.0	5.0	0
KE200-030G-T4	8.0	12.5	0	KE200-220G-T4	2.0	5.0	0
KE200-037G-T4	6.0	12.5	0	KE200-300G-T4	2.0	5.0	0
KE200-045G-T4	6.0	10.0	0				

**KE200** Inverter

			V/f	V/f w/PG	Open Loop Vector	Close Loop Vector		
<i>C6-03</i>	Carrier Proportional Gain	Carrier Freq Gain	ļ	A A	-	-		
	Setting Range: 0 to 99 Factory Default: 0							
	C6-01 Carrier Frequency C6-02 Fout × C6-03 × K*	* K varies depending on the carrier frequency upper limit (C6-01):						
		C6-01 > 10.0kH	C6-01 > 10.0kHz		= 3			
		10.0kHz > C6-01 > 5	10.0kHz > C6-01 > 5.0kHz		= 2			
		C6-01 < 5.0kH	C6-01 < 5.0kHz					
	Output Frequency							

### Figure 23 Carrier Frequency Setting

Note: An OPE11 fault occurs if either of the following conditions is present:

- 1. *C6-03* > 6kHz and *C6-02* > *C6-01*
- 2. *C6-01* > 5kHz and *C6-02* 5kHz

#### C7 Hunting Prevention

Occasionally, in an application, resonance between the internal control system and the mechanical system causes current instability. This instability is called hunting, and may cause the machine to vibrate at lower speeds (up to 30Hz). The hunting prevention function monitors the motor flux and uses a special control circuit to "smooth out" any peaks in the output current waveform.

C7-01 Hunting Prevention Selection

Hunt Prev Select



Enables the hunting prevention function in V/f control mode.

Setting	Description
0	Hunting prevention is disabled.
1 Hunting prevention is enabled (factory default	

C7-02 Hunting Prevention Gain

Hunt Prev Gain

A A
-----

Setting Range: 0.00 to 2.50 Factory Default: 1.00

Sets hunting prevention gain in units of 0.01. When hunting is present while driving a light load, increase the set value in one tenth (0.1) increments. When the motor vibrates or stalls while driving a heavy load, decrease the set value.
				V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>C</i> 8	<i>Factory Tuning</i> This section describ	bes parameters not normally acc	cessed by the user, but	which	may requ	iire adjus	stment.
<i>C8-08</i>	Automatic Frequen	cy Regulator Adjustment	AFR Gain	-	-	А	-
	Setting Range: Factory Default:	0.00 to 10.00 1.00					
	Sets AFR gain in un set value in one ten	nits of $0.01$ . When hunting is p th $(0.1)$ increments. If the spec	present during open lo ed or torque response	oop vect is slow,	or contro increase	ol, decrea	ase the value.
<i>C8-09</i>	Automatic Frequen	cy Regulator Time Constant	AFR Time	-	-	A	-
	Setting Range: Factory Default:	0 to 2000 milliseconds 50 milliseconds					

Parameter C8-09 sets the AFR (automatic frequency regulator) time. Adjusting C8-09 will increase or decrease the AFR frequency response, when the load changes.

If the motor is unstable, increase the set value.

If the speed response is slow, decrease the set value.

*C8-30 Carrier Frequency Selection During Auto-tuning* Carrier in Tune А А

During normal auto-tuning, the inverter is tuned while running at a carrier frequency of 2kHz. This parameter allows the user to specify the inverter carrier frequency during auto-tuning. Adjustment may be necessary when using a spindle motor with low inductance.

Setting	Description						
<b>0</b> Carrier frequency during auto-tuning is 2kHz ( <i>factory default</i> ).							
1	Carrier frequency during auto-tuning is set by C6-01.						
2	Carrier frequency is 5kHz. Except for 185-300 kW which is 2.5 kHz						

### KE200 Inverter

Q

Q

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

Q

Q

### **D** Reference Parameters

### D1 Preset References

			1			1
D1-01	Preset Frequency Reference 1	Reference 1	Q	Q	Q	Q
D1-02	Preset Frequency Reference 2	Reference 2	Q	Q	Q	Q
D1-03	Preset Frequency Reference 3	Reference 3	Q	Q	Q	Q
D1-04	Preset Frequency Reference 4	Reference 4	В	В	В	В
D1-05	Preset Frequency Reference 5	Reference 5	В	В	В	В
D1-06	Preset Frequency Reference 6	Reference 6	В	В	В	В
D1-07	Preset Frequency Reference 7	Reference 7	В	В	В	В
D1-08	Preset Frequency Reference 8	Reference 8				

Setting Range: 0.0 to 400.0Hz Factory Default: 0.0Hz

Up to 9 preset speed references (including jog) can be set through multi-function contact input function selections. When using the multi-step speed references, set the reference selection (B1-01) to "0", and set terminal 16 selection (H3-05) to "1F". See the following table for programming preset speed references.

Tanala al C	Tama in al O	Tamainal 7	Tamainal O	One of Defense
Terminal 5	Terminal 6	Terminal /	Terminal 8	Speed Reference
H1-03 = "3"	<i>H1-04</i> = "4"	H1-05 = "5"	<i>H1-06</i> = "6"	
Open	Open	Open	Open	Speed Reference 1 - Set Reference Source ( <i>B1-01</i> ) to "0".
Closed	Open	Open	Open	Speed Reference 2 - Set Terminal 16 Selection (H3-05) to "1F".
Open	Closed	Open	Open	Speed Reference 3
Closed	Closed	Open	Open	Speed Reference 4
Open	Open	Closed	Open	Speed Reference 5
Closed	Open	Closed	Open	Speed Reference 6
Open	Closed	Closed	Open	Speed Reference 7
Closed	Closed	Closed	Open	Speed Reference 8
Closed	Closed	Closed	Closed	Jog Speed Reference

KE200 Inverter

		V/f	V/f w/P	G	Open Loop Vector	Close Loo Vector	φ
D1-09 Jog Frequency Reference	JOG Reference	C		Q	Q	Q	

Setting Range:0.0 to 400.0HzFactory Default:0.0Hz

The jog frequency reference can be set in this parameter. Depress the JOG key on the digital operator, or close terminal 7, to use this function. The jog command always has priority over other reference commands. When using the multi-step speed references, change the jog command from terminal 7 to terminal 8 (H1-06 = "6").



Figure 24 Multi-step Speed Operation - Timing Diagram

Note: Setting units for *D1-01* to *D1-09* are dependent upon the setting of digital operator display mode (*O1-03*). Possible setting units include Hz, percentage, RPM or engineering units. See section **01**, *Monitor Selection*, on page 120 for more details.

**KE200** Inverter

				V/	f	V/f w/PG	Open Loop Vector	Close Loop Vector
D2	Reference Limits							
D2-01	Frequency Reference Upper Limit		Ref Upper Limit		B	вВ	В	В
	Setting Range: Factory Default:	0.0 to 110.0% 100.0%						
	The frequency referring in increments of 19	erence upper limit is se %.	t as a percentage of the maxi	mun	1 ou	tput fre	quency (	E1-04)
D2-02	Frequency Referen	nce Lower Limit	Ref Lower Limit	[	E	в	В	В
	Setting Range: Factory Default:	0.0 to 109.0% 100.0%		-				

The frequency reference lower limit is set as a percentage of the maximum output frequency (E1-04) in increments of 1%. When a run command is input and the frequency reference is less than the lower limit, operation continues at the frequency reference lower limit. However, when the lower limit is set to less than the minimum output frequency (E1-09), operation discontinues.



Set Frequency Reference

Figure 25 Setting Frequency Upper and Lower Limits

#### D3 Jump Frequencies

D <b>3-</b> 01	Jump Frequency Reference 1	Jump Freq 1	В	В	В	В
D3-02	Jump Frequency Reference 2	Jump Freq 2	В	В	В	В
D3-03	Jump Frequency Reference 3	Jump Freq 3	В	В	В	В
D3-04	Jump Frequency Reference Bandwidth	Jump Bandwidth	В	В	В	В

This function allows the prohibition or "jumping" of critical frequencies so that the motor can operate without resonant vibrations caused by some machine systems. This function is also used for dead-band control. Setting the value to 0.0Hz disables this function.

V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------



Figure 26 Jump Frequencies

### D4 Sequence

D4-01 Hold Reference Memory Selection

MOP Ref Memory

A A

А

А

Selects whether the held frequency during motor operated potentiometer (MOP) simulation operation is stored when operation is stopped (when power is removed or when the run command is removed).

Setting	Description
0	Held frequency during MOP operation not retained. If a stop command is given or if power is removed, the frequency reference is reset to 0Hz. If the inverter is still decelerating when the run command is restored, operation resumes at the frequency reference which the inverter has ramped down to <i>(factory default).</i>
1	Held frequency during MOP operation is retained. If a stop command is given, or if power is removed, operation resumes at the held frequency reference when run command is restored.

Note: MOP operation is set using the multi-function contact input function selections (H1-01 to H1-06, setting = "10" and "11"). See section **H1**, **Digital Inputs**, on page 76 for more information.

D4-02 Trim Control Level

Trim Control Lvl

A A A A

Setting Range:0 to 100%Factory Default:10%

Sets the motor operated pot or "trim" control level as a percentage of maximum output frequency in units of 1%. When trim control increase and decrease are selected as multi-function contact input functions (setting: HI-\_\_ = "1C" and "1D", respectively), the trim control level is added to or subtracted from the analog frequency reference, when each respective contact closes. This is useful in applications such as winders and unwinders, where speed compensation may be needed.

### KE200 Inverter

					V/f	V/f w	//PG	Open Loop Vector	Close Loop Vector
D5	Torque Control								
D5-01	Torque Control S	Selection		Torq Control Sel		-	-	-	A
	Selects between	speed and tor	que control during cl	ose loop vector ope	eratio	n ( <i>A1</i> -	03 =	"3").	
		Setting	[						
		0 5	Speed control enabled v	vith torque limit (factor	ry defa	ault)			
		1 T	orque control enabled v	vith speed limit			_		
ה 20	tion $(HI-\_= "7$	'1'').	Time	Tora Paf Filtar			F **		
D3-02	Iorque Limit Pri	mary Delay I	ime	Iorq Rej Filter		-	-	-	A
	Setting Range: Factory Default:	0 to 1000 0ms	ms						
	Sets delay time of	constant for to	orque reference input	in the torque contro	ol mo	de, in ı	units	of 1ms.	
D5-03	Speed Limit Inpi	ıt Selection		Speed Limit Sel		-	-	-	А
	Sets speed limit	selection in th	ne torque control mod	le.					
		Setting	[	Description					
		1	Speed limit is the ar terminal 13 or 14 (fa	nalog speed reference actory default).	e set b	у			
		2	Speed limit is the re	ference set by B1-01					

D5-04 Speed Limit Value

Speed Lmt Value

- - A

-

Setting Range:-120 to 120%Factory Default:0%

Sets the speed limit value in the torque control mode as a percentage of the maximum output frequency, when D5-03 = "2".

				V/f	V/f V/f w/PG		Close Loop Vector
D5-05	Speed Limit Bias		Speed Lmt Bias	-	-	-	А
	Setting Range: Factory Default:	0 to 120% 10%					

Sets the speed limit bias value in the torque control mode as a percentage of the maximum output frequency.

D5-06	Reference Delay Ti	mer	Ref Hold Time	-	-	-	А	
	Setting Range:	0 to 1000ms						
	Factory Default:	0ms						

Sets delay time from when the speed/torque control selection is made to when the control mode is actually changed, in units of 1ms.

### Torque Control Operation

To select torque control, set torque selection (*D5-01*) to "1", or close the multi-function contact input set to speed/torque control (*H1-\_\_\_* = "71") and set terminal 16 function selection to torque reference (*H3-05* = "13").



Figure 27 Torque Control Block Diagram

- \*1: When speed limit selection (*D5-03*) is set to "1", the master frequency reference input from terminal 13 or 14 becomes the speed limit; when speed limit selection (*D5-03*) is set to "2", the set value of *D5-04* becomes the speed limit.
- \*2: When terminal 14 function selection is set to torque compensation (H3-09 = "14"), terminal 14 set value can be used as the torque compensation value.

When torque reference > 0 and speed limit > 0 (winder application sequence), the following sequence is activated:

V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------

- When  $[-1 \times \text{speed limit bias } (D5-05)] < \text{motor speed} < [speed limit + D5-05], torque control is activated using the set torque reference.$
- When motor speed > [speed limit + D5-05], torque control is activated using the set torque reference.
- When motor speed <  $[-1 \times D5-05]$ , the speed limiting circuit outputs a positive torque reference to prevent the motor speed from increasing in the reverse direction.

Therefore, when torque reference > 0 and speed limit > 0, the torque control range is:

 $[-1 \times D5-05] < motor speed < [speed limit + D5-05]$ 

Refer to the following table for more details on the relationship between torque reference, speed limit and motor speed.

		Winder	Control	Unwinder Control			
Configuration			n N T M Motor	Line Direction			
Direction of Motor Rotation		Forward	Reverse	Forward	Reverse		
Reference	Torque Reference (TREF)	+	-	-	+		
Polarity	Speed Limit (NLIM)	+	-	+			
		Torque	Torque	Torque	Torque		
		Torque Limit TREF 0 NLIM Speed D5-05 Torque Limit	Torque Limit TREF D5-05	Torque Limit 0 Speed Torque Limit D5-05	Torque Limit TREF NLIM 0 Speed D5-05		

V/f V/f w/PG Open Loop Close Vector Vector

Close Loop Vector

### Speed/Torque Control Switching

When the KE200 is set up for close loop vector control (A1-03 = "3"), speed control or torque control can be selected "on the fly" by using the multi-function input speed/torque control selection command (H1-="71").

Terminal No.	Parameter No.	Setting	Description
8	H1-06	71	Speed/torque control selection
13	B1-01	1	Frequency reference selection (terminals 13, 14)
	D5-03	1	Speed limit selection (terminals 13, 14)
16	H3-05	13	Torque reference/speed limit



Figure 28 Speed/Torque Control Selection Timing Diagram

### Sequence Description

When the speed/torque control selection contact is OFF, speed control is activated.

- Speed reference during speed control depends on the frequency reference selection (*B1-01*) setting. To use terminal 13 or 14 as the master frequency reference, set *B1-01* to "1".
- Torque limit during speed control is the smaller of the absolute value of terminal 16 torque limit, or the values set in the torque limit parameters (L7-01 to L7-04).
- When a stop command is given during speed control, speed control is maintained and the smaller of the absolute value of terminal 16 torque limit, or the values set in the torque limit parameters (L7-01 to L7-04), is used as the torque limit. Then the motor decelerates to stop.

When the speed/torque control selection contact is ON, torque control is activated.

- Speed limit during torque control is the master frequency reference at terminal 13 or 14 when speed limit selection (D5-03) is set to "1", and is the speed limit value (D5-04) when D5-03 = "2", regardless of the frequency reference selection (B1-01) setting.
- During torque control, the terminal 16 analog input value becomes the torque reference.

Q

V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------

By giving a stop command during torque control, operation changes to speed control automatically, and the motor decelerates to stop. The torque limit during deceleration to stop becomes the values set in the torque limit parameters (L7-01 to L7-04).

Note: The control mode actually changes after the speed/torque control selection command changes and after the reference delay timer (D5-06) elapses. The terminal 13 speed reference/speed limit and the terminal 16 torque limit/torque reference are stored in the inverter until the time set to D5-06 elapses.

#### Е **Motor Parameters**

#### **E1** V/f Pattern

E1-01	Input Voltage	Input Voltage	Q	Q	Q
	Setting Range: Factory Default:	155 to 255V (230V class), 310 to 510V (460V class) < 230V, 460V<1110>	<1110>		

Sets the inverter input voltage in units of 1V.

E1-02 Motor Selection

Motor Selection

Q Q Q Q

Select between fan-cooled, blower-cooled and vector/inverter duty motor types with this parameter.

Setting	Description
0	Fan-cooled motor characteristics (factory default)
1	Blower-cooled or TENV motor characteristics This setting allows 120% motor current at and above 5.6 Hz continuously, and allows 100% motor current at 0 Hz continu- ously (w/ linear in between).
2	Vector/inverter duty motor <1110> This setting allows 120% motor current at all frequencies.

#### E1-03 V/f Pattern Selection

V/f Selection

Q Q Q Q

Choose a preset V/f pattern for operation in V/f modes only. It may be necessary to change the V/f pattern when using a high-speed motor, or when special torque adjustment is required in the application.

Set values 0 to E: preset V/f pattern can be selected

custom V/f pattern can be set (factory default) **F**:

Preset V/f patterns are automatically scaled by the input voltage value set in parameter E1-01. Set the V/f pattern according to the applications described in the table on the following page:

KE200 Inverter

V/f V/f w/PG Open Loop Close Loop Vector

### Preset V/f Patterns

	Specif	ications	E1-03	V	/f Pattern *1	Specifications		cations	E1-03	V/f Pattern *1	
	50Hz060Hz Saturation1 F50Hz Saturation272Hz3		0	( <sup>1</sup> 230	230 0		50Hz	High Starting Torque 1	8	230 9 28	
				17 10 0 1.3 2.5 50 (Hz)		ng Torque *		High Starting Torque 2	9	22 13 13 0 1.3 2.5 50 (Hz)	
General-purpose			1 <b>F</b>	(V) 230	230 2		bit bit 60Hz	High Starting Torque 1	A	230 <sup>(V)</sup> B	
			2	17 10 0 1.5 3.0 50 60 <sup>(Hz)</sup>				High Starting Torque 2	В	28 22 17 13 0 1.5 3.0 60 (Hz)	
			3	(V) 230 17 10 0 1.5	(V) 230 17 10 0 1.5 3.0 60 72 <sup>(Hz)</sup>		90	Hz	С	(V) 230 17 10 0 1.5 3.0 60 90 (Hz)	
	50Hz	Variable Torque 1	4	(V 230	230 V) 5		120Hz		D	230 D	
e Torque		Variable Torque 2	5	57 40 10 9 0	4 1.3 25 50 (Hz)	High Spee	High Spee			17 10 0 1.5 3.0 60 120 (Hz)	
Variable	60Hz	Variable Torque 1	6	(V 230	230 7		180Hz		E	(V) 230 <i>E</i>	
	Variable Torque 2 7 9 0 1.5 30 60 (Hz)						17 10 0 1.5 3.0 60 180 (Hz)				

Notes:

- 1 The following conditions must be considered when selecting a V/f pattern:
  - $\cdot\,$  The voltage and frequency characteristics of the motor.
  - $\cdot\,$  The maximum speed of the motor.
- 2 Select a high starting torque V/f pattern only under the following conditions:
  - The wiring distance is long 492 ft. (150m) and above.
  - · Large voltage drop at start-up.
  - · AC reactor is connected to the inverter's input or output.
- 3 Voltage in preset patterns is doubled for 460V class inverters.

**KE200** Inverter

V/f V/f w/PG Open Loop Close Loop Vector

Custom V/f Pattern

Set up a custom V/f pattern by setting parameter E1-03 to "F", and then setting the values in parameters E1-04 to E1-13.

<i>E1-04</i>	Maximum Frequency	Max Frequency	Q	Q	Q	Q
E1-05	Maximum Voltage	Max Voltage	Q	Q	Q	Q
E1-06	Motor Base Frequency	Base Frequency	Q	Q	Q	Q
<i>E1-07</i>	Middle Output Frequency A	Mid Frequency A	Q	Q	A	-
E1-08	Middle Output Voltage A	Mid Voltage A	Q	Q	A	-
<i>E1-09</i>	Minimum Output Frequency	Min Frequency	Q	Q	Q	A
<i>E1-10</i>	Minimum Output Voltage	Min Voltage	Q	Q	A	-
E1-11	Middle Output Frequency B	Mid Frequency B	А	А	А	A
E1-12	Middle Output Voltage B	Mid Voltage B	А	А	А	А
E1-13	Motor Base Voltage	Base Voltage	А	А	Q	Q



Figure 28 Custom V/f Pattern Setting

\* For 460V class units, the value is twice that of 230V class units.

Increasing the voltage in the V/f pattern increases motor torque. However, when setting a custom V/f pattern, increase the voltage gradually while monitoring the motor current, to prevent:

- · Inverter fault trips as a result of motor overexcitation
- · Motor overheat or excessive vibration

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

Parameter No.	Name	Unit	Factory Setting							
E1-03	V/f Pattern Selection	—	0	1	2	3	4	5	6	7
E1-04	Max. Output Frequency	Hz	50.0	60.0	60.0	72.0	50.0	50.0	60.0	60.0
E1-05	Max. Voltage	V	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
E1-06	Max. Voltage Frequency	Hz	50.0	60.0	50.0	60.0	50.0	50.0	60.0	60.0
E1-07	Mid. Output Frequency	V	2.5	3.0	3.0	3.0	25.0	25.0	30.0	30.0
E1-08	Mid. Output Frequency Voltage	V	17.2	17.2	17.2	17.2	40.2	57.5	40.2	57.5
E1-09	Min. Output Frequency	Hz	1.3	1.5	1.5	1.5	1.3	1.3	1.5	1.5
E1-10	Min. Output Frequency Voltage	V	10.3	10.3	10.3	10.3	9.2	10.3	9.2	10.3

### V/F Pattern for Inverter Capacity 0.4 ~ 1.5kW for 200V Class

For 460V class units, the value is twice that of 230V class units.

### Inverter Capacity 0.4 ~ 1.5kW for 200V Class (Continued)

Parameter No.	Name	Unit	Factory Setting							
E1-03	V/f Pattern Selection		8	9	А	В	С	D	Е	F
E1-04	Max. Output Frequency	Hz	50.0	50.0	60.0	60.0	90.0	120.0	180.0	60.0
E1-05	Max. Voltage	V	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
E1-06	Max. Voltage Frequency	Hz	50.0	50.0	60.0	60.0	60.0	60.0	60.0	60.0
E1-07	Mid. Output Frequency	V	2.5	2.5	3.0	3.0	3.0	3.0	3.0	3.0
E1-08	Mid. Output Frequency Voltage	V	21.8	27.6	21.8	27.6	17.2	17.2	17.2	17.2
E1-09	Min. Output Frequency	Hz	1.3	1.3	1.5	1.5	1.5	1.5	1.5	1.5
E1-10	Min. Output Frequency Voltage	V	12.6	14.9	12.6	17.2	10.3	10.3	10.3	10.3

For 460V class units, the value is twice that of 230V class units.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

Parameter No.	Name	Unit	Factory Setting							
E1-03	V/f Pattern Selection		0	1	2	3	4	5	6	7
E1-04	Max. Output Frequency	Hz	50.0	60.0	60.0	72.0	50.0	50.0	60.0	60.0
E1-05	Max. Voltage	V	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
E1-06	Max. Voltage Frequency	Hz	50.0	60.0	50.0	60.0	50.0	50.0	60.0	60.0
E1-07	Mid. Output Frequency	V	2.5	3.0	3.0	3.0	25.0	25.0	30.0	30.0
E1-08	Mid. Output Frequency Voltage	V	16.1	16.1	16.1	16.1	40.2	57.5	40.2	57.5
E1-09	Min. Output Frequency	Hz	1.3	1.5	1.5	1.5	1.3	1.3	1.5	1.5
E1-10	Min. Output Frequency Voltage	V	8.0	8.0	8.0	8.0	6.9	8.0	6.9	8.0

V/F Patterns for Inverter Capacity 2.2 ~ 45kW for 200V Class

For 460V class units, the value is twice that of 230V class units.

### V/F Patterns for Inverter Capacity 2.2 ~ 45kW for 200V Class (Continued)

Parameter No.	Name	Unit	Factory Setting							
E1-03	V/f Pattern Selection		8	9	А	В	С	D	Е	F
E1-04	Max. Output Frequency	Hz	50.0	50.0	60.0	60.0	90.0	120.0	180.0	60.0
E1-05	Max. Voltage	V	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
E1-06	Max. Voltage Frequency	Hz	50.0	50.0	60.0	60.0	60.0	60.0	60.0	60.0
E1-07	Mid. Output Frequency	V	2.5	2.5	3.0	3.0	3.0	3.0	3.0	3.0
E1-08	Mid. Output Frequency Voltage	V	20.7	26.4	20.7	26.4	16.1	16.1	16.1	16.1
E1-09	Min. Output Frequency	Hz	1.3	1.3	1.5	1.5	1.5	1.5	1.5	1.5
E1-10	Min. Output Frequency Voltage	V	10.3	12.6	10.3	14.9	8.0	8.0	8.0	8.0

For 460V class units, the value is twice that of 230V class units.

V/f V/f w/PG Open Loop Vector Vector

Parameter	Name	Unit		Factory Setting						
E1-03	V/f Pattern Selec- tion	_	0	1	2	3	4	5	6	7
E1-04	Max. Output Fre- quency	Hz	50.0 <sub>&lt;21&gt;</sub>	60.0	60.0	72.0 <sub>&lt;21&gt;</sub>	50.0 <sub>&lt;21&gt;</sub>	50.0 <sub>&lt;21&gt;</sub>	60.0	60.0
E1-05	Max. Voltage	V	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
E1-06	Max. Voltage Fre- quency	Hz	50.0 <sub>&lt;21&gt;</sub>	60.0	50.0 <sub>&lt;21&gt;</sub>	60.0	50.0 <sub>&lt;21&gt;</sub>	50.0 <sub>&lt;21&gt;</sub>	60.0	60.0
E1-07	Mid. Output Fre- quency	V	2.5 <sub>&lt;21&gt;</sub>	3.0	3.0	3.0	25.0 <sub>&lt;21&gt;</sub>	25.0 <sub>&lt;21&gt;</sub>	30.0	30.0
E1-08	Mid. Output Fre- quency Voltage	V	13.8 <sub>&lt;21&gt;</sub>	13.8<21>	13.8<21>	13.8<21>	40.2<21>	57.5 <sub>&lt;21&gt;</sub>	40.2<21>	57.5 <sub>&lt;21&gt;</sub>
E1-09	Min. Output Fre- quency	Hz	1.3 <21>	1.5	1.5	1.5	1.3<21>	1.3 <21>	1.5	1.5
E1-10	Min. Output Fre- quency Voltage	V	6.9	6.9	6.9	6.9	5.7<21>	6.9	5.7 <21>	6.9

V/F Patterns for Inverter Capacity 55 ~ 300kW for 200V Class

For 460V class units, the value is twice that of 230V class units.

### V/F Patterns for Inverter Capacity 55 ~ 300kW for 200V Class (Continued)

Parameter	Name	Unit		Factory Setting						
E1-03	V/f Pattern Selec- tion	_	8	9	А	В	С	D	Е	F
E1-04	Max. Output Fre- quency	Hz	50.0 <sub>&lt;21&gt;</sub>	50.0 <sub>&lt;21&gt;</sub>	60.0	60.0	90.0 <sub>&lt;21&gt;</sub>	120.0 <sub>&lt;21&gt;</sub>	180.0 <sub>&lt;21&gt;</sub>	60.0
E1-05	Max. Voltage	V	230.0	230.0	230.0	230.0	230.0	230.0	230.0	230.0
E1-06	Max. Voltage Fre- quency	Hz	50.0 <sub>&lt;21&gt;</sub>	50.0 <sub>&lt;21&gt;</sub>	60.0	60.0	60.0	60.0	60.0	60.0
E1-07	Mid. Output Fre- quency	V	2.5 <sub>&lt;21&gt;</sub>	2.5 <sub>&lt;21&gt;</sub>	3.0	3.0	3.0	3.0	3.0	3.0
E1-08	Mid. Output Fre- quency Voltage	V	17.2 <sub>&lt;21&gt;</sub>	23.0 <sub>&lt;21&gt;</sub>	17.2 <sub>&lt;21&gt;</sub>	23.0 <sub>&lt;21&gt;</sub>	13.8 <sub>&lt;21&gt;</sub>	13.8 <sub>&lt;21&gt;</sub>	13.8<21>	13.8<21>
E1-09	Min. Output Fre- quency	Hz	1.3<21>	1.3<21>	1.5	1.5	1.5	1.5	1.5	1.5
E1-10	Min. Output Fre- quency Voltage	V	8.0<21>	10.3 <sub>&lt;21&gt;</sub>	8.0 <sub>&lt;21&gt;</sub>	12.6<21>	6.9	6.9	6.9	6.9

For 460V class units, the value is twice that of 230V class units.

micr	סר		KE200 Inverter				
			V/f V/f w/PG Open Loop Vector Vector				
<i>E2</i>	Motor Set-up						
E2-01	Motor Rated Current	Motor Rated FLA	Q Q Q Q				
	Sets the motor rated current in units of 0.01A for models G5U2011, G5U4011 and larger. The defitting (O2-04).	r inverter models 27P5 ault setting varies depen	, 47P5 and smaller; 0.1A for nding on the inverter model set-				
<i>E2-02</i>	Motor Rated Slip Frequency	Motor Rated Slip	A A Q Q				
	Setting range: 0.00 to 20.00Hz						
	Sets the motor rated slip frequency in units of $0.01$ Hz. The default setting varies depending on the inverter model setting (O2-04). Use the following equation to calculate the motor rated slip frequency:						
	where: $f_{s} = f - f_{s}$ $f_{s} : slip frequency (Hz)$ $f : rated frequency (Hz)$ $N : rated motor speed (rpm)$ $P : number of motor poles$	$\frac{(N * P)}{120}$					
E2-03	Motor No-Load Current	No-Load Current	A A Q Q				
	Sets the motor no-load current in units of 0.01A models G5U2011, G5U4011 and larger. The def ting (O2-04).	A for inverter models 2' fault setting varies depe	7P5, 47P5 and smaller; 0.1A for ending on the inverter model set-				
E2-04	Number of Motor Poles	Number of Poles	QQ				
	Setting Range:2 to 48 polesFactory Default:4 poles						
	Sets the number of motor poles.						
E2-05	Motor Terminal Resistance	Term Resistance	A A A A				
	Sets the motor phase-to-phase resistance value is	n units of 0.01W.					
	Motor Terminal Resistance = Phase-to-Phase Resistance Insulation Class Temperatu	e at 273 + (25°C + insulati re x 273 + insulation	ion class temperature) / 2 n class temperature				

The default setting varies depending on the inverter model setting (O2-04).

	סר				KE200	Inverter
			V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
E2-06	Leakage Inductance	Leak Inductance	-	-	A	A
	Sets the motor leakage inductance in units of 0. inverter model setting (O2-04).	1%. The default setting	varies	dependi	ng on the	;
E2-07	Core-Saturation Compensation Coefficient 1	Saturation Comp1	-	-	A	A
	Setting Range:0.00 to 1.00Factory Default:0.5					
	Sets the motor iron core saturation coefficient a matically during auto-tuning, so it does not nee	at 50% of the magnetic t d to be changed.	flux. Th	nis paran	neter is so	et auto-
E2-08	Core-Saturation Compensation Coefficient 2	Saturation Comp2	-	-	A	A
	Setting Range:0.00 to 1.00Factory Default:0.75					
	Sets the motor iron core saturation coefficient a matically during auto-tuning, so it does not nee	at 75% of the magnetic f d to be changed.	flux. Th	nis paran	neter is so	et auto-
E2-09	Motor Mechanical Loss	Mechanical Loss	_	-	-	A
	Setting Range:0.0 to 10.0%Factory Default:0.0%					
	Sets the motor mechanical loss as a percentage	of motor rated output p	ower, ii	n units o	f 0.1%.	
E2-10	Sets the motor mechanical loss as a percentage Motor Iron Loss Torque Compensation <1110>	of motor rated output p Tcomp Iron Loss	ower, ii	n units o	f 0.1%.	-
E2-10	Sets the motor mechanical loss as a percentage <i>Motor Iron Loss Torque Compensation</i> <1110> Setting Range: 0 to 65535 Factory Default: 14 (Factory default dependent)	of motor rated output p <i>Tcomp Iron Loss</i> ds on inverter capacity.)	ower, in	n units o	f 0.1%.	-

**KE200** Inverter

### E3 Motor 2 Set-up

E3-01 Motor 2 Control Method Selection

Control Method

A A A A

The KE200 inverter has the capability to control 2 motors independently. A second motor may be selected using a multi-function contact input.

Select the control method best suited for your application for Motor 2.

Setting	Description
0	V/f Control - For general-purpose and multiple motor applications.
1	V/f with PG Feedback - For general-purpose applications requiring closed loop speed control.
2	Open Loop Vector ( <i>factory default</i> ) - For applications requiring precise speed control, quick response and higher torque at low speeds (150% torque below 1Hz).
3	Close loop vector - For applications requiring very precise speed and torque con- trol at a wide speed range including 0 speed. Uses encoder



The following is a list of parameters that become effective when motor 2 is selected.

Function E3 Control Method 2		Fund V/F P	ction E4 Pattern 2	Function E5 Motor Setup 2		
E3-01	Control Method 2	E4-01	Max Frequency	E5-01	Motor Rated FLA	
		E4-02	Max Voltage	E5-02	Motor Rated Slip	
		E4-03	Base Frequency	E5-03	No-Load Current	
		E4-04	Mid Frequency	E5-05	Term Resistance	
		E4-05	Mid Voltage	E5-06	Leak Inductance	
		E4-06	Min Frequency			
		E4-07	Min Voltage			

The inverter must be stopped to switch motors.

The motor 2 parameters are identical to the motor 1 parameters. Refer to E1-03 through E1-10.

E4-01	Motor 2 Maximum Frequency	Max Frequency	А	А	A	А
<i>E4-02</i>	Motor 2 Maximum Voltage	Max Voltage	А	A	A	A
E4-03	Motor 2 Base Frequency	Base Frequency	А	A	A	A
<i>E4-04</i>	Motor 2 Middle Output Frequency A	Mid Frequency A	А	А	А	-
<i>E4-05</i>	Motor 2 Middle Output Voltage A	Mid Voltage A	А	А	А	-
<i>E4-06</i>	Motor 2 Minimum Output Frequency	Min Frequency	А	А	А	A
<i>E4-07</i>	Motor 2 Minimum Output Voltage	Min Voltage	А	A	AA	-
<i>E5</i>	Motor 2 Set-up					
E5-01	Motor 2 Rated Current	Motor Rated FLA	А	A	A	A

Sets the motor rated current in units of 0.01A for inverter models 27P5, 47P5 and smaller; 0.1A for models G5U2011, G5U4011 and larger. The default setting varies depending on the inverter model setting (02-04).

E5-02 Motor 2 Rated Slip Frequency

0.00 to 20.00Hz Setting range:

Sets the motor rated slip frequency in units of 0.01Hz. The default setting varies depending on the inverter model setting (O2-04). Use the following equation to calculate the motor rated slip frequency:

 $f_s = f - \frac{(N * P)}{120}$ 

where:

f : slip frequency (Hz) f: rated frequency (Hz)

N : rated motor speed (rpm)

P: number of motor poles

E5-03 Motor 2 No-Load Current

Sets the motor no-load current in units of 0.01A for inverter models 27P5, 47P5 and smaller; 0.1A for models G5U2011, G5U4011 and larger. The default setting varies depending on the inverter model setting (02-04).

E5-04 Motor 2 Number of Motor Poles

Setting Range: 2 to 48 poles 4 poles Factory Default:

Sets the number of motor poles for motor 2.

**KE200** Inverter

V/f V/f w/PG Vector Vector

ated Slip	А	А	A	A	

Number of Poles

No-Load Current

А А

А А А

Motor R

А

Open Loop Close Loop

### KE200 Inverter

				V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
E5-05	Motor 2 Terminal Resistan	се	Term Resistance		A A	A	A
	Sets the motor phase-to-ph	ase resistance value in u	nits of 0.01W.				
	Motor Terminal Resistance =	Phase-to-Phase Resistance at	273 + (25°C + ins	ulation class	temperatu	re) / 2	
		Insulation Class Temperature	×273 + insul	ation class te	emperature		

					V/f	V/f w/PG	Open Loop Vector	Close Vect	Loop tor
	The default	t setting varies	depending on the inver	ter model setting (O2-	-04).				
E5-06	Motor 2 Le	eakage Inducta	nce	Leak Inductance		A	-	A	A
	Sets the mo	otor leakage ind odel setting (O2	luctance in units of 0.1 <sup>e</sup> 2-04).	%. The default setting	varies	dependi	ng on the	•	
F	Option Para	ameters							
F1	<b>PG Option</b> These para	<i>Set-up</i> meters can be	accessed during operation	on using a pulse gener	rator (P	G) for sj	peed feed	lback.	
	When acce nected.	ess level is BAS	SIC (A1-03), the parame	eter is not displayed u	nless th	e option	card is c	con-	
F1-01	PG Pulses	per Revolution		PG Pulses/Rev		-	Q	-	Q
	Setting Ran Factory De	nge: 0 to 6 efault: 1024	50000						
	Sets the nu	mber of PG pu	lses per motor revolutio	on (pulses/rev).					
F1-02	PG Discon	nection Detect	ion Stopping Method	PG Fdbk Loss Sel		-	В	-	В
	Selects the	stopping meth	od when a disconnected	PG is detected.					
		Setting		Description					
		٥	Pamp to stop according	to C1_02					

Setting	Description
0	Ramp to stop - according to C1-02
1	Coast to stop (factory default)
2	Fast-stop according to C1-09
3	Alarm flashes, operation continues (this setting is disabled during close loop vector control)

ation Detection	Stopping Method PG De	viation Sel	-	В		
he stopping met	hod when excessive speed deviation	on is detected	1.			
Setting	Descriptio	n				
0	Ramp to stop - according to C1-02					
1	Coast to stop					
2	Fast-stop according to C1-09					
3	Alarm flashes, operation continues	(factory default)	)			
ition Selection	PG Ra	tation Sel	-	В		
non selection						
relationship bet	ween the motor rotation direction	and PG polar	ity.			
relationship bet	ween the motor rotation direction	and PG polar	ity.			
relationship bet Setting 0	ween the motor rotation direction Descriptio Motor FWD direction is counterclock	and PG polar on wise <i>(factory</i> d	ity. lefault).			
relationship bet Setting 0 1	ween the motor rotation direction Description Motor FWD direction is counterclock Motor FWD direction is clockwise.	and PG polar on wise <i>(factory o</i>	ity. lefault).			
relationship bet Setting 0 1 or rotation direc	ween the motor rotation direction Description Motor FWD direction is counterclock Motor FWD direction is clockwise. tion applies when viewing the mo	and PG polar on wise <i>(factory a</i> otor shaft fron	ity. <i>lefault).</i> n the load s	j ide.		

### F1-03 Overspeed Detection Stopping Method PG Overspeed Sel

Selects the stopping method when an overspeed condition is detected.

Setting	Description
0	Ramp to stop - according to C1-02
1	Coast to stop (factory default)
2	Fast-stop according to C1-09
S	Alarm flashes operation continues (this setting is disabled

### F1-04 PGL

Selec

F1-05 PG R

Sets

The

F1-06 PGL

В

Setting Range: 1 to 132 Factory Default: 1 Sets the division ratio for monitoring the PG pulse signals.

**KE200** Inverter V/f w/PG

-

V/f

-

В

Close Loop Vector Open Loop Vector

В

В

В

					V/f	KE2 V/f w/PG Open Lo	op Close L
	Division Ra	tio = $\frac{n+1}{m}$		— m: 1 to 3 — n: 0, 1	32		
	Setting I When F	Example: 1-06 is set to '	132", then the division ratio = $\frac{1}{2}$	$\frac{+1}{32} = \frac{2}{16}$			
	This parameter is effective o	nly when t	he printed circuit board	PG-B2 is	used		
F1-07	Integral Value During Accel	Decel	PG Ramp PL	I/I Sel		- В	
	Selects whether speed contro	ol (ASR) in	tegral operation is activation	ated durin	ig aco	celeration/dece	eleration.
	Setting		Description				
	0	Inte	gral operation disabled (faci	tory defaul	lt)		
	I		integral operation enac	Jieu			
F1-08	Overspeed Detection Level		PG Overspa	! Level		- A	- A
	Setting Range:0 to 120Factory Default:115%	%					
	Sets the motor overspeed det	ection lev	el as a percentage of max	aimum ou	itput	frequency (E1	-04).
F1-09	Overspeed Detection Time		PG Overspd	Time		- A	- A
	Setting Range:0.0 to 2.Factory Default:0.0s	0s					
	Sets the elapsed time from w	hen an ov	erspeed condition is deter	cted to w	hen a	a fault occurs.	
	Overspeed Level (F1	-08)	IMot	or Speed			
		0					
	Overspeed Fault Sig	ınal ———	OFF	ON	1		
	Figur	e 29 Overs	peed Detection Timing Di	agram			
	A fault signal is output to sto	p operatio	n after the absolute value	e of the m	notor	speed exceeds	the set

When parameter A1-02=1 [V/f w/PG] the factory setting will be 1.0. When parameter A1-02=3 [Close Loop Vector] the factory setting will be 0.0.

micno			
			l

KE200 Inverter

Close Loop

Vector

Open Loop

Vector

V/f

V/f w/PG

F1-10	PG Deviation Dete	ection Level	PG Deviate Level	-	А	-	A
	Setting Range: Factory Default:	0 to 50% 115%					
	Sets the excessive s	peed deviation	detection level as a percentage of maxim	mum outp	out freq	uency (A	E1 <b>-</b> 04).
F1 <b>-</b> 11	PG Deviation Dete	ection Time	PG Deviate Time	-	А	-	A
	Setting Range: Factory Default:	0.0 to 2.0s 0.0s					

Sets the elapsed time from when excessive speed deviation is detected to when a fault occurs.



Figure 30 Overspeed Detection Timing Diagram

A fault signal is output to stop operation after the deviation between speed reference and the motor speed exceeds the set value of F1-10 and after the time set to F1-11 elapses. The stopping method is set by F1-04. Also, detection is not activated while accelerating/decelerating or during torque control.

<i>F1-12</i>	Number of Teeth C	Fear I	PG # Gear Teeth1	-	А	-	-	
F1 <b>-</b> 13	Number of Teeth C	Gear 2	PG # Gear Teeth2	-	A	-	-	
	Setting Range: Factory Default:	0 to 1000 0						

Sets the number of teeth for each gear when gears are installed between the motor and the PG. When the number of gear teeth is set, the motor revolutions per minute (rpm) are calculated as shown below.

No. of Motor RPM's =  $\frac{\text{No. of PG Output Pulses \times 60}}{\text{PG Pulses/Revolution}(F1-01)} \times \frac{\text{No. of Teeth Gear 2 (F1-13)}}{\text{No. of Teeth Gear 1 (F1-12)}}$ 

This function is disabled when either F1-12 or F1-13 = "0".

**KE200** Inverter

				V/	f	V/f w/P	G	Open Loop Vector	Close Loop Vector
			-						
F1-14	PGO Detection Tir	ne	PGO Detect Time		-		А	-	А
	Setting Range:	0.0 to 10 seconds							
	Factory Default:	2 seconds							
	Parameter F1-14 se	ets the time from when t	he pulse generator (PG) sig	nal i	s m	issing	g to	when th	ne fault

signal is displayed. The stopping method when a "PGO" fault is detected is selected by parameter F1-02. If a speed reference is commanded, but the motor is physically locked, a "PGO" fault will occur even

### F2 AI-14B Set-up

F2-01 Bipolar or Unipolar Input Selection AI-14 Input Sel A A A

Sets CH1 to CH3 input functions when AI-14B option is connected.

though the PG is not disconnected from the inverter.

Setting	Function	CH1 (TC1 to TC4)	CH2 (TC2 to TC4)	CH3 (TC3 to TC4)
0	3-channel individual input (factory default)	Substitute for terminals 13 and 17	Substitute for terminals 14 and 17	Substitute for terminals 16 and 17
1	3-channel additional input	Sum of CH1 to CH3 reference value.	input values is used a	as the frequency

When the 3CH individual input is used, parameter B1-01 is automatically set to "l" (frequency reference from control circuit terminal). The option/inverter reference selection, which is selected by a multi-function contact input ( $H1-_=$  "2"), is disabled when using the AI-14B option.

V/f V/f w/PG	Open Loop Vector	Close Loop Vector
--------------	---------------------	----------------------

### *F3 DI-08/DI-16H Set-up*

### F3-01 Digital Input Option

DI Input

A A A

А

А

Selects the setting mode of the frequency reference input from the DI-08 and DI-16H options.

Setting	Frequency Ref	ference Setting Mode
0	BCD 1% unit (factory defau	lt)
1	BCD 0.1% unit	
2	BCD 0.01% unit	
3	BCD 1Hz unit	
4	BCD 0.1Hz unit	
5	BCD 0.01Hz unit	
6	Binary DI-08: DI-16H, 12-bit selection: DI-16H, 16-bit selection:	255/100% 4096/100% 30000/100%
7	Binary, set value is displayed in decimal notation.	

### *F4* AO-08/AO-12 Set-up

F4-01 Analog Output Channel 1 Selection

AO CH1 Select

A A A

Selects the analog output monitors for channel 1 of the AO-08 and AO-12 options.

### Analog Output Channel 1 Selection

F4-01 Setting	Function	Description
1	Frequency reference	Monitors the frequency reference value. 10V= Max frequency (0-+/-10V possible)
2	Output frequency (factory default)	Monitors the output frequency. 10V= Max frequency (0-+/-10V possible)
3	Inverter output current	Monitors the output current. 10V=Rated current (0 to +10V output)
5	Motor speed	Monitors the motor speed. 10V= Max frequency (0 to +/- 10 V possible)
6	Output voltage	Monitors the inverters internal output voltage reference value. 10V=200 or 400 VAC
7	DC bus voltage	Monitors the DC voltage of the inverters internal main circuit. 10V=400 or 800 VDC (0 to +10V output)
8	Output power	Monitors the output power, this is an internally detected value. 10V=Max motor capacity. (0 to +/-10 V possible)
9	Torque reference (internal)	Monitors the internal torque reference value when vector control is used. 10 V=Rated torque. (0 to +/-10V possible)
10-14	Not Used	
15	Terminal 13 input voltage level	Monitors the input voltage of the frequency reference (voltage). An input of 10 V corresponds to 100%. 10 V=100% (10 V) 0 to +/-10 V possible.
16	Terminal 14 input voltage or current level	Monitors the input current of the frequency reference. (current) An input of 20 mA corresponds to 100%. 20 mA=100% (20 mA) 0 to + 10 V output.
17	Terminal 16 input voltage level	Monitors the input voltage of the multi-function analog input. An input of 10 V corresponds to 100%. 10 V= 100% (10 V). (0 to +/-10 V possible)

V/f V/f w/PG Open Loop Vector Close Loop Vector

F4-01 Setting	Function	Description
18	Motor secondary current (Iq)	Monitors the calculated value of the motors secondary current. (Iq) The motors rated secondary current corresponds to 100%. 10 V=Rated secondary current. (0 to + 10 V output)
19	Motor excitation current (Id)	Monitors the calculated value of the motors excitation current. (Id) The motors rated excitation current corresponds to 100%. 10 V=Rated excitation current. (0 to + 10 V output).
20	SFS output frequency	Monitors the output frequency after a soft start. This is the frequency without the correction from compensation functions such as slip compensation. 10 V=Max. frequency (0 to +/- 10 V possible)
21	ASR input	Monitors the input to the speed control loop. The max. frequency corresponds to 100%. 10 V=Max. frequency (0 to +/- 10 V possible)
22	ASR output	Monitors the output from the speed control loop. Analog monitor becomes 10 V/ max. output frequency with V/F control. In vector control the analog monitor be- comes 10V= motor rated excitation current. (0 to +/-10V possible.)
23	Speed deviation	Monitors the speed deviation within the speed control loop. The max. frequency corresponds to 100%. 10 V=Max. frequency (0 to +/-10 V possible.)
24	PID feedback	Monitors the feedback value when the PID control is utilized. The input for the max. frequency corresponds to 100%. 10 V= Max frequency. (0 to +/-10 V possible.)
25	Not Used	
26	Voltage reference (Vq output)	Monitors the inverters internal voltage reference value for the motors secondary current control. 10 V= 200 or 400 VAC (0 to =/- 10 V possible.)
27	Voltage reference (Vd output)	Monitors the inverters internal voltage reference value for the motors excitation current control. 10 V= 200 or 400 VAC (0 to =/- 10 V possible.)
28-30	Not Used	
31	Not Used	
32	ACR(q) Output	Monitors current control output value for the motors secondary current. 10 V= 100%.
33	ACR(d) Output	Monitors current control output value for the motors excitation current. 10 V= 100%.
34-35	Not Used	
36	PID Input Monitor	Monitors the input to the PID circuit. This is the PID reference + the PID reference bias - the PID feedback. 10 V= Max frequency.
37	PID Output Monitor	Monitors the output of the PID circuit. 10 V= Max frequency.
38	PID Setpoint or Reference	Monitors the PID setpoint. This is the PID setpoint + the PID setpoint bias. 10 V= Max frequency.

### Analog Output Channel 1 Selection (Continued)

F4-02 Analog Output Channel 1 Gain

AO CH1 Gain

А	А	A	А

Setting Range: 0.00 to 2.50 Factory Default: 1.00

Sets the channel 1 output gain for the analog output monitors. To obtain the output level, multiply the monitor output level by the gain value set in F4-02.

#### micno **KE200** Inverter Open Loop Close Loop V/f w/PG V/f Vector Vector F4-03 Analog Output Channel 2 Selection AO CH2 Select А А А А Setting Range: Same as *F4-01* Inverter output current (setting = "3") Factory Default: Selects the analog output monitors for channel 2 of the AO-08 and AO-12 options. F4-04 Analog Output Channel 2 Gain AO CH2 Gain А A A А Setting Range: 0.00 to 2.50 Factory Default: 0.50 Sets the channel 2 output gain for the analog output monitors. To obtain the output level, multiply the monitor output level by the gain value set in F4-04. F4-05 Analog Output Channel 1 Bias AO CH1 Bias А А А А Setting Range: -10.0 to +10.0Factory Default: 0.0 Sets the channel 1 output bias for the analog output monitors. This is for the AO-08 and AO-12 option cards. AO CH2 Bias F4-06 Analog Output Channel 2 Bias А А А А Setting Range: -10.0 to +10.0

Factory Default: 0.0

Sets the channel 2 output bias for the analog output monitors. This is for the AO-08 and AO-12 option cards.

### F5 DO-02 Set-up

The DO-02C option card has 2 form C type dry contacts. Each of the dry contacts can be individually set by F5-01 and F5-02.

The DO-02C option card connects to the control board at 3CN. The table is a list of items that can be selected.

F5-01 DO-02C Digital Output Channel 1 Selection DO-02

DO-02 CH1 Select

A A	А	А
-----	---	---

Selects the multi-function output selections for channel 1 of the DO-02C option. For detailed information on these settings, refer to section *H2*, *Digital Outputs*, on page 88.

Setting	Description	Setting	Description
0	During run 1 (factory default)	13	Fref/Fout agree 2
1	Zero speed	14	Fref/set agree 2
2	Fref/Fout agree 1	15	Frequency detection 3
3	Fref/set agree 1	16	Frequency detection 4
4	Frequency detection 1	17	Torque detection 1 (N.C.)
5	Frequency detection 2	18	Torque detection 2 (N.O.)
6	Inverter ready	19	Torque detection 2 (N.C.)
7	DC bus undervoltage	1A	Reverse direction
8	Baseblock 1	1B	Baseblock 2
9	Option frequency reference	1C	Motor 2 selected
А	Remote operation	1D	Regenerating
В	Torque detection 1 (N.O.)	1E	Restart enabled
С	Loss of reference	1F	Overload (OL1)
D	DB overheat	20	OH pre-alarm
E	Fault	30	Current/torque limit
F	Not used	31	Speed limit
10	Minor fault	33	Zero servo end
11	Reset command active	37	During run 2
12	Timer output	-	

F5-02 DO-02C Digital Output Channel 2 Selection

DO-02 CH2 Select

A A A A

Setting Range:Same as F5-01Factory Default:Zero speed (setting = "1")

Selects the multi-function output selections for channel 2 of the DO-02C option.

V/f V/f w/PG Open Loop Close Loop Vector

### F6 DO-08 Set-up

F6-01 DO-08 Digital Output Selection

DO-08 Selection

A	А	А	А

Selects the multi-function output selections for the DO-08 option.

Setting	Terminal No.	Description	
	TD5/TD11	Overcurrent (SC, OC, GF)	
	TD6/TD11	Overvoltage (OV)	
0	TD7/TD11	Inverter overload (OL2)	
8-channel	TD8/TD11	Fuse blown (FU)	
individual	TD9/TD11	Not used	
(factory default)	TD10/TD11	Inverter overheat (OH)	
	TD1/TD2	During zero-speed detection	
	TD3/TD4	During speed agree	
1 binary output	TD5/TD11		
	TD6/TD11	Pipary output *	
	TD7/TD11		
	TD8/TD11		
	TD9/TD11	During zero-speed detection	
	TD10/TD11	During speed agree	
	TD1/TD2	During run	
	TD3/TD4	Minor fault	

\* When F6-01 is set to binary output (setting = "1"), use the table below to read the DO-08 output.

TD8/TD11 (bit 3)	TD7/TD11 (bit 2)	TD6/TD11 (bit 1)	TD5/TD11 (bit 0)	Description
0	0	0	0	No fault
0	0	0	1	Overcurrent (SC, OC, GF)
0	0	1	0	Overvoltage (OV)
0	0	1	1	Inverter overload (OL2)
0	1	0	0	Inverter overheat (OH)
0	1	0	1	Overspeed (OS)
0	1	1	0	Fuse blown (FU)
0	1	1	1	Not used
1	0	0	0	External fault (EF3 ~ EF8)
1	0	0	1	Controller fault
1	0	1	0	Motor overload (OL1)
1	0	1	1	Not used
1	1	0	0	Power loss (UV1, UV2, UV3)
1	1	0	1	Excessive speed deviation (DEV)
1	1	1	0	PG disconnection (PGO)
1	1	1	1	Not used

Note: When the terminal is open, the bit setting is "0"; when the terminal is closed, the bit setting is "1".

**KE200** Inverter

V/f V/f w/PG Open Loop Vector Close Loop Vector

### *F7 PO-36F Set-up*

The PO-36F option card outputs pulse signals that correspond to the inverter output frequency. These signals are used in master/slave configurations where speed matching is needed.

F7-01 PO-36F Pulse Monitor Output Selection PO-36F Selection

А	А	A	А
---	---	---	---

А

А

Sets the number of pulse signals to be output from the PO-36F option.

Setting	Number of Output Pulses
0	Inverter output frequency × 1
1	Inverter output frequency × 6 (factory default)
2	Inverter output frequency × 10
3	Inverter output frequency × 12
4	Inverter output frequency × 36

### F8 Function F8 SI-F/G Set-up

The setting of parameter F8-01 selects the stopping method when an E-15 fault is detected.

F8-01 (E-15) Detection Stopping Method E-15 Det Sel

An E-15 fault may occur when using the SI-F or SI-G communication options. The fault will occur after initial communication has been established then the connection is lost. The following fault code will be displayed:

Setting	Description
0	Ramp to stop according to C1-02 set value
1	Coast to stop.
2	Ramp to stop according to C1-09 set value.
3	Alarm flashes, operation continues.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

#### *F9 CP-916 Setup*

The CP-916 option card provides PLC and motion type functions. This allows the KE200 inverter to be a stand-alone control system.

The CP-916 option card connects to the control board at 3CN.

When the CP-916 option is installed, the 4CN speed feedback option port is the only option port that is supported.

**Specifications** 

- RS 232C communication port Used for programming the CP-916G and for communication to other devices such as PLC's or printers.
- High speed (4 Mb/s) peer to peer communication port.

 Available protocol; MEMOBUS (MODBUS) 19.2 kbps maximum. Application Download Tool 19.2 kbps maximum. CP 717 Programming Tool 9.6 kbps.

F9-01 Option External Fault Selection

EFO Selection

A A A A

Parameter F9-01 selects the initial state for an external fault condition when the inverter is configured for serial communication using the CP-916.

Setting	Description
0	When closed, the inverter will trip. (factory default)
1	When open, the inverter will trip.

The "EFO" fault code will be displayed.

F9-02 Option External Fault Detection

EFO Detection

A A A

А

Parameter F9-02 selects the condition of detection for an external fault when using the CP-916 option.

Setting	Description				
0	The fault will always be detected, even when the drive is stopped. (factory default)				
1	The fault will be detected only when the drive is running.				

F9-03 ( 7 <i>F9-04</i> 7	<i>Option Es</i> Гhe settin	cternal Fault Actions of parameter FS Setting 0 1 2 3	on EFG 0-03 selects the stopping me Desc Ramp to stop according to C Coast to stop. (factory setting Ramp to stop according to C	<i>O Fault Action</i> ethod when an El ription 1-02 set value.	V/f	V/fw/PG	A Open Loop Vector	Close La Vector
F9-03 ( 7 F9-04 7	<i>Option Es</i>	cternal Fault Actions of parameter F9 Setting 0 1 2 3	D-03 selects the stopping me D-03 selects the stopping me Desc Ramp to stop according to C Coast to stop. (factory setting Ramp to stop according to C	<i>O Fault Action</i> ethod when an El ription 1-02 set value.	F0 fau	A A	A cted.	A
F9-04 T	The settin	g of parameter F9 Setting 0 1 2 3	D-03 selects the stopping me Desc Ramp to stop according to C Coast to stop. (factory setting Ramp to stop according to C	ethod when an El ription 1-02 set value.	F0 fau	lt is dete	cted.	
F9-04 T		Setting 0 1 2 3	Desc Ramp to stop according to C <i>Coast to stop. (factory setting</i> Ramp to stop according to C	ription 1-02 set value.				
F9-04 1		0 1 2 3	Ramp to stop according to C Coast to stop. (factory setting Ramp to stop according to C	1-02 set value.				
79-04 7		1 2 3	Coast to stop. (factory setting Ramp to stop according to C					
F9-04 1		2 3	Ramp to stop according to C	g)				
F9-04 1		3		1-09 set value.				
F9-04 1			Alarm flashes, operation con	tinues.				
F9-04 1						]		
ç	Trace San	nple Time	Tra	ce Sample Tim		A A	А	A
I	Setting Ra Factory D	ange: 0-6000 Default: 0	0	x the CP 016P or	ation	ard		
1	Faramete	r 9-04 sets the tra	ace sample time when using	g the CP-910D of		aru.		
F9-05 7	Torque Re	eference/Torque La	imit Select (CP-916) Tor	g Ref/Lmt Sel			-	A
т	Doromotor	= E0.05 allows the	CP 016 option card to set t	the torque limits	when	tha inva	rtor is in	tha
I S	speed con	trol mode and the	torque reference when one	rating in the torc	me cor	ntrol mo	de	IIC
-	· · · · · · · · ·				[			
		Setting	Desc	ription				
		0	Disabled -Torque reference/t gram parameters or by analog	torque limits set by og input.	G5 pro	0-		
		1	Enabled - Torque reference/t gram parameters, analog inp default)	torque limits set by put, or by the CP-93	/ G5 pr 16. (fac	o- tory		
		Operat	ion Truth Table for Paramet	ter F9-05				
Se	et Value	Speed C	ontrol (Torque Limit)	Torque Con	trol (To	rque Ref	erence)	
F9	9-05 = 0	Set by parameter of	or analog input.	Set by analog in	out tern	ninal 14 d	or 16.	
F٤	9-05 = 1	Set by CP-916 opti input.	on card, parameter, or analog	Set by CP-916 o	ption ca	ard.		
1	Note: The ana	e inverter will use log input termina	the lowest value from the C ls 14 or 16.	CP-916, L7-01 to	0 L7-04	4, or the	multi-fur	nction

			V/f	V/f	w/PG	Open Loop Vector	Close Loop Vector
F9-06	Bus Fault Select	Bus Fault Sel		A	A	A	A

The setting of parameter F9-06 selects the stopping method when an BUS fault is detected. A BUS fault may occur when using the SI-B or the CP-916 communication options. The fault will occur after initial communication has been established then the connection is lost. The following fault code will be displayed: "BUS SI-B Com Err".

Setting	Description
0	Ramp to Stop - Ramp to stop according to C1-02 set value.
1	Coast to stop.
2	Fast-Stop - Ramp to stop according to C1-09 set value.
3	Alarm Only - Alarm flashes, operation continues.

### H Control Circuit Terminal Parameters

### H1 Digital Inputs

The KE200 series has six multi-function contact inputs for the set-up of numerous functions, including multi-step speed operation, PID, speed search, speed/torque control selection, and many other. This section includes descriptions of these functions.

H1-01	Multi-function Input Terminal 3 Selection	Terminal 3 Sel	В	В	В	В
<i>H1-02</i>	Multi-function Input Terminal 4 Selection	Terminal 4 Sel	В	В	В	В
<i>H1-03</i>	Multi-function Input Terminal 5 Selection	Terminal 5 Sel	В	В	В	В
<i>H1-04</i>	Multi-function Input Terminal 6 Selection	Terminal 6 Sel	В	В	В	В
H1-05	Multi-function Input Terminal 7 Selection	Terminal 7 Sel	В	В	В	В
<i>H1-06</i>	Multi-function Input Terminal 8 Selection	Terminal 8 Sel	В	В	В	В

The following table lists the function selections for the multi-function contact inputs (terminals 4 to 8), and indicates the control modes during which each function can be enabled.

H1-01			Control Method	d (A1-02)		Deference
to 6 Setting	Function	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	Page
0	3-Wire Control	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1	Local/Remote Selection	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
2	Option/Inverter Selection	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
3	Multi-Step Ref. 1 (factory default, H1-03)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
4	Multi-Step Ref. 2 (factory default, H1-04)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
5	Multi-Step Reference 3	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
6	Jog Frequency Ref. (factory default, H1-05)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
7	Multi-Accel/Decel 1	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
8	Ext. Baseblock N.O. (factory default, H1-06)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
9	External Baseblock N.C.	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
A	Accel/Decel Ramp Hold	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
В	OH2 Alarm Signal	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
С	Terminal 16 Enable	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
D	V/f Mode Selection	-	$\checkmark$	-	-	
E	ASR Integral Reset	-	$\checkmark$	-	$\checkmark$	
10	MOP Increase	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
11	MOP Decrease	$\checkmark$				

#### **KE200** Inverter

V/f V/f w/PG Open Loop Vector Close Loop Vector

H1-01			Control Metho	d (A1-02)		Deference
to 6 Setting	Function	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	Page
12	Forward Jog	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
13	Reverse Jog	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
14	Fault Reset (factory default, H1-02)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
15	Fast-Stop	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
16	Motor 2 Select	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
17	Fast-Stop (Closed, motor decels by C1-09) <1110>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
18	Timer Function	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
19	PID Disable	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1A	Multi-Accel/Decel 2	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1B	Program Lockout	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1C	Trim Control Increase	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1D	Trim Control Decrease	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1E	Reference Sample Hold	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1F	Terminal 13/14 Switch	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
20-2F	External Fault (factory default, H1-01)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
30	Closed: PID Integral is Reset	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
31	Closed: PID Integral Value is Held <1110>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
60	DC Injection Activate	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
61	Speed Search 1	$\checkmark$	-	$\checkmark$	-	
62	Speed Search 2	$\checkmark$	-	$\checkmark$	-	
63	Energy Saving Command	$\checkmark$	$\checkmark$	-	-	
64	Speed Search 3	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
65	KEB Ridethrough N.C.	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
66	KEB Ridethrough N.O	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
71	Speed/Torque Control Change	-	-	-	$\checkmark$	
72	Zero Servo Command	-	-	-	$\checkmark$	
77	ASR Gain Switch	-	-	-	$\checkmark$	

· 3-Wire Control (setting: "0")

When *H1*-\_\_\_\_is set to "0", 3-wire control is enabled. The terminal set to "0" becomes the FWD/REV run command.



Figure 31 Terminal Function at 3-Wire Sequence Selection (H1-\_\_= "0")

\// <del>f</del>		Open Loop	Close Loop	
V/I	V/IW/PG	Vector	Vector	

· Local/Remote Selection (setting: "1")

Selects the operation mode, only when the inverter is stopped.

- Local: Operation according to frequency reference and run command from digital operator.
- Remote: Operation according to frequency reference and run command set by *B1-01* and *B1-02*, respectively.
- Note: When local/remote selection is set by a multi-function contact input terminal, local/remote selection from the digital operator key is disabled.
- Option/Inverter Selection (setting: "2")

Selects whether operation is performed using a reference command from an option card or from the inverter. Selection is effective only when the inverter is stopped.

- Open: Runs by frequency reference and run command from inverter control circuit terminal or digital operator.
- Closed: Runs by frequency reference and run command from an option card.

Multi-Step Ref 1 through 3 and Jog Freq Ref (Set value = 3, 4, 5, and 6)

Terminal 8 (H1-06 = 6)	Terminal 7 (H1-05 = 5)	Terminal 6 (H1-04 = 4)	Terminal 5 (H1-03 = 3)	Preset
Jog Freq Ref	Multi-Step Ref 3	Multi-Step Ref 2	Multi-Step Ref 1	Reference
0	0	0	0	Reference 1 (d1-01)
0	0	0	Х	Reference 2 (d1-02)
0	0	X	0	Reference 3 (d1-03)
0	0	Х	Х	Reference 4 (d1-04)
0	X	0	0	Reference 5 (d1-05)
0	Х	0	Х	Reference 6 (d1-06)
0	X	Х	0	Reference 7 (d1-07)
0	X	X	Х	Reference 8 (d1-08)
Х		_		Jog Reference (d1-09)

**O** - Open

X - Closed

-- Has no effect

d1-01 is effective when b1-01 is set to 0 (reference from the digital operator)

d1-02 is effective when the terminal 16 setting (H3-05) is set to anything other than zero.


V/f V/f w/PG Open Loop Vector Vector

It is possible to mix analog and digital references in the multi-speed input function. The parameters must be set as shown below

Parameter	Reference	Digital	Analog
(d1-01)	Reference 1	b1-01 = 0	b1-01 = 1 (terminal 13 or 14)
(d1-02)	Reference 2	H3-05 0	H3-05 = 0 (terminal 16)
(d1-03)	Reference 3	d1-03	
(d1-04)	Reference 4	d1-04	
(d1-05)	Reference 5	d1-05	
(d1-06)	Reference 6	d1-06	not available
(d1-07)	Reference 7	d1-07	
(d1-08)	Reference 8	d1-08	
(d1-09)	Jog Reference	d1-09	

· Multi Accel/Dec1 (Set value = 7)

Open: Acceleration 1 / Deceleration 1 is set by parameters C1-01 and C1-02 respectively. Closed: Acceleration 2 / Deceleration 2 is set by parameters C1-03 and C1-04 respectively.



· External Baseblock N.O. (setting: "8")

Baseblock operation is performed when the contact output is closed. External baseblock operation differs as described below, depending on the run command input status.

When an external baseblock signal is input while the inverter is running, BB blinks on the digital operator display, and the inverter output is shut OFF. When the external baseblock signal is removed, operation restarts at the previous frequency reference before baseblock. Output voltage is then increased up to its previous level before baseblock, in the voltage recovery time (L2-04). When a stop signal is input and an external baseblock signal is input while the inverter is decelerating, BB blinks on the digital operator, the inverter output shuts OFF and the frequency reference is set to 0.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

• External Baseblock N.C. (setting: "9")

Baseblock operation is performed similar to setting "8", except that operation is performed when the contact output is closed.

· Accel/Decel Hold Command (setting: "A")

The accel/decel hold command is used to temporarily hold the output frequency at the current frequency reference, when the hold command is input. When a stop command is input, the accel/decel hold condition is released and operation stops.



Figure 32 Accel / Decel Hold Command Timing Diagram

Notes:

- 1. When hold reference memory selection is enabled (D4-01 = "1") and an accel/decel hold command is input, by inputting a run command again after a stop command is input, the held output frequency is stored unless the accel/decel stop command is released. Operation resumes at the stored frequency.
- 2. When the power supply is turned OFF after the accel/decel hold command is input, the held output frequency is also stored.
- 3. When *D4-01* is set to "0". the held output frequency is not stored,
- Inverter Overheat OH2 Alarm (setting: "B")
   When the inverter overheat alarm signal is input, OH2 blinks on the digital operator display. This contact can be connected to an external temperature switch for monitoring the inverter ambient temperature. A multi-function contact output (H2-\_\_) can be set to "20" to close a contact at this condition.
- Multi-function Analog Input Selection (setting: "C")
   This setting disables the terminal 16 multi-function analog input.

Open: Terminal 16 command is not accepted. Closed: Terminal 16 command is accepted.

- Feedback Mode During V/f Selection (setting: "D")
  - Feedback input can be disabled while the inverter is running when this function is selected. However, the speed control integral value (C5-05) is held until stop.

Open: Feedback control enabled (closed loop)

Closed: Feedback control disabled (open loop)

This function is available only during V/f control with PG feedback.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

Speed Control Integral Value Reset (setting: "E")

The speed control integral value can be reset while the inverter is running when this function is selected. Reset is effective only when integral control selection during accel/decel (F1-07) = "0".

Open: PI-control (speed control integral values are added.)

Closed: P-control (speed control integral values are reset by the integral time constant.) Up/Down Command (settings: Up = "10". Down = "11")

With the FWD (REV) run command entered, a change in frequency is performed by inputting the Up or Down signals to any two contact inputs, so that operation can be performed at the desired speed.

UP command	Closed	Open	Open	Closed
DOWN command	Open	Closed	Open	Closed
Operation Status	Accel	Decel	Hold	Hold



U: Up (accelerating) status

- D: Down (decelerating) status
- H: Hold (constant speed) status
- U1: Up status, with clamping at upper limit speed
- D1: Down status, with clamping at lower limit speed

Figure 33 UP/DOWN Command Timing Diagram

Notes:

- 1. Be sure to set frequency reference selection (B1-01) = "1". When B1-01 = "0", Up/Down operation is disabled.
- 2. Upper limit speed

= Max. output frequency (E1-04)  $\times$  Frequency reference upper limit (D2-01), if used

- 3. The lower limit value is either the master frequency reference from control circuit terminals 13 or 14, or the frequency reference lower limit (*D2-01*), whichever is larger.
- 4. When hold reference memory selection is enabled (D4-01 = "1") and a hold command is input, the held output frequency is stored even after the power supply is turned OFF. When D4-01 = "0", the held output frequency is *not* stored.
- 5. If the jog frequency reference is input during Up/Down operation, the jog frequency reference has priority.

KE200 Inverter

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

• Forward and Reverse JOG commands (settings: Fwd. Jog = "12", Rev Jog = "13") Forward and reverse run jog frequency commands are enabled.

Setting	Description
12	Forward jog command is closed, run at jog frequency reference ( <i>D1-09</i> ).
13	Reverse jog command is closed, run at jog frequency reference ( <i>D1-09</i> ).

Notes:

- 1. When either the forward or reverse jog command is input during run, this command has priority.
- 2. When both the forward and reverse jog commands are closed for more than 500ms, the inverter stops according to the stopping method selection (*Bl-03*).
- 3. The forward and reverse jog commands can be set independently.
- Fault Reset (setting: "14")

Closing this contact resets a fault after the condition is removed.

• Fast-Stop (Set value = 15)

Open: The inverter operates normally.

Closed: The inverter decelerates to stop using deceleration time C1-09 (factory set to 10 sec.). The run command can remain closed during this period of time. The inverter will not run, from the external terminals or the digital operator as long as this input is closed. To restart the inverter, the run command must be cycled.

• Motor 2 Select (Set value = 16)

Open: Motor 1 is selected. Closed: Motor 2 is selected. When Motor 2 is selected, the following parameters are effective;

The inverter must be stopped to switch motors.

A multi-function digital output may be programmed when motor 2 is selected. Refer to page 88 for more information.

• Fast-Stop (setting: "17") <1110>

When this input is closed the motor decelerates to a stop using the rate defined by parameter C1-09.

• Timer Function (Set value = 18)

The timer function works independently from the inverter.

The timer input must be on longer than the time in b4-01 for the output to close.

The timer input must be off longer than the time in b4-02 for the output to open.

b4-01 is the on-delay time setting (0.0 - 300.0 second) b4-02 is the off-delay time setting (0.0 - 300.0 second)

#### **KE200** Inverter

Close Loop

Vector

Open Loop

Vector

V/f w/PG

V/f



- PID Disable (Set value = 19)
   Open: PID control is enabled.
   Closed: PID control is disabled
- Program Lockout (setting: "1B")
   Opening this contact prohibits the changing of VS-616G5 parameters.
  - $\cdot$  TrimCtl Increase (Set value = 1C)
  - TrimCtl Decrease (Set value 1D)

Closed: Increases or decreases the output frequency based on the setting of d4-02 (trim control level). This function is not available when the reference is set from the digital operator.

· Analog Reference Sample/Hold Selection (setting: "1E")

If the contact input closes for 100ms or longer, the analog frequency reference is sampled once, after which the analog frequency reference is held.



Figure 34 Sample/Hold Selection - Analog Reference

Note: t1, t3 - Reference is held at 100ms or longer. t2 - Reference is *not* held at less than 100ms.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

• Terminal 13/14 Selection (setting: "1F")

Open: Terminal 13 is used for the master frequency reference.

Closed: Terminal 14 is used for the master frequency reference.

• External Fault (setting: "20-2F") Use this contact input to select how the inverter responds to an external fault.

External Fault Selection								
Input Level	Selection	Detectio	n Method	External Fault Action			Setting	
N.O.	N.C.	Always	During Run	Ramp to Stop	Coast to Stop	Fast-stop	Alarm Only	Tresur
$\checkmark$		$\checkmark$		$\checkmark$				20
$\checkmark$		$\checkmark$			$\checkmark$			24
$\checkmark$		$\checkmark$				$\checkmark$		28
$\checkmark$		$\checkmark$					$\checkmark$	2C
$\checkmark$			$\checkmark$	$\checkmark$				22
$\checkmark$			$\checkmark$		$\checkmark$			26
$\checkmark$			$\checkmark$			$\checkmark$		2A
$\checkmark$			$\checkmark$				$\checkmark$	2E
	$\checkmark$	$\checkmark$		$\checkmark$				21
	$\checkmark$	$\checkmark$			$\checkmark$			25
	$\checkmark$	$\checkmark$				$\checkmark$		29
	$\checkmark$	$\checkmark$					$\checkmark$	2D
	$\checkmark$		$\checkmark$	$\checkmark$				23
	$\checkmark$		$\checkmark$		$\checkmark$			27
	$\checkmark$		$\checkmark$			$\checkmark$		2B
	$\checkmark$		$\checkmark$				$\checkmark$	2F

Notes:

1. N.O. = normally open contact; N.C. = normally closed contact

2. Setting "24" is the factory default.

3. Set up the external fault function according to the following tree:

Note: When the set value of Terminal 14 Selection (H3-09) is other than "1F" and the contact input is set for terminal 13/14 selection ( $H1-\_=$  "1F"), a setting error (OPE3) occurs.





- PID Integral reset (Set value = 30)
   Open: PID Integral values are added.
   Closed: PID Integral value is set to zero.
- PID Control Integral Hold (Set value = 31) <1110> Closed: Integral value of the PID control is held.
- DC Injection Braking Command (setting: "60")

When a DC injection braking command is input while the inverter is stopped, DC injection braking operation is activated. When a run command or a jog command is input, DC injection braking is released to start operation (operation has priority).



Figure 35 DC Injection Braking Contact Input Timing Diagram

V/f V/f w/PG Open Loop Close Loop Vector

Speed Search 1 and Speed Search 2 (Set value = 61 and 62)



 $\cdot$  Energy Save Mode (Set value = 63)

After the energy savings input is closed and the output frequency is equal to or greater than (b8-02) energy savings start frequency, the output voltage drops to the value in (b8-01) energy savings gain. The output voltage increases and decreases based on L2-04 (voltage recovery time).



#### **KE200** Inverter

## $\cdot$ Speed Search 3 (Set value = 64)



V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

• KEB Ridethrough (settings: N.C. = "65", N.O. = "66")

In general applications, the Kinetic Energy Braking (KEB) control circuit attempts to maintain the DC bus voltage at an optimum level  $[1.35 \times \text{input voltage} (E1-01)]$  during momentary power loss, by using load inertia to regenerate voltage back to the DC bus. The inverter decelerates at the fast-stop rate (C1-09), until power is restored, or until the time runs out and an undervoltage fault (UV) occurs. The larger the inertia, the longer the deceleration rate can be extended. If the inertia is small, then the inverter must decelerate quickly to regenerate voltage back to the DC bus, and thus the ride- through time is shorter. For most applications, set KEB Frequency Constant (L2-06) to "0" (factory default).



Figure 36 KEB Ridethrough Timing Diagram

Note: Larger model inverters (2022 and above, 4018 and above) require a separate uninterruptible power supply (UPS) for control power, in order for load inertia ridethrough to be effective.

## H2 Digital Outputs

The KE200 Series has three multi-function contact outputs for the indication of various conditions, including frequency detection, speed agree, zero speed, overtorque detection, and many others. This section includes descriptions of these functions.

H2-01	Multi-function Output 1 Selection (terminal 9, 10)	Terminal 9 Sel
<i>H2-02</i>	Multi-function Output 2 Selection (terminal 25, 27)	Terminal 25 Sel

В	В	В	В
В	В	В	В
В	В	В	В

H2-03 Multi-function Output 3 Selection (terminal 26, 27) Terminal 26 Sel

The following table lists the function selections for the multi-function contact outputs (terminals 9, 25 and 26), and indicates the control modes during which each function can be enabled.

H2-01 to			Deference			
3 Setting	Function	V/f	V/f w/ PG	Open Loop Vector	Closer Loop Vector	Page
0	During run 1 (factory default, H2-01)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1	Zero-speed (factory default, H2-02)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
2	2 Frequency agree 1 (factory default, H2-03)		$\checkmark$	$\checkmark$	$\checkmark$	
3	3 Desired frequency agree 1		$\checkmark$	$\checkmark$	$\checkmark$	
4	Frequency detection 1	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	

#### KE200 Inverter

V/f w/PG Open Loop Vector

V/f

Close Loop Vector

H2-01 to		Control Method (A1-02)			Deference	
3 Setting	Function	V/f	V/f w/ PG	Open Loop Vector	Closer Loop Vector	Page
5	Frequency detection 2	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
6	Inverter ready	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
7	DC bus undervoltage	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
8	Baseblock 1	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
9	Option reference	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
Α	Remote operation	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
В	Torque detection 1 (N.O.)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
С	Loss of reference	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
D	DB overheat	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
E	Fault	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
F	Not used	-	-	-	-	
10	Minor fault	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
11	Reset command active	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
12	Timer output	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
13	Frequency agree 2	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
14	Desired frequency agree 2	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
15	Frequency detection 3	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
16	Frequency detection 4	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
17	Torque detection 1 (N.C.)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
18	Torque detection 2 (N.O.)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
19	Torque detection 2 (N.C.)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1A	Reverse direction	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1B	Baseblock 2	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1C	Motor 2 Selection	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1D	Regenerating	-	-	-	$\checkmark$	
1E	Restart enabled	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
1F	Overload (OL1)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
20	OH pre-alarm	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
30	Current/torque limit	-	-	$\checkmark$	$\checkmark$	
31	Speed limit	-	-	-	$\checkmark$	
33	Zero servo completion	-	-	-	$\checkmark$	
37	During run 2	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	

• During Run (setting: "0")

Closes when a run command is input, or when the inverter outputs voltage.

· Zero-speed (setting: "1")

Closes when the inverter output frequency is less than the minimum output frequency (*El-09*) during V/f control with PG feedback. Closes when the motor speed is less than the zero-speed level (B2-01) during close loop vector control

V/f V/f w/PG Open Loop Close Loop Vector

• Frequency Agree 1 (setting: "2")

Closes whenever the output frequency "agrees" with the frequency reference, plus or minus the speed agree detection width (L4-02). This is effective during both forward *and* reverse operation.



Figure 37 Frequency Agree Signal 1 Timing Diagram

• Desired Frequency Agree 1 (setting: "3")

Closes whenever the output frequency "agrees" with the speed agree detection level (L4-01), plus or minus the speed agree detection width (L4-02). This is effective during both forward *and* reverse operation.



Figure 38 Desired Frequency Agree 1 Signal Timing Diagram

• Frequency Detection 1 (setting: "4")

Closes whenever the output frequency is at or below the speed agree detection level (L4-01). During acceleration from below the detection level, the output frequency increases through the detection bandwidth (L4-02) before the contact opens again. This is effective during both forward and reverse operation.





• Frequency Detection 2 (setting: "5")

Closes whenever the output frequency is at or above the speed agree detection level (L4-01). During deceleration from above the detection level, the output frequency decreases through the detection bandwidth (L4-02) before the contact opens again. This is effective during both forward *and* reverse operation.



Figure 40 Frequency Detection 2 Signal Timing Diagram

- Inverter Ready (setting: "6")
   Closes when the inverter is ready for operation (no faults or alarms).
- DC Bus Undervoltage (setting: "7") Closes when the main circuit DC bus voltage or control circuit power supply is drops below the trip level, or when the main circuit magnetic contactor (MC) turns OFF.
- Baseblock 1 N.O. (setting: "8") Closes when the inverter output shuts OFF.
- Frequency Reference Selection (setting: "9")
   Opens when the frequency reference is input from the control circuit terminals or an option.
   Closes when the frequency reference is input from the digital operator.
- Run Command Selection (setting: "A")
   Opens when run command is input from the control circuit terminals or an option.
   Closes when run command is input from the digital operator.
- Overtorque Detection 1 N.O. (setting: "B")
   Closes during overtorque detection 1 (see section *L6*, *Overtorque Detection*, on page 113).

· Loss of Frequency Reference (setting: "C")

Closes when frequency reference is reduced by 90% within 400ms. The inverter will respond according to the setting of reference loss selection (L4-05). After reference loss, if L4-05 = "1", then operation continues at 80% of the previous frequency reference, and the contact closes.



Figure 41 Reference Loss Timing Diagram

- Dynamic Braking Resistor Overheat (setting: "D") Closes during braking resistor overheating or a braking transistor fault.
- Fault (setting: "E") Closes when a fault occurs (except CPF00 and CPF01).
- Alarm (setting: "10") Closes while an alarm is displayed.
- Fault Reset (setting: "11") Closed while fault is being reset.
- Timer Output (setting: "12")
   Closes when timer contact input closes (after On-delay time elapses).
   Opens when timer contact input opens (after Off-delay time elapses).
- Frequency Agree 2 (setting: "13")

Closes whenever the output frequency "agrees" with the frequency reference, plus or minus the speed agree detection width (L4-04). This is used for setting up an alternate detection width.



Figure 42 Frequency Agree Signal 2 Timing Diagram

V/f V/f w/PG Open Loop Vector Close Loop Vector

• Desired Frequency Agree 2 (setting: "14")

Closes whenever the output frequency "agrees" with the speed agree detection level (L4-03), plus or minus the speed agree detection width (L4-04). Choose forward or reverse operation in L4-03.



Figure 43 Desired Frequency Agree 2 Signal Timing Diagram

• Frequency Detection 3 (setting: "15")

Closes whenever the output frequency is at or below the speed agree detection level (L4-03). During acceleration from below the detection level, the output frequency increases through the detection bandwidth (L4-04) before the contact opens again. Choose forward or reverse operation in L4-03.



Figure 44 Frequency Detection 3 Signal Timing Diagram

Frequency Detection 4 (setting: "16")

Closes whenever the output frequency is at or above the speed agree detection level (L4-03). During deceleration from above the detection level, the output frequency decreases through the detection bandwidth (L4-04) before the contact opens again. Choose forward or reverse operation in L4-03.



Figure 45 Frequency Detection 2 Signal Timing Diagram

Close Loon

Vector

Open Loop Vector

V/f

V/f w/PG

- Overtorque Detection 1 N.C. (setting: "17") Closes during overtorque detection 1 (see section *L6*, *Overtorque Detection*, on page 113).
- Overtorque Detection 2 N.O. (setting: "18")
   Closes during overtorque detection 2 (see section *L6*, *Overtorque Detection*, on page 113).
- Overtorque Detection 2 N.C. (setting: "19")
   Opens during overtorque detection 2 (see section *L6*, *Overtorque Detection*, on page 113).
- During Reverse Run (setting: "1A") Closes during a reverse run command.
- Baseblock 2 N.C. (setting: "1B") Opens when the inverter output shuts OFF.
- Motor 2 Selection (setting: "1C") Closed when motor 2 is selected.
  Motor 2 may be selected by using a multi-function digital input.
- Motoring/Regenerating Mode (setting: "1D")
   Closes during regenerative operation (close loop vector control only).
- Automatic Restart (setting: "1E") Closes during automatic restart operation.
- OL1 Pre-alarm (setting: "1F") Closes when the motor-calculated electronic thermal overload value increases to 90% of the internal fault detection level.
- OH Pre-alarm (setting: "20")
   Closes when the heatsink temperature exceeds the overheat temperature level (*L8-02*), or when a multi-function contact input (*H1*-\_\_ = "B") closes.
- Current/Torque Limit (setting: "30") Closes during torque limit.
- Speed Limit (setting: "31") Closes when the speed limit level (*D5-03*) is reached during torque control (close loop vector control).
- Zero-Servo Completion (setting: "33") Closes when zero-servo operation is completed.
- During Run 2 (setting: "37")
   Closes when a run command is input (does *not* close during baseblock, injection braking or initial excitation).

V/f V/f w/PG Open Loop Close Loop Vector

### H3 Analog Inputs

The KE200 series has three analog inputs (two multi-function and one reference), for the external input of numerous references and limits, including frequency, torque, PID, and others. This section includes descriptions of these functions.

H3-01 Terminal 13 Signal Selection

Term 13 Signal

в в в в

Selects the type of voltage signal input at terminal 13.

Setting	Description
0	0 to 10V input (factory default)
1	-10 to +10V input

The resolution of terminal 13 is 11 bit.

H3-02 Terminal 13 Reference % Gain

Setting Range: 0.0 to 1000.0% Factory Default: 100.0%

Sets the terminal 13 input gain level when the reference voltage is 10V.

H3-03 Terminal 13 Reference ±% Bias

Terminal 13 Bias

Terminal 13 Gain

В	В	В	В
-	-	-	-

В

В

в

В

Setting Range: -100.0 to 100.0% Factory Default: 0.0%

Sets the terminal 13 input bias level when the reference voltage is 0V.



Figure 46 Analog Input Gain and Bias Adjustment

H3-04 Terminal 16 Signal Selection

Selects the type of voltage signal input at terminal 16.

Setting Description	
0	0 to 10V input (factory default)
1	-10 to +10V input

Terminal 16 Sel

Terminal 16 Sel

The resolution of terminal 16 is 11 bit.

H3-05 Terminal 16 Multi-function Selection

The following table lists the function selections for the multi-function analog inputs (terminals 14 and 16), and indicates the control modes during which each function can be enabled.

		Control Method (A1-02)				
Setting	Function V/f V/f w/ PG		Open Loop Vector	Close Loop Vector	Setting Level	
0	Aux. Frequency Ref. (factory default)	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	±100% / ±10V
1	Frequency Gain	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	100% / 10V
2	Frequency Bias	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	±100% / ±10V
4	Voltage Bias	$\checkmark$	$\checkmark$	-	-	100% / 10V
5	Accel/Decel Change	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	100% / 1V
6	DC Injection Braking Current	$\checkmark$	$\checkmark$	$\checkmark$	-	100% / 10V
7	Overtorque Level	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	100% / 10V
8	Stall Prevention Level	$\checkmark$	$\checkmark$	-	-	100% / 10V
9	Reference Lower Limit	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	100% / 10V
Α	Jump Frequency	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	100% / 10V
В	PID Feedback	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	±100% / ±10V
С	PID Reference Bias <1110>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	10V/Fmax
D	Frequency Reference Bias 2 <1110>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	10V/Fmax
10	Forward Torque Limit	-	-	$\checkmark$	$\checkmark$	100% / ±10V
11	Reverse Torque Limit	-	-	$\checkmark$	$\checkmark$	100% / ±10V
12	Regenerative Torque Limit	-	-	$\checkmark$	$\checkmark$	100% / ±10V
13	Torque Reference	-	-	-	$\checkmark$	±100% / ±10V
14	Torque Compensation	-	-	-	$\checkmark$	±100% / ±10V
15	Forward/Reverse Torque Limit	-	-	$\checkmark$	$\checkmark$	±100% / 10V
1F	Not Used	-	-	-	-	-

KE200 Inverter

В

В

В

V/f V/f w/PG Open Loop Close Loop Vector

В

В

В

В

1

В

#### KE200 Inverter



Figure 47 Multi-function Analog Input Selection

H3-06 Terminal 16 Reference % Gain Setting Range: 0.0 to 1000.0% Factory Default: 100.0%

Sets the terminal 16 input gain level when the reference voltage is 10V. See Figure 46, on page 95.

H3-07 Terminal 16 Reference ±% Bias

Terminal 16 Bias в

в

В

Terminal 16 Gain

B B B

в

в

Setting Range: -100.0 to 100.0% Factory Default: 0.0%

Sets the terminal 16 input bias level when the reference voltage is 0V. See Figure 46, on page 95.

## KE200 Inverter

					V/f	V/f	w/PG	Open Loop Vector	Close Loop Vector
H3-08	Terminal 14 Sign	al Selection		Term 14 Signal	Γ	Δ	Δ	Δ	Δ
115 00	Selects the type o	f signal input a	at terminal 14.	ierm i r signat	L	~	Π		~
	Г	Setting		Description					
	_	0	0 to 10V input	•					
	_	1	-10 to +10V input						
		2	4 to 20mA (factory	default)					
	The resolution of	terminal 14 is	10 bit.						
	Note: To enable trol printe directly b	e terminal 14 fo ed circuit board ehind terminal	or a voltage signal d. J1 is located on l 13.	(settings: "0" or "1" the bottom left-hand	'), cut d corr	t jump her of	er wir the co	re J1 on t ontrol boa	he con- ard
H3-09	Terminal 14 Mult	i-function Selec	ction	Terminal 14 Sel		А	А	А	A
	Selects the multi- tion for details).	function analo	g input function fo	or terminal 14 (see To	ermir	nal 16	Multi	-function	n Selec-
H3-10	Terminal 14 Refer	rence % Gain		Terminal 14 Gain		A	А	А	A
	Setting Range: Factory Default:	0.0 to 1000.0 100.0%	%						
	Sets the terminal	14 input gain l	evel when the refe	erence current is 20n	nA. S	ee Fig	gure 4	6, on pag	ge 95.
H3-11	Terminal 14 Refer	rence ±% Bias		Terminal 14 Bias		A	А	А	A
	Setting Range: Factory Default:	-100.0 to 100 0.0%	.0%						
	Sets the terminal	14 input bias l	evel when the refe	erence current is 4m	A. Se	e Figu	re 46,	, on page	95.
H3-12	Analog Input Filt	er Time Consta	int	Filter Avg Time	Γ	A	A	A	A

Setting Range: 0.00 to 2.00s Factory Default: 0.00s

Sets up a delay filter time constant at terminals 13, 14 and 16. This filter inserts a delay between the time the command is input to the time it is received by the inverter.

# micno



V/f V/f w/PG Open Loop Close Loop Vector Vector

## H4 Analog Outputs

The KE200 Series has two analog outputs, for the external monitoring of drive conditions such as output frequency, output current, PID feedback and others.

H4-01 Terminal 21 Analog Output Selection

Terminal 21 Sel

B B B B

Selects the analog output monitors for terminal 21.

Setting	Description
1	Frequency reference
2	Output frequency (factory default)
3	Inverter output current
5	Motor speed
6	Output voltage
7	DC bus voltage
8	Output power
9	Torque reference (internal)
15	Terminal 13 input voltage level
16	Terminal 14 input voltage or current level
17	Terminal 16 input voltage level
18	Motor secondary current (Iq)
19	Motor excitation current (Id)
20	SFS output frequency
21	ASR input
22	ASR output
23	Speed deviation
24	PID feedback
26	Voltage reference (Vq output)
27	Voltage reference (Vd output)
32	ACR (q) Output
33	ACR (d) Output
36	PID Input Monitor <1110>
37	PID Output Monitor<1110>
38	PID Setpoint Monitor <1110>

The resolution of terminal 21 is 9 bit plus sign.

H4-02 Terminal 21 Analog Output Gain

Terminal 21 Gain

B B B B

Setting Range: 0.00 to 2.50 Factory Default: 1.00

Sets the terminal 21 output gain for the analog output monitors. To obtain the output level, multiply the monitor output level by the gain value set in *H4-02*.

				V/f		V/f w/PG	Open Loop Vector	Close Loop Vector
H4-03	Terminal 21 Analo	g Output Bias	Terminal 21 Bias		В	В	В	В
	Setting Range:	-10.0 to 10.0%						
	Factory Default:	0.0%						

Sets the terminal 21 output bias for the analog output monitors. To obtain the output level, multiply the monitor output level by the gain value set in H4-02, then add the bias value set in H4-03.



Figure 48 Analog Output Gain and Bias Adjustment

H4-04	Terminal 23 Analog Output Selection	Terminal 23 Sel	В	В	В	В

Selects the analog output monitors for terminal 23 (see Terminal 21 Analog Output Selection). The resolution of terminal 23 is 9 bit plus sign.

H4-05 Terminal 23 Analog Output Gain

Setting Range:0.00 to 2.50Factory Default:1.00

Sets the terminal 23 output gain for the analog output monitors. To obtain the output level, multiply the monitor output level by the gain value set in *H4-05*. See Figure 48.

H4-06	Terminal 23 Analog	g Output Bias	Terminal 23 Bias	В	В	В	В
	Setting Range: Factory Default:	-10.0 to 10.0% 0.0%					

Sets the terminal 23 output bias for the analog output monitors. To obtain the output level, multiply the monitor output level by the gain value set in *H4-05*, then add the bias value set in *H4-06*. See Figure 48.

H4-07 Analog Output Signal Selection

AO Level Select

Terminal 23 Gain

В

В

В

В

B B B B

Selects the type of voltage signal output at terminals 21 and 23.

Setting Description		
0 0 to 10V input (factory default)		
1	-10 to +10V input	

## KE200 Inverter

							RL200	Inventer
					V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
H5	<i>Serial Communi</i> The inverter uses	cation Set-up	o ion port 6CN to c	ommunicate via MOD	BUS p	rotocol.		
H5-01	Serial Communic	cation Station	Address	Serial Comm Adr		A A	А	A
	Setting Range: Factory Default:	0 to 1F 1F						
	Selects a station	address for id	entification of the	e inverter during serial	commu	inication	1.	
H5-02	Serial Communic	cation Baud R	ate	Serial Baud Rate		A A	A	A
	Selects the baud	rate at which	the inverter serial	ly communicates with	externa	al device	<b>'S</b> .	
		Setting		Description		]		
	-	0	1200 Baud per	Second				
		1	2400 Baud per	Second		=		
		2	4800 Baud per	Second		-		
		3	9600 Baud per S	Second (factory default)				
	-	4	19200 Baud <111	0>				
H5-03	Serial Community Selects the transp	<i>cation Parity</i> mission parity	<i>Selection</i> for the 6CN MO	<i>Serial Com Sel</i> DBUS port.		A A	A	A
	ſ	Setting		Description		]		
		0	No parity (factor	y default)		_		
		1	Even parity					
		2	Odd parity					
	-		L.					

#### KE200 Inverter

			V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
H5-04	Stopping Method After Communication Error	Serial Fault Sel	A	A	A	A

Selects the stopping method after a transmission error is detected.

Setting	Setting Description			
0	Ramp to stop according to the time set in C1-02.			
1	Fast-stop according to the time set in C1-09.			
2	Coast to stop			
3	Alarm only, continuous operation (factory default)			

#### H5-05 MODBUS Time Out Detection

Serial Fault Dtct A A A A

H5-05 enables or disables the MODBUS time out detection function. After initial communication begins, if communication is interrupted for longer than 2 seconds, then a communication fault will occur.

During a communication fault, the following fault code will be displayed: "CE Memobus Com Err".

Setting	Description
0	Disabled - Time out detection is disabled.
1	Enabled - Time out detection is enabled.

#### L Protection Parameters

### L1 Motor Overload

The KE200 Series protects against motor overload with a UL-recognized, built-in electronic thermal overload function.

L1-01 Motor Protection Fault Selection (OL1)

MOL Fault Select B B B B

Selects whether motor overload protection is provided.

Setting	Description
0	Motor overload detection is disabled.
1	Motor overload detection is enabled, motor coasts to stop (factory default).

The electronic thermal overload function estimates motor temperature, based on inverter output current and time, to protect the motor from overheating. When the electronic thermal overload relay is activated, an "OL1" error occurs, shutting OFF the inverter output and preventing excessive overheating in the motor. As long as the inverter is powered up, it continues to calculate the motor temperature.

When operating with one inverter connected to one motor, an external thermal relay is not needed.

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

When operating several motors with one inverter, install a thermal relay on each motor. In this case, set parameter L1-01 to "0".

*L1-02 Motor Protection Time Constant* 

MOL Time Const

3	В	В	В

Setting Range:0.1 to 20.0 minutesFactory Default:8.0 minutes

Sets the amount of time that the motor withstands 150% overload, when the motor is operated continuously at rated current. This value should be set according to the overload resistance of motors used.



#### Figure 49 Electronic Thermal Overload Curve

Notes:

- 1. If the motor is running at 100% output current or less, the electronic thermal overload relay will *not* trip. (continued next page)
- 2. If the motor is run continuously at 150% output current, the electronic thermal overload relay will trip after one minute if the motor is started "hot", and after eight minutes if the motor is started "cold".

## L2 Power Loss Ridethrough

When momentary power loss occurs, operation can restart automatically, according to the setting of the following parameters.

L2-01 Momentary Power Loss Ridethrough Selection PwrL

PwrL Selection

в в в

В

Selects whether the inverter stops when power loss is detected or "rides through" a momentary power loss. When ridethrough operation is selected, speed search starts from the current output frequency.

Setting	Description
0	Momentary power loss ridethrough is disabled <i>(factory default)</i> . When momentary power loss is detected, a fault contact trips, stopping the inverter.
1	Momentary power loss ridethrough is enabled, for the time set in <i>L2-02</i> . When momentary power loss is detected, a fault contact does <i>not</i> trip. If power is not restored within the time set in L2-02, a fault contact trips, stopping the inverter.

		V/f	V/f w/PG	Open Loop Vector	Close Lo Vector
Setting	Description			]	
2	Momentary power loss ridethrough is enabled, w logic time, regardless of the time set in <i>L2-02</i> . Th time differs depending on inverter capacity.	ithin the c ne control	ontrol logic		

*L2-02* Momentary Power Loss Ridethrough Time

PwrL RideThru t

В

Setting Range:0.0 to 2.0sFactory Default:Inverter model dependent

Sets the ridethrough time allowed before the inverter trips, after momentary power loss. This setting is activated when L2-01 is set to "1". If power is restored within this time, operation restarts automatically. If power is not restored within this time, a fault contact trips, stopping the inverter.

				V/f	V/f w/PG	Open Loop Vector	Close Loop Vector	
L2-03	Minimum Basebloc	sk Time	PwrL Baseblock t		B B	В	В	
	Setting Range: Factory Default:	0.1 to 5.0s Inverter model dependent		Ι	Ι	I		
	After momentary p current to be drawn block time allows t only effective when	ower loss has occurred, the n by the motor when operatio he inverter to wait for this re h L2-02 is set to "1" or "2".	notor may have residual way nestarts, and can trip the sidual voltage to dissipat	voltag e inve te bef	ge. This o erter. Tho fore resta	can cause e minimu arting. Th	excess m base- is is	
	After momentary p · If the minimum by trol logic time), th · If the minimum b after the power lo	bower loss: aseblock time $(L2-03)$ is greaten aseblock time (L2-03) is greaten aseblock time is less than the ss ridethrough time elapses.	tter than the power loss ri e minimum baseblock tir e power loss ridethrough	idethı ne eli time,	rough tin apses. then op	ne ( <i>L2-02</i> eration re	or con-	
L2-04	Voltage Recovery T	lime	PwrL V/f Ramp t		A A	А	A	
	Setting Range: Factory Default:	0.0 to 5.0s Inverter model dependent						
	When operation rea motor speed. After level (before power	starts after momentary power speed search is complete, th r loss) is defined by the volta	t loss, speed search is act e time for the output volt ge recovery time.	ivate age t	d in orde o increas	er to detection to	et the revious	
L2-05	Undervoltage Dete	ection Level	PUV Det Level		A A	А	А	
	Setting Range:         150 to 210V (230V class), 300 to 420V (460V class)           Factory Default:         190V (230V class), 380V (460V class)							
	Sets the inverter ma When setting this w side. The AC react ple when operating	ain circuit DC bus undervolta value less than the factory det or reduces peak current input at low voltages.	age level. fault, it is necessary to in t to the inverter and smoo	stall a oths c	an AC re out the D	eactor on C bus cu	the input rrent rip-	
L2-06	Kinetic Energy Bra	king Frequency Constant	KEB Frequency		A A	A	A	
	Setting Range:	0 to 100%						

Settin Factory Default: 0%

This parameter allows for setting the load inertia ridethrough level, as a percentage of output frequency. This setting is used in conjunction with multi-function contact inputs set for KEB ridethrough (H1-\_\_\_= "65" or "66"), after momentary power loss. When the KEB frequency constant is set to "0", KEB ridethrough functions as normal, to maintain a controlled deceleration rate for the longest time possible, during a momentary power loss (see section H1, Digital Inputs, on page 76 for more details). When the KEB frequency constant is set to any value other than "0", KEB ridethrough for systems use is enabled.



Figure 50 KEB Ridethrough Timing Diagram

In system applications requiring multiple drives with a common DC bus, KEB ride-through functions differently. The inverter decelerates from the output frequency to the KEB frequency level, according to the momentary power loss ridethough time (L2-02). The KEB frequency constant (L2-06) is set according to the following equation:

KEB Frequency Level = Output Frequency (1 - 
$$\frac{L2-06}{100\%}$$
)

This method is ideal when helper drives are being used on a film line, and a loss of power might cause a line break. This method will allow synchronized deceleration for all of the common-bus drives, to prevent speed deviation and thus a possible line break. If power is restored within the recovery time (L2-02), then the inverter accelerates to the previous frequency reference according to acceleration time 1 (C1-01).

Close Loop

Vector



Figure 51 KEB Ridethrough - Common DC Bus Applications

Note: Enabling KEB ridethrough overrides the momentary power loss ride-through selection (L2-01).

## L3 Stall Prevention/Current Limit

This function automatically adjusts the output frequency, acceleration and/or deceleration rates in order to continue operation without tripping or "stalling" the inverter.

L3-01 Stall Prevention Selection During Acceleration StallP Accel Sel

B B B -	В	В	В	-
---------	---	---	---	---

Enables/disables stall prevention/current limit during acceleration.

Setting	Description
0	Stall prevention/current limit during acceleration is disabled. The inverter increases the output frequency at the set acceleration rate. If the acceleration rate is too fast for the load condition, the inverter may trip on overcurrent (OC) or overload (OL).
1	Stall prevention/current limit during acceleration is enabled ( <i>factory default</i> ). The acceleration rate is automatically reduced according to motor current to prevent stalling during acceleration. The acceleration time may be longer than the set value ( <i>C1-01</i> ).
2	Stall prevention/current limit during acceleration is enabled, with an <i>intelligent</i> acceleration mode. By monitoring motor current, the acceleration rate is automatically adjusted so that acceleration can be completed in the shortest amount of time, regardless of the set acceleration time.

				V/f		V/f w/PG	Open Loop Vector	Close Loop Vector
L3-02	Stall Prevention Le	evel During Acceleration	StallP Accel Lvl		В	В	В	-
	Setting Range: Factory Default:	0 to 200% 150%						

The stall prevention/current limit level during acceleration is set as a percentage of inverter rated current. A setting of 200% disables current limit during acceleration. During acceleration, if the output current exceeds this current limit level (L3-02), acceleration stops and frequency is maintained. When the output current decreases below this current limit level (L3-02), acceleration restarts.



Figure 52 Stall Prevention/Current Limit During Acceleration

L3-03 Stall Prevention Limit (constant output area) StallP CHP Level A A

When a motor is used in the constant output area (constant HP), output frequency max. voltage output frequency (E1-06). In this area, the stall prevention/current limit level during acceleration is automatically reduced for smoother acceleration. This parameter limits the stall prevention/current limit level during acceleration in the constant output area so that it does not decrease unnecessarily. The current limit level during acceleration is changed according to the following equation:



#### **KE200** Inverter

		V/f	V/f w/PG	Open Loop Vector	Close Loop Vector	)
L3-04 Stall Prevention Selection During Deceleration	StallP Decel Sel	E	3 В	В	В	

If deceleration times are set too short for load conditions, the inverter automatically extends the deceleration time according to the main circuit DC bus voltage level. When using an optional braking resistor for the KE200 series, set parameter L3-04 to "0".

Setting	Description
0	Stall prevention during deceleration is disabled. An excessively short deceleration time will generate an overvoltage fault (OV), and the inverter will stop.
1	Stall prevention during deceleration is enabled <i>(factory default)</i> . The DC bus voltage level is monitored, and the deceleration rate is automatically extended to prevent an overvoltage condition. This deceleration rate may be longer than the set value <i>(C1-02)</i> .
2	Stall prevention during deceleration is enabled, with an <i>intelligent</i> deceleration mode. By monitoring DC bus voltage, the deceleration rate is automatically adjusted so that deceleration can be completed in the shortest amount of time, regardless of the set deceleration time.
3	Overvoltage (OV) countermeasure during deceleration (with braking resistor installed). Improves stall prevention during deceleration. Overvoltage (OV) sometimes occurs even under settings 1 or 2 above. The rising of the DC bus voltage is limited during fast deceleration of the motor. This feature allows a faster than normal decel time. Note: When in vector mode setting 3 cannot be used with braking resistor and with stall prevention.



Figure 53 Stall Prevention During Deceleration

Note: Intelligent stall prevention during deceleration (L3-04 = "2") cannot be set in the vector control modes (when A1-02 = "2" or "3").

V/f V/f w/PG Open Loop Vector Vector

В

L3-05 Stall Prevention Selection During Running

StallP Run Sel

в - -

Sets a function to prevent stalling during an overload condition while running at constant speed.

Setting	Description
0	Stall prevention/current limit during running is disabled. An excessively short deceler- ation time will generate an overvoltage fault (OV), and the inverter will stop.
1	Stall prevention/current limit during running is enabled (factory default). When the inverter output current exceeds the current limit level ( $L3-06$ ) for more than 100ms during speed agree, the output frequency is decreased according to deceleration time 1 ( $C1-02$ ), and this can prevent stalling. When the load condition is stabilized, the inverter accelerates to the previous frequency.
2	Stall prevention/current limit during running is enabled as in setting "1", however the output frequency is decreased according to deceleration time 2 ( <i>C1-04</i> ).

L3-06 Stall Prevention Level During Running

StallP Run Lvl



Setting Range:30 to 200%Factory Default:160%

The stall prevention/current limit level during running is set as a percentage of inverter rated current. A setting of 200% disables current limit during running. During speed agree, if the output current exceeds this current limit level during running, then deceleration starts.

When the output current exceeds this current limit level (L3-06), deceleration continues. When the output current decreases below this current limit level (L3-06), acceleration starts, up to the set frequency.



Figure 54 Stall Prevention/Current Limit During Running

V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
-----	----------	---------------------	----------------------

В

В

В

В

В

В

В

В

#### L4 Reference Detection

The KE200 series utilizes three different functions for detecting output frequency:

- When frequency agree is enabled at the multi-function contact outputs ( $H2-\_="2"$  or "13"), the contact closes whenever the output frequency "agrees" with the frequency reference, plus or minus the speed agree detection width.
- When desired frequency agree is enabled at the multi-function contact outputs ( $H2-\_="3"$  or "14"), the contact closes whenever the output frequency "agrees" with the speed agree detection level, plus or minus the speed agree detection width.
- When frequency detection is enabled at the multi-function contact outputs ( $H2-\_="4", "5", "15"$  or "16"), the contact closes whenever the output frequency is less than or more than the speed agree detection level, depending on which detection is selected.

Refer to section *H2*, *Digital Outputs* on page 88, for more detailed information on setting these functions.

L4-01 Speed Agree Detection Level (without sign)

Setting Range: 0.0 to 400.0Hz Factory Default: 0.0Hz

Sets the detection level for the desired frequency agree 1 and frequency detection 1 and 2 functions. The set detection level is effective during both FWD and REV operation.

L4-02 Speed Agree Detection Width

Setting Range: 0.0 to 20.0Hz Factory Default: 2.0Hz

Sets the detection width for frequency and desired frequency agree 1 and frequency detection 1 and 2 functions.

L4-03 Speed Agree Detection Level (with sign)

Spd Agree Lvl+-

Spd Agree Level

Spd Agree Width



Setting Range: 0.0 to ±400.0Hz Factory Default: 0.0Hz

Sets the detection level for the desired frequency agree 2 and frequency detection 3 and 4 functions. The set detection level is effective during either FWD or REV operation, depending on the set detection level (positive value for FWD operation, negative value for REV operation).

L4-04 Speed Agree Detection Width

Spd Agree Width+-

А	А	А	А

Setting Range:0.0 to 20.0HzFactory Default:2.0Hz

Sets the detection width for frequency and desired frequency agree 2 and frequency detection 3 and 4 functions.

			V/f	V/f w/PG	Open Loop Vector	Close Loo Vector	р
L4-05	Operation When Frequency Reference Loss	Ref Loss Sel	A	A	А	A	

Selects operation when the frequency reference from the control circuit terminal is reduced by 90% within 400ms.

Setting	Description
0	Stop (factory default).
1	Run at 80% of the previous frequency reference.

#### L5 Automatic Restart

After a fault occurs, the inverter and its fault detection circuit can be reset. The automatic restart function allows the inverter to continue operation after certain faults.

L5-01 Number of Automatic Restart Attempts

Num of Restarts

B B B B

Setting Range:0 to 10Factory Default:0

Sets the number of automatic restart attempts. Setting to "0" disables this function.

#### Automatic Restart Operation

- When a fault is detected, the inverter output shuts OFF for the minimum baseblock time (L2-03). The digital operator displays the fault while the inverter output is shut OFF.
- While the minimum baseblock time elapses, the fault is reset automatically and speed search starts from the previous output frequency before the fault occurred.
- When the total number of faults exceeds the number of automatic restart attempts, the faults are *not* reset automatically and the inverter output remains OFF. At this time, a fault contact output is activated.

The inverter can be set to automatically restart after the following faults occur:

- · Overcurrent (OC)
- · Overvoltage (OV)
- · Undervoltage PUV (UV1)
- $\cdot$  Ground fault (GF)
- · Regenerative transistor fault (rr)

However, automatic restart is not available for the following faults:

- · Control circuit undervoltage (UV2)
- MC answer-back fault (UV3)
- · Load short-circuit (SC)
- Heatsink overheat (OH)
- · Run command fault (EF)
- $\cdot$  Overspeed (OS)

- Excessive speed deviation (DEV)
- PG disconnection (PGO)
- · Parameter setting error (OPR)
- · Communication error (CE)
- External fault (EF3 to EF8)

The number of restart attempts is reset to 0 when:

- · A fault does not occur for more than 10 minutes after restart.
- · A fault reset command is input from the control circuit terminal or the digital operator.
- · Power is cycled.

### KE200 Inverter

					V/f	V/f	w/PG	Open Loop Vector	Close Loop Vector
L5-02	Automatic R	estart Oper	ation Selection	Restart Sel		В	В	В	В
Selects whether a fault contact output is activated during automatic restart.									
		Setting		Description					
		0	No fault relay (factor	y default)					
		1	Fault relay active						

#### L6 Torque Detection

The overtorque detection circuit activates when the motor load causes the motor current (or torque during vector control) to exceed the overtorque detection level (L6-02). When an overtorque condition is detected, alarm signals are sent to multi-function output terminals 9, 25 and 26.

To output an overtorque detection signal, select torque detection 1 at either of the multi-function contact outputs (H2-\_\_= "B" or "17"). Refer to section H2, *Digital Outputs* on page 88, for more details.



Release width (hysteresis) during overtorque detection is 5% of the inverter rated current level.

Figure 55 Overtorque Characteristics Timing Diagram

				V/f	V/f w/PG	Open Loop Vector	Clos Ve	e Loop ctor
L6-01	Overtorque	e Detection 1 Selection	Torg Det 1 Sel		В	В	В	В
	Activates of	vertorque detection, and selects	s whether detection gener	ates an	alarm or a	a fault.		
	Setting		Description					
	0	Overtorque detection is disabled	(factory default).					
	1	Overtorque detection is enabled accelerating or decelerating). Con	whenever at the speed agre	e level ( n (OL3 a	when inver alarm).	ter is not		
	2	Overtorque detection is enabled a	always. Continue running af	ter detec	ction (OL3 a	alarm).		
	3	Overtorque detection is enabled v detection (OL3 fault).	whenever at the speed agree	e level. (	Coast to a s	top after		
	4	Overtorque detection is enabled	always. Coast to a stop afte	r detecti	on (OL3 fau	ult).		
	L6-01 Note 1. To dete	es: ect torque during acceleration of	r deceleration, set to "2"	or "4". '2" Du	ring datage	tion the d	igital	

- 2. To continue operation after overtorque detection, set to "1" or "2". During detection, the digital operator displays an "OL3" alarm (blinking).
- 3. To stop the inverter after an overtorque detection fault, set to "3" or "4". During detection, the digital operator displays an "OL3" fault.
Close Loop

Vector

Open Loop

Vector

V/f w/PG

V/f

<i>L6-02</i>	Overtorque Detection 1 Level		Torq Det 1 Lvl	В	В	В	В	
	Setting Range:0 to 300%Factory Default:150%							
	Sets the overtorque detection level as a percentage of inverter rated current, during V/f control, and motor rated torque, during vector control.							
L6-03	Overtorque Detection 1 Time		Torq Det 1 Time	В	В	В	В	
	Setting Range: Factory Default:	0.0 to 10.0s 0.1s						
	The overtorque detection delay time inserts a delay, between the time motor current (or torque) exceeds the overtorque detection level ( $L6-02$ ) and when the overtorque detection function is enable The digital operator then displays "OL3".							

Activates overtorque detection 2, and selects whether detection generates an alarm or a fault.

Setting	Description
0	Overtorque detection is disabled (factory default).
1	Overtorque detection is enabled whenever at the speed agree level (when inverter is not accelerating or decelerating). Continue running after detection (OL4 alarm).
2	Overtorque detection is enabled always. Continue running after detection (OL4 alarm).
3	Overtorque detection is enabled whenever at the speed agree level. Coast to a stop after detection (OL4 fault).
4	Overtorque detection is enabled always. Coast to a stop after detection (OL4 fault).

Overtorque detection 2 functions the same as overtorque detection 1 (L6-01), except that "OL4" is displayed on the digital operator instead. This function is used when two types of detection are output to the multi-function output terminals.

L6-05 Overtorque Detection 2 Level

*L6-04 Overtorque Detection 2 Selection* 

Torg Det 2 Lvl

A A A

Setting Range: 0 to 300% Factory Default: 150%

Sets the second overtorque detection level as a percentage of inverter rated current, during V/f control, and motor rated torque, during vector control.

Torg Det 2 Sel

A A A

А

А

				V/f	V/f w/PG	Open Loop Vector	Close Vec	Loop tor
<i>L6-06</i>	Overtorque Detect	ion 2 Time	Torq Det 2 Time		А	А	A	A
	Setting Range: Factory Default:	0.0 to 10.0s 0.1s						
	The overtorque det exceeds the overtor enabled. The digita	rection 2 delay time inserts a c rque detection level ( <i>L6-05</i> ) a al operator then displays "OL?	delay, between the tin nd when the second c 3".	ne motor overtorqu	current ue detec	tion func	ue) xtion i	.S
L7	<i>Torque Limit</i> The torque limit fu operation:	nction limits the amount of m	notor torque in all fou	r quadra	nts of v	ector con	trol	
	· Forv · Rev	ward Motoring erse Motoring	<ul> <li>Forward Rege</li> <li>Reverse Rege</li> </ul>	enerating nerating	5			
	Torque limit is act	ivated in both the speed and to	orque control modes.					
L7-01	Forward Torque Limit		Torq Limit Fwd		-	-	В	В
27 01	Setting Range: Factory Default:	0 to 300% 200%						
	Sets the motoring s	side torque limit value during	FWD run.					
L7-02	Reverse Torque Lin	mit	Torq Limit Rev		-	-	В	В
	Setting Range: Factory Default:	0 to 300% 200%						
	Sets the motoring s	side torque limit value during	REV run.					
L7-03	Regenerative Forv	vard Torque Limit	Torq Lmt Fwd Rgi	n	-	-	В	В
	Setting Range: Factory Default:	0 to 300% 200%						
	Sets the regeneration	ng side torque limit value dur	ing FWD run.					
L7-04	Regenerative Reve	erse Torque Limit	Torq Lmt Rev Rgn		-	-	В	В
	Setting Range: Factory Default: Sets the regeneration	0 to 300% 200% ng side torque limit value dur	ing REV run.					



Figure 56 Torque Limit - 4 Quadrant Operation

## L8 Hardware Protection

The KE200 series comes equipped with a number of built-in functions designed to protect the inverter and its components from damage. This section describes the set-up of these functions.

L8-01 Protection Selection for Internal DB Resistor D

DB Resistor Prot

B B B B

When a Anyhertz dynamic braking resistor is used, protection against overheat is enabled with this function. The duty cycle of the braking resistor is monitored in software so that it does not exceed 3%.

Setting	Description
0 DB resistor overheat protection is not provided (factory defail	
1	DB resistor overheat protection is provided.

If the duty cycle exceeds 3%, a DB overheat fault (RH) occurs, and the inverter coasts to stop.

### L8-02 OH Pre-Alarm Level

*OH Pre-Alarm Lvl* A

A A A

Setting Range:0 to 100 CFactory Default:100 C

Sets the heatsink temperature level for protection against overheat (OH).

## micno

## KE200 Inverter



## A A A A

L8-03 Stopping Method Selection After OH Pre-Alarm OH Pre-Alarm Sel Selects the stopping method when heatsink overheat is detected.

Setting	Description
0 Ramp to stop according to C1-02 setting.	
1	Coast to stop
2	Ramp to stop according to C1-09 setting (fast-stop).
3	Operation continues, alarm only (factory default).

### L8-05 Input Phase Loss Protection

Ph Loss In Sel

A A A A

The input phase loss detection circuit monitors the DC bus current ripple and activates when the one of the input phases are lost. The detection circuit calculates the maximum and minimum values of the DC bus voltage in one second intervals, and compares the difference (V) between these values with an internal detection level. If V reaches or exceeds the detection level, then after 0.5 second, input phase loss is detected; a PF fault occurs, and the motor coasts to stop.

Setting	Description
0	Input phase loss protection is disabled (factory default).
1	Input phase loss protection is enabled.

Input phase loss detection is disabled in the following cases:

- · A Stop command is input.
- · Magnetic Contactor (MC) shuts OFF.
- · CPU A/D converter fault (CPF5).
- · During deceleration.
- Output current 30% of Inverter rated current.

### **KE200** Inverter

			V/f	V/f w/PG	Open Loop Vector	Close Loop Vector
<i>L8-07</i>	Output Phase Loss ProtectionP	h Loss Out Sel	А	А	А	А

The output phase loss detection circuit monitors the DCCT and activates when one of the output phases are lost. The detection circuit calculates the RMS current value (I<sub>RMS</sub>) for each of the phases and compares it with an internal output detection level. If I<sub>RMS</sub> decreases to or below the detection level for 10 seconds, an output phase loss (LF) fault occurs, and the motor coasts to stop.

Setting	Description
0	Output phase loss protection is disabled (factory default).
1	Output phase loss protection is enabled.

### L8-10 Ground Fault Protection

Ground Fault Sel

А А А А

The ground fault detection circuit monitors the output current and activates when one of the output phases is connected to ground.

A ground fault will occur when the inverter output grounding current has exceeded 50% of the inverter rated current.

When a ground fault condition occurs, the following fault code will be displayed: "GF Ground Fault".

Setting Description			
0 Disabled - Ground fault protection is disabled			
1 Enabled - Ground fault protection is enabled. (factory de			

## KE200 Inverter

V/f V/f w/PG Open Loop Close Loop Vector

А

А

## L8-17 IGBT Protection at Low Speed

Prtct@L-Spd

A A -

This parameter assists in protecting the IGBT from overheating of the transistor junction when the output current is high and the output frequency is low. The settings are as follows:

Setting	Description
0	Conventional Method (No change in carrier), inverter relies on L8-19 protection (same as 1042 software).
1	Lower fc - When output current is greater than 100%, and output frequency is less than or equal to 10Hz, the carrier frequency is automatically decreased to the L8-18 setting (between 8 and 2 kHz depending on model). The carrier will automatically return to the normal value after the load is reduced. (factory default)
2	Short term OL2 - OL occurs in 2 seconds when at low output frequencies (6Hz or less) and in hard current limit.
3	I-Limit=150% - Current limit is 150% of inverter rated current. The IGBT junction temperature should be below any critical level provided the output current is less than 150%. <1110>

L8-19 OL2 Characteristics at Low speed <1110>

OL2 Chara@L-Spd

A A A

This parameter allows the selection of normal or fast OL2 protection below 6 or 10 Hz. It is recommended that this parameter be enabled at all times. In some instances fast OL2 protection (L8-19=1) may not be desired, such as when operating in close loop vector at zero speed. If L8-19 is set to 0 (disabled) L8-17 must be set to 1,2, or 3.

Setting	Description
0	Disabled -OL2 protection is disabled at low speed. This OL2 protection is the same at high speed and low speed. <i>(factory default)</i> .
1	Enabled - A current limiting function is performed at low speed, the inverter OL2 protection responds quickly at 6 Hz or less.

*Caution*: When disabling OL2 protection, (L8-19=0) verify that the motor current will not go beyond the current limit level when operating below 10 Hz. Or set the carrier frequency equal to or less than 2 kHz.

		0	01
V/f	V/f w/PG	Vector	Vector

В

## **O** Operator Parameters

## 01 Monitor Selection

*O1-01* Monitor Selection

User Monitor Sel

B B B

The top level in the operation menu allows the viewing of four monitor variables. These are  $F_{ref}$ ,  $F_{out}$ ,  $I_{out}$ , and a user-selected monitor. This function can replace the output voltage monitor with another monitor in the operation mode. Choose one of the monitors *U1-04* to *U1-39* in this parameter.

Setting	Description
4	Control method
5	Motor speed
6	Output voltage (factory default)
7	DC bus voltage
8	Output power
9	Torque reference (internal)
10	Input terminal status
11	Output terminal status
12	Internal control status 1
13	Elapsed time
14	FLASH ID number
15	Terminal 13 input voltage level
16	Terminal 14 input voltage or current level
17	Terminal 16 input voltage level
18	Motor secondary current (Iq)
19	Motor excitation current (Id)
20	SFS output frequency
21	ASR input
22	ASR output
23	Speed deviation
24	PID feedback
25	DI-16H reference
26	Voltage reference (Vq output)
27	Voltage reference (Vd output)
28	CPU ID number
32	ACR (q) Output
33	ACR (d) Output
34	OPE Detected
35	Zero Servo Pulse
36	PID Deviation
37	PID Output Monitor
38	PID Setpoint

									V/f	V/f w/PG	Open Loop Vector	Close Vec	e Loop Stor
01-02	М	onitor Selection Aft	er Powei	r-up		Pa	wer-On	Monitor	r	В	В	В	В
	Se O	elects the monitor to N.	be displa	ayed or	n the digi	tal opera	ator imme	ediately	after th	ne power	supply	is turn	ied
		Settir	ng			Des	cription						
		1	D	isplays	frequency	referenc	e (factory	default)					
		2	D	isplays	output fre	quency.							
		3	D	isplays	output cu	rrent.							
		4	D	isplays	the monitor	or set in	01-01.						
	U	nits for parameters a	and moni	itors rel	lated to f	requenc	y can be	scaled a	as show	n below	<i>.</i>		
		Setting				D	escription						
		00000	Unit: 0.0	)1Hz <i>(fa</i>	ctory defa	ult)							
		00001	Unit: 0.0	)1%									
		00002 to 00039	Unit: rpr	n (0 to 3	3999)								
		00040 to 03999	Digits:	<u>5th</u>	<u>4th</u>	<u>3rd</u>	<u>2nd</u>	<u>1st</u>					
		(user-selected units)		0	0	0	0	0					
			The 1st	thru 4th	digits det	ermine th	ne set valu	ie at 100	)% outpi	ut frequer	ncy.		
	Decimal point positi 5th digit = 0: disp 5th digit = 1: disp 5th digit = 2: disp 5th digit = 3: disp				osition is s displayed displayed displayed displayed	set by the 1 as 0000 1 as 000. 1 as 00.0 1 as 0.00	e 5th digit ) 0 0 0	as follov	vs:				

If 100% output frequency is equal to 200.0 units:

of this reference is displayed as 120.0.

If 100% output frequency is equal to 65.00:

Set O1-03 = "12000"; 100% of this reference is displayed as 200.0 and 60%

Set O1-O3 = "26500"; 60% of this reference is displayed as 39.00.

Example 1

Example 2

							V/f	V/f w/P0	G Open Loop Vector	Close Loop Vector
									l	L
01	<b>•</b> •		<b>T</b> T •• C	с 1						
01-0	04	Display	Units fo	or Speed	-Related Parameters	Display Units		-		В
		Sets the mode.	display	units for	parameters and monito	ors related to frequency	y, in the o	close lo	pop vector	control
				Setting		Description				
				0	Displays frequency i	n Hz (factory default).				
				1	Displays frequency	n rpm.				
01-0	05	Parame	ter Seleo	ction		Address Display		A	A A	А
		Selects I	how the	paramet	er addresses are displa	yed on the digital operation	ator.			
				1						
				Setting		Description				
				0	Displays parameter	number (factory default).				
				1	Displays MODBUS	address.				
02-0	01	Local/R Enables	<i>ections</i> <i>emote K</i> disable	<i>Tey</i> is the dig	ital operator LOCAL/F	<i>Local/Remote Key</i> REMOTE key.	,	В	ВВ	В
			Sat	tina		Description				
			00	n n	Local/Remote key is disa	ibled			_	
				。 1	Local/Remote key is ena	bled (factory default).				
				-	Depressing the Local/Re	mote key switches opera	tion com	mands		
					between the digital operation	tor and the settings of B	1-01 and	B1-02.		
02-0	02	STOP K	ey Duri	ng Exter	nal Terminal Operation	n Oper STOP Key		В	B B	В
		Enables ing seria	/disable al comm	s the dig unicatio	ital operator STOP key n.	, during operation from	n the ext	ternal t	erminals a	nd dur-
		Setting				Description				
		0		The digit ital operation	al operator STOP key is o ator.	lisabled when Run comm	and does	s not co	me from the	e dig-
		1		The digit	al operator STOP key is a	always enabled <i>(factory d</i> ring external terminal ope	<i>lefault)</i> . eration an	d serial	communica	ation.
						<u> </u>				

## KE200 Inverter

					V/f	V/f w/PG	Open Loop Vector	Close Vec	Loop tor
02-03	User-Deft	ined Default V	alue Setting	User Defaults		В	В	В	В
	Parameter	rs set by user	can be stored in th	e inverter as user default valu	ues.				
	Γ	Setting		Description			1		
		0	No change (factor)	y default)					
		1	Sets user-specified Each parameter's the values are cha can be restored by 50 changed values	d values as defaults. set values are stored as user de inged after this parameter is set, v setting <i>A1-03</i> = "1110" (user init s can be stored	efaults. E user de ialization	Even if faults ). Up to			
		2	Clears user defaul	ts			_		
02-04	Inverter N	Aodel Selectio	n	Inverter Model #		А	A	A	A
	Setting Ra Factory D Sets the in inverter c need char	ange: 23 Default: Inv nverter capaci apacity are se aging, unless t	P7 to 2075, 43P7 to verter model deper ity, according to m t automatically (i.e he control board is	to 4300 ndent nodel number. Control param e. carrier frequency, motor da s replaced.	eters wi nta, etc.)	ith defau ). This p	ilts speci arameter	fic to does	the <i>not</i>
<i>O2-05</i>	Digital O	perator M.O.	P. Mode Selection	Operator M.O.P.		А	A	А	А
	Selects w The digita	hether the EN al operator car	TER key is used v n simulate a motor	when the frequency reference operated potentiometer (M.C	is set b O.P.) by	y the dig setting	gital ope this para	rator. meter	-
	Setting			Description					
	0	the fre-							
	1	The digital or reference con ENTER key	operator M.O.P. mod ommand as soon as being depressed.	le is enabled. The inverter accept changes are made with the arro	ots the fro w keys,	equency without th	ne		

02-06	Digital Operator Disconnection Detection	Oper Detection	A	A	A	A	
	If the digital operator is disconnected from the inve	rter, this parameter	selects	whether	the inve	erter	

Setting Description 0 Detection is disabled. Operation continues (factory default) 1 Detection is enabled. When the inverter detects that the digital operator has been disconnected while running, the inverter coasts to stop and the error message "OPR Operator Disconnected" is displayed on the digital operator, after it is connected again.

This function can only be activated when the run command comes from the digital operator.

#### **O2-07** Operation Time Setting

detects this condition

Setting Range: 0 to 65535 Hours Factory Default: 0 Hours

Sets the initial value for the cumulative operation time. Operation time starts accumulating from the set value. This is very useful for preventive maintenance purposes.

#### *O2-08* Cumulative Operation Time Selection

Defines the operation time that accumulates in the timer.

Setting	Description
0	Power-On time is the accumulated time (factory default).
	The timer counts the time while the inverter power supply is turned ON as operation time.
1	Running time is the accumulated time. The timer counts the time while the inverter is running
	as operation time.

#### **O2-09** Initialization Mode Selection

Sets factory defaults to worldwide specifications.

Setting	Description
0	Japanese specifications
1	American specifications (factory default)
2	European specifications

After changing this setting, reinitialize the inverter in parameter A1-03. This initialization affects market-driven parameter settings (motor-related parameters, carrier frequency, inverter rated current, etc.)

Init Mode Sel

*Elapsed Time Set* 

Elapsed Time Run Α А Α А

А

А

А

А

А

А

# Chapter 7 Parameter List

								Change	Pa	rameter A	ccess Le	vel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		A1-00	Language Selection (Select Language)	0.1	0	0	0: English	0	Q	Q	Q	Q	
ialize	ion	A1-01	Access Level (Access Level)	0~4	1	2	0: Operation Only 1: User Level (Note 5) 2: Quick-Start [Q] 3: Basic Level [B] 4: Advanced Level [A]	0	Q	Q	Q	Q	
	Initializati	A1-02	Control Method Selection (Control method)	0~3	1	0 (Note1)	0: V/F Control 1: V/F w/PG Fdbk 2: Open Loop Vector 3: Close Loop Vector	x	Q	Q	Q	Q	
Ц		A1-03	Initialize (Init Parameters)	0 1110 2220 3330	N/A	0	0 : No Initialize 1110: User Initialize (Note 7) 2220: 2-Wire Initialize 3330: 3-Wire Initialize	x	Q	Q	Q	Q	
		A1-04	Password 1 * (Enter Password)	0000~ 9999	1	0000	Password protection for: A1-01 Access Level A1-02 Control Method A1-03 Initialization A2-01 to A2-32 User Parame- ters (If selected)	x	Q	Q	Q	Q	
	User Parameters	A2-01 ~ A2- 32	User Setting Parameters (Function A2)	_	_	_	User Parameter 1 to User Parameter 32	x	A	A	A	A	
No No No	te 1 te 2 te 5 te 7	Not ini Setting Selecti Setting	tialized. (Domestic st g range is only 0 and 2 ion "1: User Level" is g 1110: User Initialize	andard sp 1 when the only availa is only ava	ecificatior e control n able after s ailable afte	ns: A1-01 nethod is selecting s er setting	= 1, A1-02 = 2) set to close loop vector control (A setting 4: Advanced Level and th Parameter No. O2-03 to 1.	1-02 = 3) nen entering a	a user pa	arameter	n A2-01.		

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		B1-01	Reference Selec- tion (Reference Source)	0~4	1	1	0: (Operator) 1: (Terminals) 2: Communication (Serial Com) 3: (Option PCB) 4: (EWS) Reference from CP- 717 <1110>(Note 8)	x	Q	Q	Q	Q	
		B1-02	Operation Method Selection (Run Source)	0~4	1	1	0: (Operator) 1: (Terminals) 2: Communication(Serial Com) 3: (Option PCB) 4: (EWS) Run from CP-717 <1110> (Note 8)	x	Q	Q	Q	Q	
plication	Sequence	B1-03	Stopping Method Selection (Stopping Method)	0 ~ 3 (Note 2)	1	0	0: (Ramp to Stop) 1: (Coast to Stop) 2: DC injection to stop (DCInj to Stop) 3: Coast to stop with timer (Coast w/Timer)	x	Q	Q	Q	Q	
roup B Ap	nction b1 S	B1-04	Reverse Operation Prohibit (Reverse Oper)	0, 1	1	0	0: (Reverse Enabled) 1: (Reverse Disabled)	х	В	В	В	В	
0	Fu	B1-05	Operation Selec- tion for Setting of E1-09 or less (Zero-Speed Oper)	0~3	1	0	<ol> <li>Run at frequency reference (Run at Freq Ref)</li> <li>(STOP)</li> <li>Run at minimum frequency (RUN at Min Freq)</li> <li>(RUN at Zero RPM)</li> </ol>	x	-	-	-	A	
		B1-06	Digital Input Scan Time (Cntl Input Scans)	0, 1	1	1	0: (2 mS - 2 Scans) 1: (5 mS - 2 Scans)	x	A	A	A	A	
		B1-07	Operation selection after switching to remote mode (LOC/REM RUN Sel)	0, 1	1	0	<ol> <li>Cycle external run (Cycle Extern RUN)</li> <li>Accept external run (Accept Extern RUN)</li> </ol>	x	A	A	A	A	
		<b>B1-08</b> <1110>	Run command acceptance while being programmed (RUN CMD at PRG)	0, 1	1	0	0: Disabled 1: Enabled	x	A	A	A	A	
Not Not	e 2 ie 8	Setting rai (Tentative)	nge is only 0 and 1 wh ) Setting parameter B	nen the co 1-01 or B1	ntrol meth -02 to 4 a	iod is set Illows refe	to close loop vector control (A1-0 erence and/or run source from C	2 = 3) P-717 when	either CF	-916 or C	CP-216 op	tion card	s are

Note 9 Drive can be switched between local and remote mode while continuing to run. When switching from remote to local the last remote speed command will be set as the local speed for a bumpless transition.

			Name (Digital					Change	Parameter Access Level				
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		B2-01	DC Injection Braking Starting Frequency (DCInj Start Freq)	0.0~ 10.0	0.1Hz	0.5	_	x	В	В	В	В	
Group b Application	n Brake	B2-02	DC Injection Current (DCInj Current)	0~100	1%	50	_	x	В	В	В	-	
	2 DC Injectio	B2-03	DC Injection Time at Start (DCInj Time @Start)	0.00~ 10.00	0.01s	0.00	_	X	В	В	В	В	
	Function b	B2-04	DC Injection Braking Time at Stop (DCInj Time @Stop)	0.00~ 10.00	0.01s	0.50 *	* When 02-09 = 1 (American), the setting is 0.00s. <24>	X	В	В	В	В	
		<b>B2-08</b> <1110>	Magnetic Flux Com- pensation Capacity (FieldComp)	0~500	1%	0	100% is no-load current value at Min. frequency (E1-09)	х	-	-	A	A	
	rch	B3-01	Speed Search Selection at Start (SpdSrch at Start)	0,1	1	0*	0: Disabled 1: Enabled * Factory setting defaults to 0: Disabled except when (A1- 02=1) (V/F w/PG Fdbk) or 3 (Close loop vector).	x	A	A	A	A	
	Speed Sea	B3-02	Speed Search Operation Current (SpdSrch Current)	0~200	1%	150*	* Factory setting defaults to 150 when A1-02=0 (V/F Control). When A1-02=2 (Open Loop Vector), the default is 100.	x	A	-	A	-	
		B3-03	Speed Search Deceleration Time (SpdSrch Dec Time)	0.1~ 10.0	0.1s	2.0	_	X	A	-	A	-	
	Timers Sequence	B4-01	Timer Function On-delay Time (Delay-ON Timer)	0.0~ 300.0	0.1s	0.0	_	х	A	A	A	A	
	Delay Brake S	B4-02	Timer Function Off-delay Time (Delay-OFF Timer)	0.0~ 300.0	0.1s	0.0	_	х	A	A	А	Α	

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		B5-01	PID Control Mode Selection (PID Mode)	0~4	1	0	<ol> <li>(Disabled)</li> <li>(Enabled D=Fdbk)</li> <li>Enabled D = Feed-For- ward (Enabled D=Fdfwd)</li> <li>Reference = Frequency Reference + PID Output (Fref+PID D=Fdbk)</li> <li>Reference = Frequency Reference + PID Output D is feed-forward (Fref+PID D=Fdfwd)</li> </ol>	X	A	A	A	A	
ation		B5-02	Proportional Gain (P) (PID Gain)	0.00~ 25.00	0.01	1.00	_	0	A	A	A	A	
		B5-03	Integral (I) Time (PID I Time)	0.0~ 360.0	0.1s	1.0	_	0	А	Α	А	А	
		B5-04	Integral (I) Limit (PID I Limit)	0.0~ 100.0	0.1%	100	_	0	А	А	А	А	
	Control	B5-05	Derivative (D) Time (PID D Time)	0.00~ 10.00	0.01s	0.00	_	0	А	A	A	A	
Applic	5 PID	B5-06	PID Limit (PID Limit)	0.00~ 100.0	0.1%	100.0	_	0	А	А	А	А	
Group b	Function t	B5-07	PID Offset Adjustment (PID Offset)	-100.0~ +100.0	0.1%	0.0	_	0	A	A	A	A	
		B5-08	PID Primary Delay Time (PID Delay Time)	0.00~ 10.00	0.01s	0.00	_	0	A	A	A	A	
		<b>B5-09</b> <1110>	PID Output Selection (Output Level Sel)	0, 1	1	0	<ol> <li>PID Forward Output [X 1] (Normal Character)</li> <li>PID Reverse Output [X–1] (Rev Character)</li> </ol>	x	A	A	A	A	
		<b>B5-10</b> <1110>	PID Output Gain (Output Gain)	0.0 ~ 25.0	.1	1.0	-	х	А	Α	А	А	
		<b>B5-11</b> <1110>	PID Output Reverse Selection (Output Rev Sel)	0, 1	1	0	<ol> <li>When PID output is negative, motor direction is not changed, PID output is limited to 0. (0 limit)</li> <li>When PID output is negative, motor reverses direction. (Reverse)</li> </ol>	X	A	A	A	A	

								Change	Par	rameter A	Access Le	vel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	PID Control	<b>B5-12</b> <1110>	PID Feedback Ref- erence Missing Detection Selection (Fb Los Det Sel)	0~2	1	0	<ol> <li>PID feedback missing detection disabled. (Dis- abled)</li> <li>PID feedback missing detection enabled. (Alarm) Operation continues after detection, "Fbl" alarm is dis- played.</li> <li>PID feedback missing detection enabled. (Fault) Inverter output is shut off after detection, "Fbl" is dis- played.</li> </ol>	x	A	A	A	A	
		<b>B5-13</b> <1110>	PID Feedback Ref- erence Missing Detection Level (Fb los Det Lvl)	0~100	1%	0	_	x	A	A	A	A	
Application		<b>B5-14</b> <1110>	PID Feedback Ref- erence Missing Detection Time (Fb los Det Time)	0.0~ 25.5	0.1s	1.0	_	x	A	A	A	A	
Group b.	łold	B6-01	Dwell Frequency at Start (Dwell Ref @Start)	0.0~ 400.0	0.1Hz	0.0	_	x	A	A	A	A	
	eference H	B6-02	Dwell Time at Start (Dwell Time @ Start)	0.0~ 10.0	0.1s	0.0	_	x	A	A	A	A	
	iction b6 R	B6-03	Dwell Frequency at Stop (Dwell Ref @ Stop)	0.0~ 400.0	0.1Hz	0.0	_	x	A	A	A	A	
	Fun	B6-04	Dwell Time at Stop (Dwell Time @ Stop)	0.0~ 10.0	0.1s	0.0	_	x	A	A	A	A	
	control trol	B7-01	Droop Control Gain (Droop Quantity)	0.0~ 100.0	0.1%	0.0	_	0	-	-	-	A	
	Function b7 Droop Con Droop Con	B7-02	Droop Control Delay Time (Droop Delay Time)	0.03~ 2.00	0.01s	0.05	_	0	-	-	-	A	

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		B8-01	Energy-saving Gain (Energy Save Gain)	0~100	1%	80	_	х	А	Α	-	-	
uo	Saving	B8-02	Energy-saving Frequency (Energy Save Freq)	0.0~ 400.0	0.1Hz	0.0	_	x	A	A	-	-	
pplicati	Energy :	<b>B8-03</b> <1110>	Energy -saving Mode Selection	0, 1	1	0	0: (Disabled) 1: (Enabled)	х	-	-	F (A) Note	F (A) Note	
Group b A	Function b8 E	<b>B8-04</b> <1110>	Energy-saving Con- trol Gain (Energy Save Gain)	0.0~ 10.0	0.1	0.7*	*When control mode A1- 02 = 3, default factory setting becomes1.0	0	-	-	F (A) Note	F (A) Note	
		<b>B8-05</b> <1110>	Energy-saving Con- trol Time Constant (Energy Save F .T)	0.00~ 10.00	0.01s	0.50*	*When control mode A1- 02 = 3, default factory setting becomes.01	0	-	-	F (A) Note	F (A) Note	
	ervo	B9-01	Zero-servo gain (Zero Servo Gain)	0~100	1	5	_	X	-	-	-	А	
	Zero Se	B9-02	Zero-servo Completion Width (Zero Servo Count)	0~ 16383	1	10	_	x	-	-	-	A	
								Note: USA Advanced,	(02x09= <sup>.</sup> others ar	1) and EL e Factory	IR. (02x09 setting.	9=2) are	
		C1-01	Acceleration Time 1 (Accel Time 1)			10.0	_	0	Q	Q	Q	Q	
		C1-02	Deceleration Time 1 (Decel Time 1)			10.0	_	0	Q	Q	Q	Q	
		C1-03	Acceleration Time 2 (Accel Time 2)	Depends	Depende	10.0	_	0	В	В	В	В	
		C1-04	Deceleration Time 2 (Decel Time 2)	C1-10	On C1-10	10.0	_	0	В	В	В	В	
	<del>a</del>	C1-05	Acceleration Time 3 (Accel Time 3)	0.00~		10.0	_	x	А	А	А	А	
ing	el / Dec	C1-06	Deceleration Time 3 (Decel Time 3)	600.00 or	0.01s or	10.0	_	x	А	А	А	А	
p C Tur	C1 Acce	C1-07	Acceleration Time 4 (Accel Time 4)	0.0 ~	0.1s	10.0	_	х	А	А	А	А	
Grou	nction (	C1-08	Deceleration Time 4 (Decel Time 4)	6000.0		10.0	_	Х	А	А	A	А	
	Fur	C1-09	Emergency Stop Time (Fast Stop Time)			10.0	_	x	В	В	В	В	
		C1-10	Accel/Decel Time Set Unit (Acc/Dec Units)	0.1	1	1	0: Set unit of accel/decel time is 0.01s. (0.01 Seconds) 1: Set unit of accel/decel time is 0.1s. (0.1 Seconds)	x	A	A	A	A	
		C1-11	Accel/Decel Time Switching Frequency (Acc/Dec SW Freq)	0.0~ 400.0	0.1Hz	0.0	_	x	A	A	A	A	

								Change	Pa	rameter A	Access Le	vel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	Acc/Dec	C2-01	S-Curve Character- istic Time at Accel- eration Start (SCrv Acc@ Start)	0.00~ 2.50	0.01s	0.20	_	x	A	A	A	A	
	C2 S-Curve	C2-02	S-Curve Character- istic Time at Accel- eration End (SCrv Acc@ End)	0.00~ 2.50	0.01s	0.20	_	x	A	A	A	A	
	Function	C2-03	S-Curve Character- istic Time at Decel- eration Start (SCrv Dec @ Start)	0.00~ 2.50	0.01s	0.20	_	x	A	A	A	A	
C Tuning		C3-01	Slip Compensation Gain (Slip Comp Gain)	0.0~2.5	0.1	1.0*	* Default factory setting is 0.0 when A1-02=0 [V/F mode]. When A1-02=2 [Open Loop Vector] or 3 [Close loop vector] default factory	0	В	-	В	В	
oup C Tuning	ion	C3-02	Slip Compensation Primary Delay Time (Slip Comp Time)	0~10000	1 ms	200*	* Default factory setting is 2000ms when A1-02=0 [V/F mode]. When A1-02=2 [Open Loop Vector] default factory setting is 200ms.	x	A	-	A	-	
Gro	Compensat	C3-03	Slip Compensation Limit (Slip Comp Limt)	0~250	1%	200	_	х	A	-	A	-	
	3 Motor Slip (	C3-04	Slip Compensation Selection during Regeneration (Slip Comp Regen)	0, 1	1	0	0 : Disabled 1 : Enabled	x	A	-	A	-	
	Function (	<b>C3-05</b> <1110>	Flux Calculation Method ( Flux Select)	0, 1	1	0	<ul> <li>Magnetic flux is calculated by output frequency after compensation. (Slip Included)</li> <li>Magnetic flux is calcu- lated by output frequency before compensation. (Slip Excluded)</li> </ul>	x	-	-	A	-	
Not		<b>C3-06</b> <1110>	Output Voltage Limit Operation Selection (Output V limit)	0, 1	1	0	0 : Disabled (Note 10) 1 : Enabled (Note 11)	x	-	-	A	A	
No	e 10	vVhen this speed.	parameter is "0" slip con	npensation	will be disa	abled wher	n the motor is operating above its ba	se speed. Th	e motor vo	ottage will	not be red	uced abov	e base

Note 11 Open Loop Vector: When this parameter is set to "1" the motor voltage will be reduced slightly when the motor is operating above 90% base speed. Slip Compensation is enabled. Speed control accuracy is improved. This may prevent speed instabilities due to motor voltage saturation. This setting may improve speed regulation however motor torque/amp will be reduced by up to 10% due to motor voltage reduction above base speed. Close loop vector: Torque linearity is improved.

# micno

								Change	Pa	rameter A	Access Le	vel	
Group C Tuning	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		C4-01	Torque Compensa- tion Gain (Torq Comp Gain)	0.00~ 2.50	0.01	1.00	_	0	В	В	В	-	
	sation	C4-02	Torque Compensa- tion Time (Torq Comp Time)	0~10000	1 ms	20*	* When A1-02=2 [Open Loop Vector] factory default setting is 20 ms. When A1-02=1or 3 [V/ F or V/F w/PG] factory default setting is 200 ms.	x	A	A	A	-	
	C4 Torque Compens	<b>C4-03</b> <1110>	Forward Torque Compensation Value @ Start (F TorqCmp @start)	0.0~ 200.0	0.1%	0.0	Functions only when starting a motor. Torque reference and motor flux can be ramped up quickly to improve speed response during start. A set- ting of 0.0 disables this feature.	X	-	-	A	-	
	Function	<b>C4-04</b> <1110>	Reverse Torque Compensation Value @ Start. (R TorqCmp @ start)	200.0~ 0.0	0.1%	0.0	Functions only when starting a motor. Torque reference and motor flux can be ramped up quickly to improve speed response during start. A set- ting of 0.0 disables this feature.	x	-	-	A	-	
bu		<b>C4-05</b> <1110>	Torque Compensa- tion Time Constant (TorqCmp Delay T)	0~200	1ms	10	When 0~4ms is set, it is oper- ated without filter. Functions with C4-03 and C4-04.	х	-	-	A	-	
Group C Tuni		C5-01	ASR Proportional (P) Gain 1 (ASR P Gain 1)	0.00~ 300.00	0.01	20.00*	When A1-02=1 [V/f w/PG] fac- tory default setting is .20. When A1-02=3 factory default setting is 20.00.	0	-	В	-	В	
		C5-02	ASR Integral (I) Time 1 (ASR 1 Time 1)	0.000~ 10.000	0.001s	0.500*	When A1-02=1 [V/f w/PG] fac- tory default setting is .200. When A1-02=3 factory default setting is .500	0	-	В	-	В	
	R Tuning	C5-03	ASR Proportional (P) Gain 2 (ASR P Gain 2)	0.00~ 300.00	0.01	20.00*	When A1-02=1 [V/f w/PG] fac- tory default setting is .02 When A1-02=3 factory default setting is 20.00.	0	-	В	-	В	
	unction C5 AS	C5-04	ASR Integral (I) Time 2 (ASR 1 Time 2)	0.000~ 10.000	0.001s	0.500*	When A1-02=1 [V/f w/PG] fac- tory default setting is .050. When A1-02=3 factory default setting is .500.	0	-	В	-	В	
	ц	C5-05	ASR Limit (ASR Limt)	0.0~ 20.0	0.1%	5.0	-	х	-	А	-	-	
		C5-06	ASR Primary Delay Time (ASR Delay Time)	0.000~ 0.500	0.001s	0.004	_	x	-	-	-	A	
		C5-07	ASR Switching Frequency (ASR Gain SW Freq)	0.0~ 400.0	0.1Hz	0.0	_	x	-	-	-	A	
		C5-08	ASR Integral Limit (ASR I Limit)	0~400	1	400%	_	х	-	-	-	А	

								Change	Pa	ameter A	Access Le	evel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	requency	C6-01	Carrier Frequency Upper Limit (Carrier Freq Max)	0.4~ 15.0**	0.1 kHz	15.0**	When control mode is vector control (A1-02=2, 3), the setting	x	В	В	В	В	
	6 Carrier F	C6-02	Carrier Frequency Lower Limit (Car- rier Freq Min)	0.4~ 15.0	0.1 kHz	15.0**	range of C6-01 and C6-02 is 2.0 ~15.0. ** Setting range and factory	x	A	A	-	-	
Group C Tuning	Function C	C6-03	Carrier Frequency Proportional Gain (Carrier Freq Gain)	00~99**	1	00**	setting differ depending on inverter capacity.	х	A	A	-	-	
	revention	C7-01	Hunting Prevention Selection (Hunt Prev Select)	0, 1	1	1	0: Disabled 1: Enabled	x	A	A	-	-	
	Function C7 Hunting P	C7-02	Hunting Prevention Gain (Hunt Prev Gain)	0.00~ 2.50	0.01	1.00	_	x	A	A	-	-	
	b	C8-08	AFR Gain (AFR Gain)	0.00~ 10.00	0.01	1.00	_	х	-	-	А	-	
Бu	y Tunir	C8-09	AFR Time Constant (AFR Time)	0~2000	1 ms	50	-	х	-	-	А	-	
Group C Tuning	Function C8 Factor	<b>C8-30</b> <1110>	Carrier Frequency Selection during Auto-tuning (Carrier in tune)	0~2	1	0	<ul> <li>0: Carrier frequency is 2 kHz.</li> <li>1: Carrier frequency depends on C6-01.</li> <li>2: Carrier frequency is 5 kHz. (185~300 kW: 2.5 kHz)</li> </ul>	x	-	-	A	A	

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		D1-01	Frequency Reference 1 (Reference 1)	0.00~ 400.00	0.01Hz	0.00	_	0	Q	Q	Q	Q	
		D1-02	Frequency Reference 2 (Reference 2)	0.00~ 400.00	0.01Hz	0.00	_	0	Q	Q	Q	Q	
		D1-03	Frequency Reference 3 (Reference 3)	0.00~ 400.00	0.01Hz	0.00	_	0	Q	Q	Q	Q	
	Reference	D1-04	Frequency Reference 4 (Reference 4)	0.00~ 400.00	0.01Hz	0.00	-	0	Q	Q	Q	Q	
	d1Preset F	D1-05	Frequency Reference 5 (Reference 5)	000~ 400.00	0.01Hz	0.00	_	0	В	В	В	В	
	Function	D1-06	Frequency Reference 6 (Reference 6)	0.00~ 400.00	0.01Hz	0.00	_	0	В	В	В	В	
teference		D1-07	Frequency Reference 7 (Reference 7)	0.00~ 400.00	0.01Hz	0.00	-	0	В	В	В	В	
Group d R		D1-08	Frequency Reference 8 (Reference 8)	0.00~ 400.00	0.01Hz	0.00	_	0	В	В	В	В	
		D1-09	Jog Frequency Reference (Jog Reference)	0.00~ 400.00	0.01Hz	6.00	_	0	Q	Q	Q	Q	
	ion d2 ce Limits	D2-01	Frequency Refer- ence Upper Limit (Ref Upper Limit)	0.0~110.0	0.1%	100.0	_	x	В	В	В	В	
	Funct	D2-02	Frequency Refer- ence Lower Limit (Ref Lower Limit)	0.0~109.0	0.1%	0.0	_	x	В	В	В	В	
	encies	D3-01	Jump Frequency 1 (Jump Freq 1)	0.0~400.0	0.1Hz	0.0	_	х	В	В	В	В	
	Frequ	D3-02	Jump Frequency 2 (Jump Freq 2)	0.0~400.0	0.1Hz	0.0	_	x	В	В	В	В	
	3 Jump	D3-03	Jump Frequency 3 (Jump Freq 3)	0.0~400.0	0.1Hz	0.0	_	х	В	В	В	В	
	Function d(	D3-04	Jump Frequency Width (Jump Bandwidth)	0.0~20.0	0.1Hz	1.0	_	x	В	В	В	В	

								Change	Pa	rameter A	Access Le	evel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	tion d4 Sequence	D4-01	Frequency Refer- ence Hold Function Selection (MOP Ref Memory)	0, 1	1	0	<ul> <li>0: (Disabled) No hold frequency is memo- rized.</li> <li>1: (Enabled) Hold frequency is memo- rized.</li> </ul>	x	A	A	A	A	
	Funct	D4-02	±Speed Limits (Trim Control Lvl)	0~100	1%	25*	*When 02-09=1 [USA], the unit is 10%. <24>	x	А	Α	A	Α	
ence		D5-01	Torque Control Selection (Torq Control Sel)	0, 1	1	0	0: (Speed Control) 1: (Torque Control)	x	-	-	-	A	
ip d Refere	introl	D5-02	Torque Reference Delay Time (Torque Ref Filter)	0~1000	1 ms	0	_	x	-	-	-	A	
Grou	Torque Co	D5-03	Speed Limit Selection (Speed Limit Sel)	1, 2	1	1	<ol> <li>1: (Analog Input) terminal 13, 14</li> <li>2: (Program Setting)</li> </ol>	х	-	-	-	A	
	tion d5	D5-04	Speed Limit (Speed Lmt Value)	-120 ~ +120	1%	0	_	х	-	-	-	А	
	Func	D5-05	Speed Limit Bias (Speed Lmt Bias)	0~120	1%	10	_	х	-	-	-	А	
		D5-06	Speed/torque Control Switching Timer (Ref Hold Time)	0~1000	1 ms	0	_	x	-	-	-	A	

							Change	Pa	rameter A	Access Le	vel	
nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	E1-01	Input Voltage Setting (Input Voltage)	155~ 255 (Note 13)	1 V	200 (Note 13)	<sup>1</sup> When 02-09=1 [USA], the value is 1.15 times of Japanese spec., which is 230/200	X	Q	Q	Q	Q	
	E1-02	Motor Selection (Motor Selection)	0, 1, 2	1	0	0: (Std Fan-Cooled) 1: (Std Blower-Cooled) 2: (Vector Motor) <1110>	x	Q	Q	Q	Q	
Function E1 V/F Pattern	E1-03	V/f Pattern Selection (V/F Selection)	00~0F	1	OF	V/f pattern selection 0: 50Hz 1: 60Hz Saturation 2: 50Hz Saturation 3: 72Hz 4: 50Hz Variable Torque 1 5: 50Hz Variable Torque 1 6: 60Hz Variable Torque 1 7: 60Hz Variable Torque 2 8: 50Hz High Starting Torque 2 8: 50Hz High Starting Torque 2 8: 60Hz High Starting Torque 1 8: 60Hz High Starting Torque 2 C: 90Hz D: 120Hz E: 180Hz F: User-defined V/f pattern	X	Q	Q	Q	Q	
	E1-04	Max. Output Frequency (Max Frequency)	40.0~40 0.0	0.1Hz	60.0* (Note 13)	*Factory setting differs depend- ing on the inverter capacity 02- 04. When 02-09=2 [EUR.], the value is 50.0Hz.	x	Q	Q	Q	Q	
. 10	E1-05	Max. Voltage (Max Voltage)	0.0~ 255.0 (Note 13)	0.1 V	200.0 (Note 13)*	*Factory setting differs depend- ing on the inverter capacity (02- 04). When 02-09=1 (USA), the value is 1.15 times of Japanese spec., which is 230/200	x	Q	Q	Q	Q	
	Function E1 V/F Pattern	Parameter No.           E1-01           E1-02           Hotomore           E1-03           E1-04           E1-05	Parameter No.Name (Digital Operator Display)IntuiningE1-01Input Voltage Setting (Input Voltage)E1-02Motor Selection (Motor Selection)E1-03V/f Pattern Selection (V/F Selection)E1-04Max. Output Frequency (Max Frequency)E1-05Max. Voltage (Max Voltage)	InctionParameter No.Name (Digital Operator Display)Setting RangeE1-01Input Voltage Setting (Input Voltage)155~ 255 (Note 13)E1-02Motor Selection (Motor Selection)0, 1, 2E1-03V/f Pattern Selection (V/F Selection)00~0FE1-04Max. Output Frequency (Max Frequency)40.0~40 0.0E1-05Max. Voltage (Max Voltage)0.0~ 255.0 (Note 13)	InctionParameter No.Name (Digital Operator Display)Setting RangeSetting UnitE1-01Input Voltage Setting (Input Voltage)155~ 255 (Note 13)1 VE1-02Motor Selection (Motor Selection)0, 1, 21E1-03V/f Pattern Selection (V/F Selection)00~0F1E1-04Max. Output Frequency (Max Frequency)40.0~40 0.00.1HzE1-05Max. Voltage (Max Voltage)0.0~ 255.0 (Note 13)0.1 V	InctionParameter No.Name (Digital Operator Display)Setting RangeSetting UnitFactory SettingE1-01Input Voltage Setting (Input Voltage)155- 255 (Note 13)1 V200 (Note 13)E1-02Motor Selection (Motor Selection)0, 1, 210E1-03V/f Pattern Selection (V/F Selection)00~0F10E1-04Max. Output Frequency (Max Frequency)40.0~40 0.00.1Hz60.0* (Note 13)E1-05Max. Voltage (Max Voltage)0.0~ 255.0 (Note 13)0.1 V200.0 (Note 13)*	Parameter No.         Name (Digital Operator Display)         Setting Range         Factory Unit         Remarks (Digital Operator Display)           E1-01         Input Voltage Setting (Input Voltage)         155- 255 (Note 13)         200 13)         "When 02-09=1 [USA], the value is 1.15 times of Japanese spec., which is 230/200           E1-02         Motor Selection (Motor Selection)         0, 1, 2         1         0         0: (Std Fan-Cooled) 1: (Std Blower-Cooled) 2: (Vector Motor) <110>           V/f Pattern Selection (V/F Selection)         0, 1, 2         1         0         0: GSd Fan-Cooled) 1: (Std Blower-Cooled) 2: (Vector Motor) <110>           V/f Pattern Selection (V/F Selection)         00-0F         1         0F         Soft2 Variable Torque 1 6: 60H2 Variable Torque 1 9: 50H2 High Starting Torque 2 8: 60H2 High Starting Torque 2 120Hz E: 180Hz           E1-04         Max. Output Frequency (Max Frequency)         40.0-40 0.0 0.0-2 255.0 (Note Max. Voltage         0.0-2 255.0 (Note Max. Voltage         0.0-2 255.0 (Note Max. Voltage         0.0-2 255.0 (Note Max. Voltage         200.0 13)         *Factory setting differs depend- ing on the inverter capacity 02- 04.         *Factory setting differs depend- ing on the inverter capacity 02- 04.           13)         Max. Voltage Max. Voltage         0.0-7 255.0 (Note Max. Voltage)         0.1 V 13)	Parameter No.         Name (Digital Operator Display)         Setting Range         Setting Unit         Factory Setting (Digital Operator Display)         Remarks (Digital Operator Display)         Change during Operation c. Enabled           E1-01         Input Voltage Setting (Input Voltage)         155~ 255 (Note 13)         200 (Note 13)         "When 02-09=1 [USA], the value is 1.15 times of Japanese spec., which is 230/200         x           E1-02         Motor Selection (Motor Selection)         0, 1, 2         1         0         : (Std Fan-Cooled) 2: (Vector Motor) <1110>         x           E1-03         Wif Pattern Selection (V/F Selection)         0, 1, 2         1         0         : (Std Fan-Cooled) 2: (Vector Motor) <1110>         x           E1-04         Max. Output Frequency (Max Frequency)         0, -0F         1         0         0         : StoHz Variable Torque 1 5: SoHz Variable Torque 2 8: SoHz High Starting Torque 2 8: SoHz High Starting Torque 2 8: SoHz High Starting Torque 1 8: SoHz High Starting Torque 2 8: SoHz High Starting Torque 1 8: GoHz High Starting Torque 2 8: SoHz High Starting Other Pattern 9: CoHz High Starting Torque 2 8: SoHz High Starting Torque 2 8: SoHz High Starting differs depend- ing on the inverter capacity 02- 04.<	Parameter No.         Name (Digital Operator Display)         Setting Range         Setting Unit         Factory Setting         Remarks (Digital Operator Display)         Change Operator (Digital Operator Display)         Pactory Operator         Remarks (Digital Operator Display)         Pactory Operator         Pactory (Digital Operator Display)         Pactory Operator         Remarks (Digital Operator Display)         Pactory Operator         Pactory (Digital Operator Display)         Pactory (Digital Operator Display)         Pactory Operator           E1-01         Input Voltage (Input Voltage)         155- (Note 13)         1         200 (Note 13)         When 02-09=1 [USA], the value is 1.15 times of Japanese spec., which is 230/200         x         Q           E1-02         Motor Selection (Motor Selection)         0, 1, 2         1         0         0: (Sid Fan-Cooled) 1: (Sid Biower-Cooled) 2: (Vector Motor) <1110>         x         Q           E1-03         Vif Pattern (ViF Selection)         00~0F         1         0F         6: 60Hz Variable Torque 1 5: 60Hz Variable Torque 1 5: 60Hz Variable Torque 1 5: 60Hz Variable Torque 1 8: 60Hz High Starting Torque 2 8: 60Hz         x         Q           E1-04         Max. Output Frequency (Max Frequency)         40.0~40 (Note 13)         0.1Hz         60.	Parameter No.         Name (Digital Operator Display)         Setting Range         Factory Unit         Remarks (Digital Operator Display)         Change Operator (Digital Operator Display)         Parameter / Wrf           E1-01         Input Voltage (Input Voltage)         155~ (Note 13)         200 (Note 13)         When 02-09=1 [USA], the value is 1.5 times of Japanese spec., which is 230/200         x         Q         Q           E1-02         Motor Selection (Motor Selection)         0, 1, 2         1         0         Cisid Fan-Cooled) 1: (Std Blower-Cooled)         x         Q         Q           E1-02         Motor Selection (Motor Selection)         0, 1, 2         1         0         Cisid Fan-Cooled) 1: (Std Saturation 2: (Vector Motor) <1110>         x         Q         Q           E1-03         Vif Pattern Selection (V/F Selection)         00~0F         1         0F         7. 60Hz Variable Torque 1 5: 60Hz	Parameter No.     Name (Digital Operator Display)     Setting Range     Setting Unit     Factory Setting     Remarks (Digital Operator Display)     Change Operator (Digital Operator Display)     Parameter Access Le during       Input Voltage Setting (Input Voltage)     155- 255 (Note (Input Voltage)     1V     200 (Note 13)     'When 02-09=1 (USA), the value is 1.15 times of Japanese spec., which is 230/200     x     Q     Q     Q       E1-01     Motor Selection (Motor Selection)     0, 1, 2     1     0     0: (Std Fan-Cooled) 1: (Std Blower-Cooled)     x     Q     Q     Q       E1-02     Motor Selection (Motor Selection)     0, 1, 2     1     0     0: (Std Fan-Cooled) 1: (Std Blower-Cooled)     x     Q     Q     Q       Vif Pattern (ViF Pattern     0     0, 1, 2     1     0     0: (Std Fan-Cooled)     x     Q     Q     Q       Vif Pattern (ViF Selection)     0, 0, 0     0, 1, 2     1     0     0: (Std Fan-Cooled)     x     Q     Q     Q       Vif Pattern (ViF Selection)     0, 0, 0     0, 1, 2     1     0     0: (Std Fan-Cooled)     x     Q     Q     Q       E1-04     Max. Output (ViF Selection)     0, 0     0, 0     0     0     0     0     0     0     0     0     0     0     0 <t< td=""><td>Parameter No.     Name (Digital Operator Display)     Setting Range     Setting Unit     Factory Setting     Remarks (Digital Operator Display)     Change Operator (Display)     Parameter Access Level       Input Voltage Setting (Input Voltage)     155~ (Note 13)     200 (Note 13)     When 02-09=1 [USA], the value is 1.15 times of Japanese spec, which is 230/200     x     Q     Q     Q     Q       E1-01     Motor Selection (Motor Selection)     0, 1, 2     1     0     0. (Stif Fan-Cooled) 2: (Vector Motor) +110&gt;     x     Q     Q     Q     Q       E1-03     Motor Selection (Motor Selection)     0, 1, 2     1     0     0. (Stif Fan-Cooled) 2: (Vector Motor) +110&gt;     x     Q     Q     Q     Q       E1-03     Motor Selection (V/F Pattern     00-0F     1     0     0. (Stif Fan-Cooled) 2: Stif Patter Motor) +110&gt;     x     Q     Q     Q     Q       E1-04     Max. Output Fedue     00-0F     1     0     0. (Stif Fan-Cooled) 2: Stif Pattern Selection (V/F Selection)     x     Q     Q     Q     Q       E1-04     Max. Output Fequency (Max Frequency)     40.0-40 0.0     0.1Hz     0.0-7 255.0 (Note 13)     0.1Hz     60.0-7 60.0-7 8: Stif High Starting Torque 1 8: Stif High Starting Torque 2 9: Stif High Starting Torque 2 1: 1: Stil Biorol 2: Stif</td></t<>	Parameter No.     Name (Digital Operator Display)     Setting Range     Setting Unit     Factory Setting     Remarks (Digital Operator Display)     Change Operator (Display)     Parameter Access Level       Input Voltage Setting (Input Voltage)     155~ (Note 13)     200 (Note 13)     When 02-09=1 [USA], the value is 1.15 times of Japanese spec, which is 230/200     x     Q     Q     Q     Q       E1-01     Motor Selection (Motor Selection)     0, 1, 2     1     0     0. (Stif Fan-Cooled) 2: (Vector Motor) +110>     x     Q     Q     Q     Q       E1-03     Motor Selection (Motor Selection)     0, 1, 2     1     0     0. (Stif Fan-Cooled) 2: (Vector Motor) +110>     x     Q     Q     Q     Q       E1-03     Motor Selection (V/F Pattern     00-0F     1     0     0. (Stif Fan-Cooled) 2: Stif Patter Motor) +110>     x     Q     Q     Q     Q       E1-04     Max. Output Fedue     00-0F     1     0     0. (Stif Fan-Cooled) 2: Stif Pattern Selection (V/F Selection)     x     Q     Q     Q     Q       E1-04     Max. Output Fequency (Max Frequency)     40.0-40 0.0     0.1Hz     0.0-7 255.0 (Note 13)     0.1Hz     60.0-7 60.0-7 8: Stif High Starting Torque 1 8: Stif High Starting Torque 2 9: Stif High Starting Torque 2 1: 1: Stil Biorol 2: Stif

								Change	Par	rameter A	ccess Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		E1-06	Max. Voltage Frequency (Base Frequency)	0.0~ 400.0	0.1Hz	60.0* (Note 13)	*Factory setting differs depend- ing on the inverter capacity (02- 04). When 02-09=2 (EUR.), the value is 50.0Hz.	x	Q	Q	Q	Q	
		E1-07	Mid. Output Frequency (Mid Frequency A)	0.0~ 400.0	0.1Hz	3.0* (Note 13)	*Factory setting differs depend- ing on the inverter capacity (02- 04). When 02-09=2 (EUR.), A1- 02=0, and E1-03=OF, the value is 5/6 times that of Japan spec.[for a V/F pattern with a 50Hz base frequency]	x	Q	Q	A	F	
Group E Motor		E1-08	Mid. Output Frequency Voltage (Mid Voltage A)	0.00~ 255. 0 (Note 13)	0.1 V	11.0 (Note 13)*	*Factory setting differs depend- ing on the inverter capacity (02- 04). When 02-09=1 (USA), the value is 1.15 times of Japanese spec., which is 230/200.	X	Q	Q	A	F	
	Torque Control	E1-09	Min. Output Frequency (Min Frequency)	0.0~ 400.0	0.1Hz	0.5* (Note 13)	*Factory setting differs depend- ing on the inverter capacity (02- 04). When 02-09=2 (EUR.), A1- 02=0, and E1-03=OF, the value is 5~6 times of Japan.	x	Q	Q	Q	A	
		E1-10	Min. Output Frequency Voltage (Min Voltage)	0.0~ 255.0 (Note 13)	0.1V	2.0 (Note 13)*	*Factory setting differs depend- ing on the inverter capacity (02- 04). When 02-09=1 (USA), the value is 1.15 times of Japanese spec., which is 230/200.	x	Q	Q	A	F	
		E1-11	Mid. Output Fre- quency 2 (Mid Frequency B)	0.0~ 400.0	0.1Hz	0.0	_	x	A	A	A	A	
		E1-12	Mid. Output Fre- quency Voltage 2 (Mid Voltage B)	0.0~ 255.0 (Note 13) *	0.1V	0.0	*When 02-09=1 (USA), the value is 1.15 times of Japanese spec., which is 230/200.	x	A	A	A	A	
		E1-13	Base Voltage (Base Voltage)	0.0~ 255.0 (Note 13)	0.1V	200.0 (Note 13) *	*When 02-09=1 (USA), the value is 1.15 times of Japanese spec., which is 230/200.	x	A	A	Q	Q	
Not	te 13:	This valu	e is for the 200V class	3. For 400	√ class, th	ie value is	s twice that of 200V class.						

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		E2-00	Motor Rated (Motor Rated )	_	_	_		x	-	-	-	-	
		E2-01	Motor Rated Current (Motor Rated FLA)	0.1~ 1500.0	0.1A*	1.9**	-	x	Q	Q	Q	Q	
		E2-02	Motor Rated Slip (Motor Rated Slip)	0.00~ 20.00	0.01Hz	2.90**	* When inverter capacity is	x	А	А	Q	Q	
		E2-03	Motor No-Ioad Current (No-Load Current)	0.00~ 1500.0	0.01A*	1.20**	unit becomes 0.01 A.	x	A	A	Q	Q	
oup E Motor		E2-04	Number of Motor Poles (Number of Poles)	2~48	1 pole	4	depending on inverter capacity (02-04).	x	-	Q	-	Q	
	Setup	E2-05	Motor Line-to-line Resistance (Term Resistance)	0.000~ 65.000	0.001 W	9.842**		x	A	A	A	А	
	E2 Motor	E2-06	Motor Leak Inductance (Leak Inductance)	0.0~ 30.0	0.1%	18.2**		x	-	-	A	A	
Gro	Function	E2-07	Motor Iron-core Saturation Coeffi- cient 1 (Saturation Comp 1)	0.00~ 0.50	0.01	0.50	_	x	-	-	A	A	
		E2-08	Motor Iron-core Saturation Coeffi- cient 2 (Saturation Comp 2)	0.00~ 0.75	0.01	0.75	_	x	-	-	A	A	
		E2-09	Motor Mechanical Loss (Mechanical Loss)	0.0~ 10.0	0.1%	0.0	_	x	-	-	-	A	
		E2-10	Motor Iron Loss of Torque Compensa- tion (Tcomp Iron Loss)	0~ 65535	1W	14	Access level is changed from F to A. <1110>	x	A	A	-	-	

								Change	Pa	rameter A	ccess Le	evel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	Function E3 Control Method	E3-01	Motor 2 Control Method Selection (Control Method)	0~3	1	2	0: (V/F Control) 1: (V/F w/PG Fdbk) 2: (Open Loop Vector) 3: (Close loop vector)	x	A	A	A	A	
Group E Motor		E4-01	Motor 2 Max. Out- put Frequency (Max Frequency)	40.0~ 400.0	0.1Hz	60.0	_	x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
		E4-02	Motor 2 Max. Voltage ( Max Voltage)	0.0~ 255.0 (Note 13)	0.1V	200.0 (Note 13)	_	x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
	n 2	E4-03	Motor 2 Max. Voltage Frequency (Base Frequency)	0.0~ 400.0	0.1Hz	60.0	_	x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
0	. V/F Patter	E4-04	Motor 2 Mid. Output Frequency 1 (Mid Frequency)	0.00~ 400.0	0.1Hz	3.0*	* Factory setting differs depending on the control method [E3-01]	x	A (Note 14)	A (Note 14)	A (Note 14)	F (Note 14)	
	Function E4	E4-05	Motor 2 Mid. Output Frequency Voltage 1 (Mid Voltage)	0.0~ 255.0 (Note 13)	0.1V	11.0 (Note 13)*	* Factory setting differs depending on the control method [E3-01]	x	A (Note 14)	A (Note 14)	A (Note 14)	F (Note 14)	
		E4-06	Motor 2 Min. Output Frequency ( Min Frequency)	0.0~ 400.0	0.1Hz	0.5*	* Factory setting differs depending on the control method [E3-01]	x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
		E4-07	Motor 2 Min. Output Frequency Voltage (Min Voltage)	0.0~ 255.0 (Note 13)	0.1V	2.0* (Note13)	* Factory setting differs depending on the control method [E3-01]	x	A (Note 14)	A (Note 14)	A (Note 14)	F (Note 14)	
No No	te 13: te 14:	This valu Control m	e is for the 200V class node is determined by	s. For 400\ E3-01.	/ class, th	ne value is	s twice that of 200V class.						

Name (Digital													
Fun	iction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		E5-01	Motor 2 Rated Current (Motor Rated FLA)	0.00~ 1500.0	0.1A*	1.9**		x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
	2	E5-02	Motor 2 Rated Slip (Motor Rated Slip)	0.00~ 20.00	0.01Hz	2.90**		x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
Motor	tor Setup	E5-03	Motor 2 No-load Current (No-Load Current)	0.00~ 1500.0	0.01A*	1.20**	* Setting unit is 0.01A for mod- els of 7.5 kW or less.	x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
Group E	tion E5 Mc	E5-04	Motor 2 Number of poles (Motor 2 # Poles)	2~48	1 pole	4	** Factory setting differs depending on inverter capacity (02-04).	х	- (Note 14)	A (Note 14)	- (Note 14)	A (Note 14)	
Note	Func	E5-05	Motor 2 Line-to-line Resistor (Motor 2 term Ohms)	0.000~ 65.000	0.001 W	9.842**		x	A (Note 14)	A (Note 14)	A (Note 14)	A (Note 14)	
		E5-06	Motor 2 Leak Induc- tance (Motor 2 Leak)	0.0~ 30.0	0.1%	18.2**		x	A (Note 14)	- (Note 41)	A (Note 14)	A (Note 14)	
Not Not	e 13: e 14:	This value Control m	e is for the 200V class ode is determined by	. For 400\ E3-01.	/ class, th	e value is	twice that of 200V class.						
		F1-01	PG Constant (PG Pulses/Rev)	0~ 60000	1	600*	*When 02-09=1 (USA), 2 (EUR.), factory setting is 1024	x	-	Q	-	Q	
		F1-02	Operation Selec- tion at PG Open Circuit (PG Fdbk Loss Sel)	0~3	1	1	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast-Stop) 3: (Alarm Only)	x	-	В	-	В	
	0	F1-03	Operation Selec- tion at Overspeed (PG Overspeed Sel)	0~3	1	1	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast-Stop) 3: (Alarm Only)	x	-	В	-	В	
Options *	Option Setur	F1-04	Operation Selec- tion at Deviation (PG Deviation Sel)	0~3	1	3	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast-Stop) 3: (Alarm Only)	x	-	В	-	В	
Group F (	unction F1 PG	F1-05	PG Rotation (PG Rotation Sel)	0, 1	1	0	0: Counter-clockwise (Fwd = C.C.W.) 1: Clockwise (Fwd = C.W.)	x	-	В	-	В	
	ш	F1-06	PG Division Rate PGPulse monitor (PG Output Ratio)	1~132	1	1	Effective only when control cir- cuit board PG-B2 is used.	х	-	В	-	В	
		F1-07	Integral Value during Accel/decel Enable/disable (PG Ramp PI/I Sel)	0, 1	1	0	0: (Disabled) 1: (Enabled)	x	-	В	-	-	
* \\	/hen :	F1-08	Overspeed Detection Level (PG Overspd Level) el is BASIC (A1-03)	0~120	1%	115 aved unle	-	X	-	A	-	A	

E Options *								Change	Pa	rameter A	Access Le	vel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		F1-09	Overspeed Detection Delay Time (PG Overspd Time)	0.0~2.0	0.1s	0.0*	* When A1-02=1 [V/f w/PG] fac- tory setting is 1.0. When A1- 02=3 [ Close loop vector] factory set- ting is 0.0.	x	-	A	-	A	
	etup	F1-10	Excessive Speed Deviation Detection Level (PG Deviate Level)	0~50	1%	10	_	x	-	A	-	A	
)ptions *	PG Option Se	F1-11	Excessive Speed Deviation detection Delay Time (PG Deviate Time)	0.0~ 10.0	0.1s	0.5	_	X	-	A	-	A	
Group F Options *	Function F1	F1-12	Number of PG Gear Teeth 1 (PG # Gear Teeth 1)	0~1000	1	0	_	x	-	A	-	-	
		F1-13	Number of PG Gear Teeth 2 (PG # Gear Teeth 2)	0~1000	1	0	—	x	-	A	-	-	
		F1-14	PGO Detection Time (PGO Detect Time)	0~10.0	0.1s	2.0	_	x	-	A	-	A	
* 1/	Function F2 AI-14 Setup	F2-01	AI-14B Card Input Selection (AI-14 Input Sel)	0, 1	1	0	0: (3-ch Individual) 1: (3ch Addition)	x	A	A	A	A	
* \	When a	access lev	el is BASIC (A1-03), o	constant is	not displa	ayed unle	ss the option is connected.						

			Change Parameter Access Level						vel				
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	Function F3 DI-08, 16 Setup	F3-01	Digital Input Selection (DI Input)	0~7	1	0	0: (BCD 1%) 1: (BCD 0.1%) 2: (BCD 0.01%) 3: (BCD 1Hz) 4: (BCD 0.1Hz) 5: (BCD 0.01Hz) 6: BCD Special setting 5 digit input, Binary 255/100% (BCD (5DG) 0.01Hz) 7: (Binary)* *Set value is displayed as decimal.	X	A	A	A	A	
Group F Options *	Function F4 AO-08. 12	F4-01	Channel 1 Monitor Selection (AO Ch1 Select)	1~38	1	2	Analog Output option Channel 1 1: Frequency reference 2: Output frequency 3: Inverter output current 5: Motor speed 6: Output voltage 7: DC bus voltage 8: Output power 9: Torque reference (internal) 15: External terminal 13 input voltage 16: External terminal 14 input voltage 17: External terminal 16 input voltage 18: Motor secondary current (Iq) 19: Motor excitation current (Id) 20: Primary frequency after SFS 21: Speed controller ASR input 22: Speed controller ASR output 23: Speed deviation 24: PID feedback 26: Voltage reference (Vq out- put) 27: Voltage reference (Vd out put) 32: ACR (q) Output 33: ACR (d) Output 36: PID Input <1110> 37: PID Output <1110> 38: PID Reference <1110>	X	A	A	A	A	
		F4-02	Channel 1 Gain (AO Ch1 Gain)	0.00~ 2.50	0.01	1.00	-	0	А	А	А	А	
		F4-03	Channel 2 Monitor Selection (AO Ch2 Select)	1~38	1	3	Analog Output option Channel 2 selection (same as F4-01)	х	A	A	A	A	
		F4-04	Channel 2 Gain (AO Ch2 Gain)	0.00~ 2.50	0.01	0.50	_	0	А	А	А	Α	
		<b>F4-05</b> <1110>	CH1 Output Bias (AO Ch1 Bias)	-10.0 ~10.0	0, 1	0.0	-	0	A	A	A	A	
		<b>F4-06</b> <1110>	CH2 Output Bias	-10.0 ~10.0	0, 1	0.0		0	A	А	А	А	
* V	Vhen a	access lev	el is BASIC (A1-03), o	constant is	not displa	ayed unle	ss the option is connected.						

								Change	Pa	rameter A	ccess Le	vel	
Function		Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	02 Setup	F5-01	Channel 1 Output Selection (DO-02 Ch1 Select)	00~37	1	0	_	x	A	A	A	A	
	Function F5 DO -	F5-02	Channel 2 Output Selection (DO-02 Ch2 Select)	00~37 <26>	1	1	_	x	A	A	A	A	
	Function F6 DO - 08 Setup	F6-01	Output Mode Selection (DO-08 Selection)	0, 1	1	0	0: (8ch Individual) 1: (Binary Output)	x	A	A	A	A	
	Function F7 PO - 36F Setup	F7-01	Frequency Multiple Selection (PO-36F Selection)	0~4	1	1	0: (1 X Output Freq) 1: (6 X Output Freq) 2: (10 X Output Freq) 3: (12 X Output Freq) 4: (36 X Output Freq)	x	A	A	A	A	
SUC	Function F8 SI - F./G Setup	F8-01	SI-F/G Communication Error Detection Operation Selection (E-15 Det Sel)	0~3	1	1	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast - Stop) 3: (Alarm Only)	x	A	A	A	A	
<b>Group F</b> Optio		F9-01	Option External Fault Selection (EFO Selection)	0, 1	1	0	0: When 1 is shown, EFO occurs (Normally Open) 1: When 0 is shown, EFO occurs. (Normally Closed)	x	A	A	A	A	
	3I-B	F9-02	Option External Fault Detection Selection (EFO Detection)	0, 1	1	0	0: (Always Detected) 1: (Only During Run)	x	A	A	A	A	
	etup / DDS • S	F9-03	Option External Fault Detection Operation Selection (EFO Fault Action)	0~3	1	1	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast - Stop) 3: (Alarm Only)	x	A	A	A	A	
	CP-916 Se	F9-04	Trace Sampling Time (Trace Sample Tim)	0~ 60000	1	0	_	x	A	A	A	A	
	Function F9 C	F9-05	Torque Reference/ Torque Limit Selec- tion through DP- RAM communica- tion (Torq Ref / Lmt Sel)	0, 1	1	1	0: (Disabled) 1: (Enabled)	x	-	-	-	A	
		F9-06	DP-RAM Communi- cation Error Detec- tion Operation Selection (BUS Fault Sel)	0~3	1	1	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast - Stop) 3: (Alarm Only)	x	A	A	A	A	

							Change	Par	rameter A	ccess Le	vel	
Function	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	dunng Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
Terminal Function Function H1 Digital Inputs	H1-01	Terminal 3 Selection (Terminal 3 Sel) Terminal 4 Selection (Terminal 4 Sel) Terminal 5	00~77	1	24	Multi-function input (terminal 3) 0: 3-Wire Control 1: Local/Remote Selection 2: Option/Inverter Selection 3: Multi-Step Reference 1 4: Multi-Step Reference 2 5: Multi-Step Reference 3 6: Jog Frequency Reference 7: Multi-Accel/Decel 1 8: External Baseblock N.O. 9: External Baseblock N.O. 9: External Baseblock N.O. 9: External Baseblock N.O. 9: External Baseblock N.C. A: Accel/Decel Ramp Hold B: OH2 Alarm Signal C: Terminal 16 Enable D: V/F Mode Select E: ASR Integral Reset F: Terminal Not Used 10: MOP Increase 11: MOP Decrease 12: Forward Jog 13: Reverse Jog 14: Fault Reset 15: Fast-Stop N.O. 16: Motor 2 Select 17: Fast Stop N.C. input <1110> 18: Timer Function 19: PID Disable 1A: Multi-Accel/Decel 2 1B: Program Lockout 1C: Trim Control Increase 1D: Trim Control Increase 1D: Trim Control Increase 1E: Ref Sample Hold 1F: Terminal 13/14 Switch 24: External Fault 30: PID Integral Reset 31: PID Control Integral Hold <1110> 60: DC Injection Activate 61: Speed Search 1 62: Speed Search 2 63: Energy Save Mode 64: Speed Search 3 65: KEB Ridethrough N.O. 71: Speed/Torque Control Change 72: Zero Servo Command 77: ASR Gain Switch Multi-function input (terminal 4) (same as H1-01)	x	В	В	В	В	
	H1-03	Selection (Terminal 5 Sel)	00~77	1	(Note 15)	(same as H1-01)	x	В	В	В	В	

							Change	Pa	rameter Access Level			
Function	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	H1-04	Terminal 6 Selection (Terminal 6 Sel)	00~77	1	4 (3) (Note 15)	_	x	В	В	В	В	
	H1-05	Terminal 7 Selection (Terminal 7 Sel)	00~77	1	6 (4) (Note 15)	_	х	В	В	В	В	
	H1-06	Terminal 8 Selection (Terminal 8 Sel)	00~77	1	8 (6) (Note 15)	_	х	В	В	В	В	
Note 15: Factory settings in the parentheses are values obtained at 3-wire initialization.												

	_							Change	Pa	Parameter Access Level				
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting	
	I Outputs	H2-01	Multi-function Input Terminal 9-10 (Terminal 9 Sel)	00~37	1	0	Multi-function output 1 (terminal 9, terminal 10) (same as F5-01)	x	В	В	В	В		
	n H2 Digita	H2-02	Multi-function Input Terminal 25 (Terminal 25 Sel)	00~37	1	1	Multi-function output 2 (terminal 25, terminal 27) (same as F5-01)	x	В	В	В	В		
	Functio	H2-03	Multi-function Input Terminal 26 (Terminal 26 Sel)	00~37	1	2	Multi-function output 3 (terminal 26, terminal 27) (same as F5-01)	x	В	В	В	В		
	puts	H3-01	Signal Level Selec- tion Terminal 13 (Term 13 Signal)	0, 1	1	0	0: (0 - 10 VDC) 1: (-10 +10 VDC)	x	В	В	В	В		
		H3-02	(Terminal 13 Gain)	0.0~ 1000.0	0.1%	100.0	Frequency reference gain of Al- 14U, Al-14B (3ch addition input), Dl-08, and Dl-16 is com- mon.	0	В	В	В	В		
nal		H3-03	(Terminal 13 Bias)	-100.0 ~ +100.0	0.1%	0.0	Frequency reference gain of Al- 14U, Al-14B (3ch addition input), Dl-08, and Dl-16 is com- mon.	0	В	В	В	В		
Termi		H3-04	Terminal 16 Signal Level Selection (Term 16 Signal)	0, 1	1	0	0: (0 - 10 VDC) 1: (-10 +10 VDC)	x	В	В	В	В		
	Function H3 Analog Ir	H3-05	Terminal 16 Multi- function Analog Input (Terminal 16 Sel)	0~1F	1	0	Multi-function analog input selec- tion (terminal 16) 0: Auxiliary Reference 1: Frequency Gain 2: Frequency Bias 4: Voltage Bias 5: Accel/Decel Change 6: DC Brake Current 7: Overtorque Level 8: Stall Prevention Level 9: Reference Lower Limit A: Jump Frequency B: PID Feedback C: PID Setpoint D: Frequency Bias 2 10: Forward Torque Limit 11: Reverse Torque Limit 12: Regenerative Torque Limit 13: Torque reference 14: Torque Compensation 15: Forward/Reverse Torque Limit 1F: Not Used	X	В	В	В	В		

						Factory	Factory Remarks Setting (Digital Operator Display)	Change	Parameter Access Level				
Fu	nction	Parameter No.	Operator Display)	Setting Range	Setting Unit	Factory Setting		Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		H3-06	(Terminal 16 Gain)	0.0~ 1000.0	0.1%	100.0	_	0	В	В	В	В	
Terminal		H3-07	(Terminal 16 Bias)	-100.0 ~ +100.0	0.1%	0.0	_	0	В	В	В	В	
		H3-08	Signal Level Selection Terminal 14 (Term 14 Signal)	0, 1, 2	1	2	0: (0 - 10 VDC) 1: (-10 +10 VDC) 2: (4 - 20 mA)	x	A	A	A	A	
	Analog Inputs	H3-09	Multi-function Analog Input Terminal 14 (Terminal 14 Sel)	1~1F	1	1F	The function choices for terminal 14 are the same as the choices for terminal 16 [see H3-05], except that [setting 0] "Auxiliary Reference" is not available.	x	A	A	A	A	
		H3-10	Terminal 14 Gain (Terminal 14 Gain)	0.0~ 1000.0	0.1%	100.0	_	0	А	А	Α	А	
		H3-11	Terminal 14 Bias (Terminal 14 Bias)	-100.0 ~ +100.0	0.1%	0.0	_	0	A	A	A	A	
		H3-12	Analog Input Filter Time Constant (Filter Avg Time)	0.00~ 2.00	0.01s	0.00	_	x	A	A	A	A	

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
tp H Terminal Function	Function H4 Analog Outputs	H4-01	Monitor Selection Terminal 21 (Terminal 21 Sel)	1~38	1	2	Analog output selection (terminal 21 (same as F4-01) 1: Frequency reference 2: Output frequency 3: Inverter output current 5: Motor speed 6: Output voltage 7: DC bus voltage 8: Output power 9: Torque reference (internal) 15: External terminal 13 input voltage 16: External terminal 14 input voltage 17: External terminal 16 input voltage 18: Motor secondary current (Iq) 19: Motor excitation current (Id) 20: Primary frequency after SFS 21: Speed controller ASR input 22: Speed controller ASR output 23: Speed deviation 24: PID feedback 26: Voltage reference (Vq out- put) 27: Voltage reference (Vq out- put) 31: Not Used 32: ACR (q) Output 33: ACR (d) Output 36: PID Input <1110> 37: PID Output <1110> 38: PID Reference <1110>	X	В	В	В	В	
		H4-02	Terminal 21 Output Gain (Terminal 21 Gain)	0.00~ 2.50	0.01	1.00	_	0	В	В	В	В	
		H4-03	Terminal 21Output Bias (Terminal 21 Bias)	-10.0~ +10.0	0.0%	0.0	_	0	В	В	В	В	
		H4-04	Terminal 23 Monitor (Terminal 23 Sel)	1~38	1	3	Analog output selection (terminal 23) (same as H4-01)	x	В	В	В	В	
		H4-05	Terminal 23 Output Gain (Terminal 23 Gain)	0.00~ 2.50	0.01	0.50	_	0	В	В	В	В	
		H4-06	Terminal 23 Output Bias (Terminal 23 Bias)	-10.0~ +10.0	0.1%	0.0	_	0	В	В	В	В	
		H4-07	Analog Output Signal Selection (AO Level Select)	0, 1	1	0	0: (0 - +10 VDC) 1: (-10V +10 VDC)	х	В	В	В	В	

								Change	Pa	ameter A	ccess Le	evel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	cation	H5-01	Station Address (Serial Comm Adr)	0~20	1	1F	_	х	А	А	А	Α	
Function	<b>DBUS</b> Communic	H5-02	Communication Speed Selection (Serial Baud Rate)	0~4	0	3	0 : (1200 Baud) 1 : (2400 Baud) 2 : (4800 Baud) 3 : (9600 Baud) 4 : (19200 Baud) <1110>	X	A	A	A	A	
Terminal	Setup M0	H5-03	Communication Parity Selection (Serial Com Sel)	0, 1, 2	1	0	0 : (No Parity) 1 : (Even Parity) 2 : (Odd Parity)	x	A	A	A	A	
Group H	H5 Serial Com	H5-04	Stopping Method After Communica- tion Error (Serial Fault Sel)	0~3	1	3	0: (Ramp to Stop) 1: (Coast to Stop) 2: (Fast - Stop) 3: (Alarm Only)	x	A	A	A	A	
	Function I	H5-05	Timeover Detection (Serial Flt Dtct)	0, 1	1	1	0 : (Disabled) 1 : (Enabled)	х	A	A	A	A	
	Overload	L1-01	Motor Protection Selection (MOL Fault Select )	0, 1	1	1	0: (Disabled) 1: (Coast to Stop)	x	В	В	В	В	
Protection	Function L1 Motor	L1-02	Motor Protection Time Constant (MOL Time Const)	0.1~5.0 min.	0.1 min.	1.0	When O2-09=1 [American Spec] the setting range is 0.1~20min. The factory default setting then becomes 8 min. 8 min. is the operation time from a cold start.	x	В	В	В	В	
		L2-01	Momentary Power Loss Detection (PwrL Selection)	0, 1, 2	1	0	<ul> <li>0 : (Disabled)</li> <li>1 : Power loss ride through (PwrL RideThru t)</li> <li>2 : (CPU Power Active)</li> </ul>	x	В	В	В	В	
	rough	L202	Momentary Power Loss Ride Through (PwrL Ridethru t)	0.0~2.0	0.1s	0.7**	** Factory setting differs depending on inverter capacity (02-04).	x	В	В	В	В	
otection	/er Loss Ride Th	L2-03	Min. Baseblock Time (PwrL Baseblock t)	0.1~5.0	0.1s	0.5*	* Factory setting differs depending on inverter capacity. Lower limit of setting range is changed from 0 to 0.1. <1110>	x	В	В	В	В	
P	ion L2 Pow	L2-04	Voltage Recovery Time (PwrL V/F Ramp t)	0.0~5.0	0.1s	0.3*	* Factory setting differs depending on inverter capacity (02-04).	х	A	A	A	A	
	Funct	L2-05	Undervoltage Detection Level (PUV Det Level)	150~ 210	1V	190*	*Voltage Class 200V class=190V Det level 400V class=190V x 2= 380V level	x	A	A	A	A	
		L2-06	KEB Deceleration Rate (KEB Frequency)	0.0~ 100.0	0.1%	0.0	_	x	A	A	А	A	
								Change	Pa	rameter A	Access Le	evel	
------------	-----------------------------------	------------------	--	------------------	-----------------	--------------------	--	--	-----	-----------------	------------------------	-------------------------	-----------------
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		L3-01	Stall Prevention During Acceleration (StallP Accel Sel)	0, 1, 2	1	1	0: (Disabled) 1: (General Purpose) 2: (Intelligent)	x	В	В	В	-	
		L3-02	Stall Prevention Level During Accel- eration (StallP Accel Lvl)	0~200	1%	150	_	x	В	В	В	-	
		L3-03	Stall Prevention Limit During Accel- eration (StallP CHP Lvl)	0~100	1%	50	_	x	A	A	A	-	
Protection	tion L3 Stall Prevention Function	L3-04	Stall Prevention During Deceleration (StallP Decel Sel)	0, 1, 2, 3	1	1	0: (Disabled) 1: (General Purpose) 2: (Intelligent) <1110> can use setting 2 for all control modes A102=0,1,2,3 3: With braking resistor (Stall prev w/R) When in Vector w/PG A1- 02=3 setting 3 cannot be set with braking resistor and with stall prevention.	x	В	В	В	В	
	Funct	L3-05	Stall Prevention Selection during Running (StallP Run Sel)	0, 1, 2	1	1	0: (Disabled) 1: (Decel Time 1) C1-02 2: (Decel Time 2) C1-04	x	В	В	-	-	
		L3-06	Stall Prevention Level during Running (StallP Run Level)	30~200	1%	160	_	x	В	В	-	-	
		L3-07	Stall Prevention Function P Gain (StallP Gain)	0.10~ 2.00	0.01	1.00	_	x	F	F	-	-	
		L3-08	Stall Prevention Function Integral Time (StallP Intg Time)	10~250	1 ms	100	_	x	F	F	-	-	

								Change	Pa	rameter A	ccess Le	vel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	ſ	L4-01	Frequency Detection Level (Spd Agree Level)	0.0~ 400.0	0.1Hz	0.0	_	x	В	В	В	В	
	e Detectio	L4-02	Frequency Detection Width (Spd Agree Width)	0.0~ 20.0	0.1Hz	2.0	_	х	В	В	В	В	
	Reference	L4-03	Frequency Detection Level ± (Spd Agree Lvl ±)	-400.0 ~ +400.0	0.1Hz	0.0	_	х	A	A	A	A	
	unction L4	L4-04	Frequency Detection Width ± (Spd Agree Wdth ±)	0.0~ 20.0	0.1Hz	2.0	_	х	A	A	A	A	
	LL.	L4-05	Frequency Loss Detection Selection (Ref Loss Sel)	0, 1	1	0	0: (Stop) 1: (Run@ 80% PrevRef)	х	A	A	A	A	
	ult Restart	L5-01	Number of Auto Restart Attempts (Num of Restarts)	0~10	1	0	_	х	В	В	В	В	
Protection	Function L5 Fai	L5-02	Auto Restart Operation Selection (Restart Sel)	0, 1	1	0	0: (No Flt Relay) 1: (Flt Relay Active)	x	В	В	В	В	
	Function L6 Torque Detection	L6-01	Overtorque Detection Selection 1 (Torq Det 1 Sel)	0~4	1	0	<ul> <li>0: (Disabled)</li> <li>1: (@SpdAgree - Alm) Detected during speed agree only. Operation con- tinues after detection and OL3 flashes on display.</li> <li>2: (At RUN - Alarm) Overtorque detection during running. Operation contin- ues after detection and OL3 flashes on the display.</li> <li>3: (@SpdAgree - Flt) Detected during the speed agree only. Inverter trips on OL3, output is shut OFF.</li> <li>4: (At RUN - Fault) Detected during running, and the inverter trips on OL3. Output is shut OFF.</li> </ul>	x	В	В	В	В	

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		L6-02	Overtorque Detection Level 1 (Torq Det 1 Lvl)	0~300	1%	150	_	x	В	В	В	В	
		L6-03	Overtorque Detection Time 1 (Torq Det 1 Time )	0.0~ 10.0	0.1s	0.1	_	x	В	В	В	В	
Protection	Function L6 Torque Detection	L6-04	Overtorque Detection Selection 2 (Torq Det 2 Sel)	0~4	1	0	<ul> <li>0: (Disabled)</li> <li>1: (@SpdAgree - Alm) Detected during speed agree only. Operation con- tinues after detection and OL4 flashes on display.</li> <li>2: (At RUN - Alarm) Overtorque detection during running. Operation contin- ues after detection and OL4 flashes on the display.</li> <li>3: (@SpdAgree - Flt) Detected during the speed agree only. Inverter trips on OL4, output is shut OFF.</li> <li>4: (At RUN - Fault) Detected during running, and the inverter trips on OL4. Output is shut OFF.</li> </ul>	X	A	A	A	A	
		L6-05	Overtorque Detection Level 2 (Torq Det 2 Lvl)	0~300	1%	150	_	x	A	A	A	A	
		L6-06	Overtorque Detection Time 2 (Torq Det 2 Time)	0.0~ 10.0	0.1s	0.1	_	x	A	A	A	A	
	nit	L7-01	Forward Torque Limit (Torq Limit Fwd)	0~300	1%	200	_	x	-	-	В	В	
	Torque Lin	L7-02	Reverse Torque Limit (Torq Limit Rev)	0~300	1%	200	_	x	-	-	В	В	
	Inction L7	L7-03	Forward Regenera- tive Torque Limit (Torq Lmt Fwd Rgn)	0~300	1%	200	_	x	-	-	В	В	
	ΕL	L7-04	Reverse Regenera- tive Torque Limit (Torq Lmt Rev Rgn)	0~300	1%	200	_	x	-	-	В	В	

								Change	Pa	rameter A	ccess Le	vel	
Fu	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation O: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
		L8-01	Internal DB Resistor Protection Selection (DB Resistor Prot)	0, 1	1	0	0: (Not Provided) 1: (Provided)	x	В	В	В	В	
	Protection	L8-02	Overheat Pre-alarm Level (OH Pre-Alarm Lvl)	50~130	1 deg C	95 C*	*Factory setting depends on inverter model [02-04].	x	A	A	A	A	
Protection	tion L8 Hardware	L8-03	Operation Selec- tion after OH Pre- alarm (OH Pre-Alarm Sel)	0~3	1	3	0: (Ramp to Stop) using C1-02 1: (Coast to Stop) 2: (Fast-Stop) using C1-09 3: (Alarm Only) display flashes OH Heatsink Ovrtemp	x	A	A	A	A	
	Fund	L8-05	Input Phase Loss Protection (PH Loss In Sel)	0, 1	1	0	0: (Disabled) 1: (Enabled)	x	A	A	A	A	
		L8-07	Output Phase Loss Protection (PH Loss Out Sel)	0, 1	1	0*	0: (Disabled) 1: (Enabled) *When 02-09=1, the factory default setting is 1.	x	A	A	A	A	
		L8-10	Short-circuit Protection Selection (Ground Fault Sel)	0, 1	1	1	0: (Disabled) 1: (Enabled)	x	A	A	A	A	
Protection	Function L8 Hardware Protection	L8-17	IGBT Protection Selection at Low Frequency (Prtct@L - Spd)	0, 1	1	1*	<ul> <li>0: Conventional</li> <li>1: (Lower fc) Carrier frequency is decreased when fout</li> <li>10Hz and the load is &gt;</li> <li>100% iac.</li> <li>2: (Short term OL2) OL occurs after 2 seconds during low speed [fout £ 6Hz] current limit.</li> <li>3: (I-Limit=150%) Current limit is set to 150% of the inverter rated current.</li> <li>&lt; G5 plus &gt; Addition</li> <li>* When 02-09=1 factory set- ting is 1.</li> <li>* When 02-09=2 factory set- ting is 2.</li> </ul>	X	A	A	A	-	
		<b>L8-19</b> <1110>	OL2 Characteris- tics Selection at Low Speed (OL2 Chara@L- Spd)	0, 1	1	0	0: (Disabled) Low frequency OL disabled 1: (Enabled) Low frequency OL enabled	x	A	A	A	A	

								Change	Pa	rameter A	Access Le	vel	
Fur	nction	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
Operator	Function of Monitor Selection	O1-01	Monitor Selection (User Monitor Sel)	4~39	1	6	Monitor selection 4: Control method 5: Motor speed 6: Output voltage 7: DC bus voltage 8: Output power 9: Torque reference (internal) 10: Input terminal status 11: Output terminal status 12: Internal Control Status 1 13: Elapsed time 14: Flash software ID number 15: External terminal 13 input voltage 16: External terminal 14 input voltage 17: External terminal 16 input voltage 18: Motor secondary current (Iq) 19: Motor excitation current (Id) 20: Primary frequency after SFS 21: Speed controller ASR input 22: Speed controller ASR output 23: Speed deviation 24: PID feedback 25: DI-16 reference 26: Voltage reference (Vq out- put) 27: Voltage reference (Vd out put) 28: CPU ID number	0	В	В	В	В	
	lections	01-02	Monitor Selection after Power Up (Power- On Moni- tor)	1~4	1	1	1: (Frequency Ref) 2: (Output Freq) 3: (Output Current) 4: (User Monitor)	0	В	В	В	В	
	ion o2 Key Sel	O1-03	Frequency Units of Reference Setting and Monitor (Display Scaling)	0~ 39999	1	0	_	x	В	В	В	В	
	Funct	01-04	(Display Units)	0, 1	1	0	0: (Hertz) 1: (RPM)	х	-	-	-	В	
		O1-05	Parameter No. Dis- play Selection (Address Display)	0, 1	1	0	0: (Parameter Number) 1: (Memobus Address)	х	A	A	A	A	
		O2-01	LOCAL/REMOTE Key Enable/Disable (Local/Remote Key)	0, 1	1	1	0: (Disabled) 1: (Enabled)	х	В	В	В	В	
		O2-02	STOP Key Func- tion Selection (Oper STOP Key)	0, 1	1	1	<ul><li>0: (Disabled) When the inverter is operated from the digital operator.</li><li>1: (Enabled) Always enabled.</li></ul>	x	В	В	В	В	

							Change	Pa	rameter A	Access Le	vel	
Function	Parameter No.	Name (Digital Operator Display)	Setting Range	Setting Unit	Factory Setting	Remarks (Digital Operator Display)	during Operation o: Enabled x: Disabled	V/f	V/f w/ PG	Open Loop Vector	Close Loop Vector	User Setting
	02-03	User Parameter Ini- tialization Selection (User Defaults)	0, 1, 2	1	0	0: (No Change) Micno default values used 1: (Set Defaults) Sets user specified value as default. 2: (Clear All) Clears user defaults	x	В	В	В	В	
	O2-04	kVA Selection (Inverter Model #)	0~FF	1	_*	<ul> <li>Not initialized. Sets the inverter capacity according to the model number.</li> </ul>	х	В	В	В	В	
	O2-05	Frequency Refer- ence Setting Method Selection (Operator M.O.P.)	0, 1	1	0	0: (Disabled) 1: (Enabled)	x	A	A	A	A	
Operator nction o2 Key Selection	O2-06	Operation Selec- tion When Digital Operator is Discon- nected (Oper Detection)	0, 1	1	0*	<ol> <li>O: (Disabled) Operation continues even if the digital operator is disconnected.</li> <li>(Enabled) Inverter fault when the digital operator is disconnected.</li> <li>* When 02-09=1, the value is 1.</li> </ol>	x	A	A	A	A	
ШЦ	O2-07	Elapsed Timer Setting (Elapsed Time Set)	0~ 65535	1 hour	_	_	x	A	A	A	A	
	O2-08	Elapsed Timer Selection (Elapsed Time Run)	0, 1	1	0	0: (Power - On Time) 1: (Running Time)	x	A	A	A	A	
	O2-09	Initialization Mode Selection (Init Mode Sel)	0~3	1	0	0: (Japanese spec) 1: (American spec) 2: (European spec) 3: (OMRON spec) When 02-09 = 1 or 2, it is added by <1032>. When 02-09 = 0 or 3, it is added by <1040>.	x	A	A	А	A	

# Monitor Display (Un-XX)

					Analog	Par	ameter A	Access L	evel
Functior	Parameter No.	Name (Digital Operator Display)	Min. Unit	Description	Monitor Output Level	V/f	V/f w/ PG	Vector w/o PG	Vector w/ PG
	U1-01	Frequency Reference (Frequency Ref)	0.01Hz	The unit differs depending on O1-03 setting.	10V/Max. output frequency	Q	Q	Q	Q
	U1-02	Output Frequency (Output Freq)	0.01Hz	The unit differs depending on O1-03 setting.	10V/Max. output frequency	Q	Q	Q	Q
	U1-03	Output Current (Output Current)	0.1A	Minimum unit is 0.01 A for 7.5 kW or less.	10V/Inverter rated current	Q	Q	Q	Q
Monitor	U1-04	Control Method* (Control Method)	_	0: V/f control 1: V/f control with PG 2: Vector control without PG 3: Vector control with PG	_	Q	Q	Q	Q
	U1-05	Motor Speed (Motor Speed)	0.01Hz	The unit differs depending on O1-03 setting.	10V/Max. Output frequency	х	Q	Q	Q
	U1-06	Output Voltage (Output Voltage)	0.1V	_	10V/200V or 400V	Q	Q	Q	Q
	U1-07	DC Bus Voltage V (DC Bus Voltage)	1V	_	10V/400V or 800V	Q	Q	Q	Q
	U1-08	Output Power (Output kWatts)	0.1kW	_	10V/Inverter capacity (kW)	Q	Q	Q	Q
	U1-09	Torque Reference (Torque Reference)	0.1%	_	10V/Motor rated torque	х	х	Q	Q
Monitor	U1-10	Input Terminal Status* (Input Term Sts)	_	0       0	_	Q	Q	Q	Q
	U1-11	Output Terminal Status* (Output Term Sts)		0       0       0       0       0       0       0         1:       T25 "Closed"       1:       T25 "Closed"         1:       T26 "Closed"       0:       Not used         0:       Not used       0:       Not used         0:       Not used       0:       Not used         1:       Fault       1:       Fault		Q	Q	Q	Q

\* Cannot be changed by U1-04

					A	Par	ameter A	Access L	.evel
Function	Parameter No.	Name (Digital Operator Display)	Min. Unit	Description	Analog Monitor Output Level	V/f	V/f w/ PG	Vector w/o PG	Vector w/ PG
	U1-12	Operation Status* (Int Ctl Sts 1)	_	0       0       0       0       0       0         -1:       During reverse       -1:       During reverse         1:       During reset signal input         1:       During speed agree         1:       Inverter operation ready         1:       Major fault	_	Q	Q	Q	Q
	U1-13	Elapsed Time* (Elapsed Time)	1 hour	_	_	Q	Q	Q	Q
	U1-14	Software No. at FLASH Side* (FLASH ID)	_	_	_	Q	Q	Q	Q
	U1-15	Control Circuit Terminal 13 (Term 13 Level)	0.1%	_	10V/10V	В	В	В	В
Monitor	U1-16	Control Circuit Terminal 14 Input Voltage (Term 14 Level)	0.1%	_	10V/10V or 20 mA	В	В	В	В
	U1-17	Control Circuit Terminal 16 Input (Terminal 16 Level)	0.1%	_	10V/10V	В	В	В	В
	U1-18	Motor Secondary Current (Iq) (Mot SEC Current)	0.1%	_	10V/Motor rated primary current	В	В	В	В
	U1-19	Motor Excitation Current (Mot EXC Cur- rent)	0.1%	_	10V/Motor rated primary current	x	x	В	В
	U1-20	Output Frequency after Soft-start (SFS Output)	0.01Hz	_	10V/Max. output frequency	A	A	A	A
	U1-21	ASR Input (ASR Input)	0.01%	_	10V/Max. output frequency	х	A	x	A
	U1-22	ASR Output (ASR Output)	0.01%	Analog monitor output level becomes 10V/Max. out- put frequency for V/f control mode with PG.	10V/Motor rated primary current	X	A	X	A
	U1-23	Speed Deviation (Speed Deviation)	0.01%	_	10V/Max. output Frequency	х	A	x	A
	U1-24	PID Feedback Capacity (PID Feedback)	0.01%	-	10V/Max. output Frequency	A	A	A	A

\* Cannot be changed by U1-04

_					Analog	Par	ameter A	Access L	evel
Functior	Parameter No.	Name (Digital Operator Display)	Min. Unit	Description	Monitor Output Level	V/f	V/f w/ PG	Vector w/o PG	Vector w/ PG
	U1-25	D1-16H Input Status* (DI-16 Reference)	_	Displays input value according to F3-01 setting. For example: When lower 8 bit is ON, Binary selection: 256, BCD selection: 99	_	A	A	A	A
	U1-26	Output Voltage Refer- ence Vq (Voltage Ref (Vq))	0.1V	_	10V/200V or 400V	x	х	A	A
	U1-27	Output Voltage Reference Vd (Voltage Ref (Vd))	0.1V	_	10V/200V or 400V	x	x	A	A
	U1-28	Software No. at CPU Side* (CPU ID)	_	_	_	A	A	A	A
	U1-32	ACR (q) Output (ACR (q) Output)	0.1%	_	_	х	х	А	А
J	U1-33	ACR (d) Output (ACR (d) Output)	0.1%	_	_	х	х	А	А
Monit	U1-34	OPE Detection Parameter* (OPE Detected)	_	_	_	A	A	A	A
	U1-35	No. of O Servo Moving Pulses (Zero Servo Pulse)	1	_	_	x	х	х	A
	<b>U1-36</b> <1110>	PID Deviation (PID Input)	0.01%	PID reference + PID reference bias – PID feedback capacity	10V/Max. Output Fre- quency	A	A	A	A
	<b>U1-37</b> <1110>	PID Output Capacity (PID Output)	0.01%	PID output capacity	10V/Max. Output Fre- quency	A	A	A	A
	<b>U1-38</b> <1110>	PID Reference (PID Setpoint)	0.01%	PID reference + PID reference bias	10V/Max. Output Fre- quency	A	A	A	A
	<b>U1-39</b> <1110>	Temperature for Cooling Fin (Heatsink Temp)	1 C	_	_	F	F	F	F

\* Cannot be changed by U1-04

_					Analog	Par	ameter A	Access L	evel
Functior	Parameter No.	Name (Digital Operator Display)	Min. Unit	Description	Monitor Output Level	V/f	V/f w/ PG	Vector w/o PG	Vector w/ PG
	U2-01	Current Fault (Current Fault)	_	_	_	Q	Q	Q	Q
	U2-02	Last Fault (Last Fault)	_	_	_	Q	Q	Q	Q
	U2-03	Frequency Reference at Fault (Frequency Ref)	0.01Hz	_	_	Q	Q	Q	Q
	U2-04	Output Frequency at Fault (Output Freq)	0.01Hz	_	—	Q	Q	Q	Q
	U2-05	Output Current at Fault (Output Current)	0.1A	_	_	Q	Q	Q	Q
	U2-06	Motor Speed at Fault (Motor Speed)	0.01Hz	_	_	х	Q	Q	Q
ault Trace	U2-07	Output Voltage Refer- ence at Fault (Output Voltages)	0.1V	_	_	Q	Q	Q	Q
n U2 F	U2-08	DC Bus Voltage at Fault (DC Bus Voltage)	1V	_	_	Q	Q	Q	Q
Functio	U2-09	Output Power at Fault (Output kWatts)	0.1kW	_	_	Q	Q	Q	Q
	U2-10	Torque Reference at Fault (Torque Reference)	0.1%	_	_	х	Х	Q	Q
	U2-11	Input Terminal Status at Fault (Input Term Sts)	_	Displays the same status as the U1-10.	_	Q	Q	Q	Q
	U2-12	Output Terminal Status at Fault (Output Term Sts)	_	Displays the same status as the U1-11.	_	Q	Q	Q	Q
	U2-13	Operation Status at Fault (Inverter Status)	_	Displays the same status as the U1-12.	_	Q	Q	Q	Q
	U2-14	Elapsed Operation Time at Fault (Elapsed Time)	1 hour	_	_	Q	Q	Q	Q

_					Analog	Par	ameter A	Access L	evel
Functior	Parameter No.	Name (Digital Operator Display)	Min. Unit	Description	Monitor Output Level	V/f	V/f w/ PG	Vector w/o PG	Vector w/ PG
	U3-01	Most Recent Fault (Last Fault)	_	_	_	Q	Q	Q	Q
	U3-02	Second Most Recent Fault (Fault Message 2)	_	_	_	Q	Q	Q	Q
	U3-03	Third Most Recent Fault (Fault Message 3)	_	_	_	Q	Q	Q	Q
History	U3-04	Fourth/oldest Fault (Fault Message 4)	_	_	_	Q	Q	Q	Q
n U3 Fault	U3-05	Elapsed Operation Time at Fault (Elapsed Time 1)	1 hour	_	_	Q	Q	Q	Q
Functio	U3-06	Elapsed Time of Second Fault (Elapsed Time 2)	1 hour	_	_	Q	Q	Q	Q
	U3-07	Elapsed Time of Third Fault (Elapsed Time 3)	1 hour	_	_	Q	Q	Q	Q
	U3-08	Elapsed Time of Fourth/ oldest Fault (Elapsed Time 4)	1 hour	_	_	Q	Q	Q	Q

## **Chapter 8 Maintenance & Trouble Shooting**

### 8.1 Maintenance & Inspection

This section describes basic maintenance and inspection procedures for the KE200 inverter.

#### **Periodic Inspection**

The KE200 inverter will function longer if it is kept clean, cool and dry, and if all precautions highlighted in this manual are observed. Periodically inspect the inverter as described in the table below to prevent accidents and to ensure high performance with high reliability.

To prevent electrical shock, disconnect all power before servicing the inverter. Then wait at least five minutes after the power supply is disconnected and all LEDs are extinguished.

Component	Check	Corrective Action
External Terminals, Connectors, Mounting Screws, etc.	Loose screws or connectors	Securely tighten.
Heatsink	Build-up of dust and dirt	Blow with dry, compressed air [39.2 $10^4$ to 58.8 $10^4$ Pa (4 to 6kg $\cdot$ cm <sup>2</sup> ) pressure].
Printed Circuit Board (PCB)	Accumulation of conductive dust or oil	Blow with dry, compressed air [39.2 $10^4$ to 58.8 $10^4$ Pa (4 to 6kg·cm <sup>2</sup> ) pressure]. If dust and oil cannot be removed, replace the board.
Cooling Fan	For abnormal noise and vibration	Replace the cooling fan.
Power Components	Accumulation of dust and dirt	Blow with dry, compressed air [39.2 $10^4$ to 58.8 $10^4$ Pa (4 to 6kg·cm2) pressure].
Smoothing Capacitor	Discoloration or odor	Replace the capacitor or the inverter.

### 8.2 Alarm & Fault Displays

This section describes the alarm and fault displays, explanations for fault conditions, and corrective actions to be taken if the KE200 inverter malfunctions.

#### **Inverter Alarms & Faults**

When the KE200 inverter detects a fault, the fault is displayed on the digital operator and activates a fault contact output, after which the motor coasts to a stop. Check the causes listed in the table below and take the corresponding corrective actions. To restart the inverter, remove any run command and turn ON the reset input signal or depress the RESET key on the digital operator, or cycle power to reset the stop status. If taking the corrective actions described does not solve the problem, contact your Micno representative immediately.

Unlike faults, alarms do not activate fault contact outputs. After the cause of the alarm is corrected, the inverter returns to its former operation status automatically.

Fault Diagnosis and Corrective Actions

Fault Display	Name	Description	Corrective Action	Class
UV1 DC Bus Undervolt	Main circuit undervoltage (PUV)	Undervoltage in the DC main circuit during running. <u>Detection level</u> 230 V class: Approx. 190 V or less 460 V class: Approx. 380 V or less	• Check the power supply wir-	A
UV2 CTL PS Undervolt	Control circuit under- voltage (CUV)	Undervoltage in the control circuit dur- ing running.	· Correct the line voltage	A
UV3 MC Answerback	MC fault	The pre-charge contactor opened dur- ing running.		А
UV Under Voltage	Momentary power loss	<ul> <li>The main circuit DC voltage fell below the PUV level.</li> <li>The control power source fell below the CUV level.</li> <li>The pre-charge contactor opened.</li> </ul>		В
OC Overcurrent	Overcurrent (OC)	The inverter output current exceeded the OC level.	<ul> <li>Check the motor coil resistance.</li> <li>Extend the accel/decel time.</li> <li>Check the motor insulation.</li> <li>Multi-meter check.</li> </ul>	A
GF Ground Fault	Ground fault (GF)	Inverter output grounding current exceeded 50% of inverter rated cur- rent.	Check that motor insulation has not deteriorated.     Check that connection between inverter and motor is not damaged.	A

Fault Display	Name	Description	Corrective Action	Class
OV Overvoltage	Overvoltage (OV)	The main circuit direct current voltage exceeded the OV level. <u>Detection level</u> 230 V class: Approx. 410 V 460 V class: Approx. 820 V	Extend the deceleration time, add braking circuit.	A
SC Short Circuit	Load short-circuit (SC)	Inverter output (load) is short-circuited.	<ul> <li>Check the motor coil resistance.</li> <li>Check the motor installation.</li> </ul>	A
PUF DC Bus Fuse Open	Fuse blown (FU)	<ul> <li>The DC bus fuse is blown.</li> <li>The output transistors were damaged.</li> </ul>	Check for damaged transis- tor, load side short circuit, grounding, etc.	A
OH Heatsink Over tmp	Heatsink overheat (OH1)	The transistor heatsink temperature exceeded the allowable value.	Check the fan and ambient temperature.	Α
OL1 Motor Overloaded	Motor overload (OL1)	Inverter output exceeded the motor overload level.	Reduce the load.	А
OL2 Inv Overloaded	Inverter overload (OL2)	Inverter output exceeded the inverter overload level.	Reduce the load, extend the acceleration time.	А
PF Input Pha Loss	Input open-phase	Inverter input power supply has open phase. Large unbalanœ in input voltage.	Check the line voltage.     Re-tighten the input terminal screws.	A
LF Output Pha Loss	Output open-phase	Inverter output has open-phase.	<ul> <li>Check the output wiring.</li> <li>Check the motor impedance.</li> <li>Re-tighten the output terminal screws.</li> </ul>	A
RR Dyn Brk Transistr	Braking transistor fail- ure	The braking transistor has failed.	The inverter requires repair.	А
RH Dyn Brk Resistor	Braking resistor unit overheat	The braking resistor unit temperature has exceeded the allowable value. (Protects only inverter built-in type)	Reduce the regenerative load.	A
OS Over speed	Overspeed (OS)	The motor speed exceeded the over- speed level.		Α
PGO PG open	PG open circuit (PGO)	The PG line is broken.	·Check the PG line. ·Check the condition of the motor lock or the load.	A
DEV Speed Deviation	Speed deviation (DEV)	The deviation of the speed reference and speed feedback exceeded the regulation level.	Check the load.	В
EF External Fault	Simultaneous forward/ reverse run commands	Both FWD and REV run commands are simultaneously input for 500ms or longer.	Check sequence circuit.	В
BB Base Block	External baseblock	External baseblock command is input from control circuit terminal.	Check sequence circuit.	В

Fault Display	Name	Description	Corrective Action	Class
EF3 External Fault 3	External fault at terminal 3	Fault occurred in the external control circuit.	Check the condition of the input terminal. If the LED lights when terminal is not connected, then the inverter requires repair.	A
EF4 External Fault 4	External fault at terminal 4			
EF5 External Fault 5	External fault at terminal 5		Check the condition of the	
EF6 External Fault 6	External fault at terminal 6	Fault occurred in the external control lights when terminal is the lights when terminal is the		В
EF7 External Fault 7	External fault at terminal 7		requires repair.	
EF8 External Fault 8	External fault at terminal 8			
OPE01 kVA Selection	kVA setting error (OPE01)	Inverter kVA setting error.	Check and set the parameter data (O2-04).	С
OPE02 Limit	Parameter setting range error (OPE02)	Parameter data is out of range.	Check the parameter data settings.	С
OPE03 Terminal	Multi-function input setting error (OPE03)	<ul> <li>Multi-function input settings in H1-01 to H1-06 are not in ascending order.</li> <li>Or, set values other than "F" are over- lapping.</li> </ul>	Check the function selection.	С
OPE10 V/f	V/f data setting error ( <i>E1-04</i> to <i>E1-10</i> )	V/f data is set such that the following equation is <i>not</i> satisfied: <i>E1-04 E1-06 &gt; E1-07 E1-09</i>	Check the parameter data settings.	С
OPE11 FC/ On-Dly	Parameter setting error	When one of the following setting errors occurs: • Carrier frequency upper limit (C6-01) > 5kHz, and Carrier frequency lower limit (C6-02) 5kHz • Carrier frequency proportional gain (C6-03) > 6 and (C6-01) < (C6-02)	Check the parameter data settings.	С
ERR EEPROM R/W Err	EEPROM writing fault (ERR)	EEPROM internal data did not match when initializing the parameter.	Replace the control board.	В
CALL Serial Com Call	SI-B transmission error	Control data was not received correctly when power supply was turned ON.	Check transmission devices and transmission signals.	С
CE Memobus Com Err	Transmission error	Control data was not received correctly when power supply was turned ON.	Check transmission devices and transmission signals.	A

Fault Display	Name	Description	Corrective Action	Class
CPF00 COM-ERR(OP&INV)	Control circuit fault 1 (CPF00) Digital perator trans- mission fault	<ul> <li>Transmission between the inverter and digital operator cannot be estab- lished 5 seconds after supplying power.</li> <li>MPU peripheral element check fault (on-line)</li> </ul>	<ul> <li>Insert the operator connector again.</li> <li>Check the wiring of control circuit.</li> <li>Replace the control board.</li> </ul>	A
CPF01 COM-ERR(OP&INV)	Control circuit fault 2 (CPF01) Digital perator trans- mission fault	<ul> <li>Transmission between the inverter and digital operator is established once after supplying power, but later transmission fault continues for more than 2 seconds.</li> <li>MPU peripheral element check fault (on-line).</li> </ul>	<ul> <li>Insert the digital operator connector again.</li> <li>Check the digital control cir- cuit wiring.</li> <li>Replace the control board.</li> </ul>	A
CPF02 BB Circuit Err	Baseblock circuit fault (CPF02)			А
CPF03 EEPROM Error	EEPROM fault (CPF03)	Invertor DCP control board fault	Poplace the control beard	A
CPF04 Internal A/D Err	CPU internal A/D con- verter fault (CPF04)	- Inverter PCB control board fault. Replace the control boar		А
CPF05 External A/D Err	CPU external A/D con- verter fault (CPF05)			А
CPF06 Option Error	Option connection fault (CPF06)	The option card is not installed cor- rectly.	Install the option card again.	А
CPF20 Option A/D Error	A/D converter fault in analog speed refer- ence card (CPF20)	Option card (AI-14B) A/D converter fault	Replace the option card.	A

Classes are described as follows:

- A: Major fault. Motor coasts to stop, operation indicator illuminates, and fault contact output (terminals 18 & 19) is activated.
- B: Fault. Operation continues, operation indicator illuminates, and multi-function fault signal is output (when multi-function output is selected). Fault contact output is *not* activated.
- C: Alarm (warning). Operation cannot be performed, and operation indicator illuminates, but *no* fault signal is output.



### Motor Faults

If a motor fault occurs, follow the checkpoints listed in the table below and take the corresponding cor- rective actions. If taking the corrective actions described does not solve the problem, contact your Micno representative immediately.

### Motor Faults and Corrective Actions

Fault	Check Point	Corrective Action
	Power supply voltage applied to power supply ter- minals L1, L2, L3? Charge LED is ON?	<ul> <li>Turn ON power supply.</li> <li>Turn OFF power supply, and then ON again.</li> <li>Check power supply voltage.</li> <li>Make sure terminal screws are tight.</li> </ul>
Matar daga pat ratata	Use rectifier type voltmeter to test. Voltage output to output terminals T1, T2, T3 correct?	Turn OFF power supply, then turn ON again.
	Motor locks due to excessive load?	Reduce the load and release the lock.
	Fault displayed in operator display?	Check troubleshooting table on page 64.
	FWD or REV run command entered?	Check the wiring.
	Frequency setting voltage entered (when using terminals 13 or 14)?	·Check the wiring. ·Check frequency setting voltage.
	Are reference and run source settings correct?	Check reference and run source selections (B1-01, B1-02).
Motor rotation reverses	Wiring of terminals T1, T2, T3 correct?	Match wiring to the phase order of the motor leads T1, T2, T3.
	FWD and REV wiring run signals entered?	Correct the wiring.
Motor rotates, but vari- able speed not avail- able.	Wiring of frequency setting circuit correct?	Correct the wiring.
	Are reference and run source settings correct?	Check reference and run source selections ( <i>B1-01</i> , <i>B1-02</i> ).
	Load excessively large?	Reduce the load.
	Motor ratings (number of poles, voltage) correct?	Check motor nameplate specifications.
Motor rpm too high or	Accel/decel speed change ratio for gears, etc. correct?	Check speed changer (gears, etc.)
too low	Maximum frequency set value correct?	Check the maximum frequency set value.
	Use rectifier voltmeter. Voltage between motor terminals not excessively reduced?	Check V/f characteristics values.
Motor rpm not stable during operation	Load excessively large?	Reduce the load.
	Load variation excessively large?	·Reduce the load variation. ·Increase inverter motor capacity.
	3-phase or single-phase power supply used? For 3-phase power supply, open phase?	<ul> <li>For 3-phase power supply, check the wiring if power supply is open phase.</li> <li>For single-phase power supply, connect AC reactor to the power supply.</li> </ul>

## **Chapter 9 MODBUS Communication Protocol**

KE200 series inverter provides RS485 communication interface, and adopts MODBUS communication protocol. User can realize centralized monitoring through PC/PLC, host computer, and also can set inverter's operating commands, modify or read function parameters, read operating status and fault information, etc.



### 9.1 About Protocol

This serial communication protocol defines the transmission information and use format in the series communication. It includes the formats of master-polling, broadcast and slave response frame, and master coding method with the content including slave address (or broadcast address), command, transmitting data and error checking. The response of slave adopts the same structure, including action confirmation, returning the data and error checking etc. If slave takes place the error while it is receiving the information or cannot finish the action demanded by master, it will send one fault signal to master as a response.

### 9.2 Application Method

The inverter could be connected into a "Single-master Multi-slave" PC/PLC control network with RS485 bus.



### 9.3 Bus Structure

- (1) Interface mode RS485
- (2) Transmission mode

There provide asynchronous series and half-duplex transmission mode. At the same time, just one can send the data and the other only receives the data between master and slave. In the series asynchronous

communication, the data is sent out frame by frame in the form of message.

#### (3) Topological structure

In Single-master Multi-slave system, the setup range of slave address is 0 to 247. 0 refers to broadcast communication address. The address of slave must be exclusive in the network. That is basic condition of MODBUS communication.

### 9.4 Protocol Description

KE200 series inverter communication protocol is a kind of asynchronous serial master-slave communication protocol. In the network, only one equipment (master) can build a protocol (Named as "Inquiry/Command"). Other equipment (slave) response "Inquiry/Command" of master only by providing the data, or doing the action according to the master's "Inquiry/Command". Here, master is Personnel Computer, Industrial control equipment or Programmable logical controller, and the slave is inverter or other communication equipment with the same communication protocol. Master not only can visit some slave separately for communication, but also sends the broadcast information to all the slaves. For the single "Inquiry/Command" of master, slave needs not feedback a response to master.

The parameter of H5-01~H5-05 should be set correct before build the communication with the host machine. H5-01~H5-03 should be reset after switching on the power of KE200.

It should be pay more attention that when you set the communication parameters by the operator, after setting, the power supply of KE200 should be switched off and then switched on, and then the setting will be effective. The communication parameters are listed as below:

Parameters code	Name	Setting range	Minimum setting	Default	Remark
B1-01	Reference Selection (Reference Source)	0~4	0	1	0: Operator 1: Terminals 2: Communication (Serial Com) 3: Communication (Serial Com)
B1-02	Operation Command Selection (Run Source)	0~4	0	1	0: Operator 1: Terminals 2: Communication (Serial Com) 3: Communication (Serial Com)
H5-01	Station Address (Serial Comm Adr)	0~20	0	1F	KE200 Adr
H5-02	Communication Speed Selection (Serial Baud Rate)	0~4	0	3	0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS
H5-03	Communication Parity Selection (Serial Com Sel)	0,1,2	0	1	0: No Parity 1: Even Parity 2: Odd Parity
H5-04	Stopping Method After Communication Error (Serial Fault Sel)	0~3	0	1	0: Ramp To Stop 1: Coast to Stop 2: Fast – Stop 3: Alarm Only
H5-05	Timeover Detection (Serial Flt Dtct)	0.1	0	1	0: Disabled 1: Enabled

#### 9.5 Communication Data Structure

MODBUS protocol communication data format of MICNO series inverter is shown as following:

In RTU mode, the Modbus minimum idle time between frames should be no less than 3.5 bytes. The checksum adopts CRC-16 method. All data except checksum itself sent will be counted into the calculation. Please refer to section: CRC Check for more information. Note that at least 3.5 bytes of Modbus idle time should be kept and the start and end idle time need not be summed up to it.

The entire message frame must be transmitted as a continuous data stream. If a idle time is more than 1.5 bytes before completion of the frame, the receiving device flushes the incomplete message and assumes that the next byte will be the address field of a new message. Similarly, if a new message begins earlier than 3.5 bytes interval following a previous message, the receiving device will consider it as a continuation of the previous message. Because of the frame's confusion, at last the CRC value is incorrect and communication fault will occur.

START	Transmission time of 3.5 bytes
Slave Address	Communication addr. : 0 to 247
Command Code	03H:Read slave parameters 06H: Write slave parameters
DATA (N-1)	Data:
DATA (N-2)	Function code parameter address, the number of
	function code parameter, Function code parameter,
DATA0	etc.
CRC Low byte	
CRC High byte	Detection value: CRC value
END	Transmission time of 3.5 bytes

#### 9.6 Command Code and Communication Data Description

**9.6.1 Command code**: 03H (0000 0011), reads N words. (There are 16 characters can be read at the most.)

For example: The inverter start address 0026H (DC Bus Voltage) of the slave 01 (H5-01=1) continuously reads two consecutive values.

Master command information

START	T1-T2-T3-T4 (Transmission time of 3.5 words)
Address	01H
Command Code	03H
Start Address High byte	00H
Start Address Low byte	26H
Data Number High byte	00H
Data Number Low byte	02H
CRC CHK Low byte	25H
CRC CHK High byte	СОН
END	T1-T2-T3-T4 (Transmission time of 3.5 words)



Slave responding information

START	T1-T2-T3-T4 (Transmission time of 3.5 words)
Address	01H
Command Code	03H
Byte Number	04H
Data Address 0004H High byte	02H
Data Address 0004H Low byte	4DH
Data Address 0005H High byte	00H
Data Address 0005H Low byte	00H
CRC CHK Low byte	6BH
CRC CHK High byte	9CH
END	T1-T2-T3-T4 (Transmission time of 3.5 words)

#### 9.6.2 Command code: 10H (0001 0000) , write a word

For example: Write 0001H into address 0000H (communication start-up address of KE200), slave address 01H (H5-01=1).

Master command information

START	T1-T2-T3-T4 (Transmission time of 3.5 words)
Address	01H
Command Code	10H
Write Data Start Address High byte	00H
Write Data Start Address Low byte	00H
Write Data Number High byte	00H
Write Data Number Low byte	01H
Write Data Number	02H
Write Data Content High byte	00H
Write Data Content Low byte	01H
CRC CHK Low byte	67H
CRC CHK High byte	90H
END	T1-T2-T3-T4 (Transmission time of 3.5 words)

Slave responding information

START	T1-T2-T3-T4 (Transmission time of 3.5 words)
Address	01H
Command Code	10H
Write Data Start Address High byte	00H
Write Data Start Address Low byte	00H
Write Data Number High byte	00H
Write Data Number Low byte	01H
CRC CHK Low byte	01H
CRC CHK High byte	C9H
END	T1-T2-T3-T4 (Transmission time of 3.5 words)

#### Command code: 08H (0000 1000), diagnostic function

Meaning of subsidiary function code:

Subsidiary Function Code	Remark
0000	Feedback inquiry data

Example: if we do loop detection for the driver address 01H, we will get the same inquiry string content and response string content, the format is as below:

**RTU Master Command Information** 

START	T1-T2-T3-T4 (Transmission time of 3.5 words)
ADDR	01H
CMD	08H
Subsidiary Function Code High byte	00H
Subsidiary Function Code Low byte	00H
Data Content High Byte	12H
Data Content Low Byte	ABH
CRC CHK Low Byte	ADH
CRC CHK High Byte	14H
END	T1-T2-T3-T4 (Transmission time of 3.5 words)

#### RTU Slave responding information

START	T1-T2-T3-T4 (Transmission time of 3.5 words)
ADDR	01H
CMD	08H
Subsidiary Function Code High byte	00H
Subsidiary Function Code Low byte	00H
Data Content High Byte	12H
Data Content Low Byte	ABH
CRC CHK Low Byte	ADH
CRC CHK High Byte	14H
END	T1-T2-T3-T4 (Transmission time of 3.5 words)

#### Communication Frame Error Checking

It includes two parts for the frame error checking, bit checking of byte (Odd / Even Parity Checking) and complete data checking (CNC checking and LRC checking)

#### Bit checking of byte

Customers can choose different bit checking type based on different request, No parity checking also can selected, it will affect the bit checking setting for each byte.

Meaning of Even Parity Checking, add additional Even Parity Checking bit before transmission, it's used to check whether the number of "1" in the transited data is Odd or Even, if it is Even, the checking bit will be changed as "0", otherwise it will be changed as "1", to keep the parity of data to be unchanged.

Meaning of Odd Parity Checking, add additional Odd Parity Checking bit before transmission, it's used to check whether the number of "1" in the transited data is Odd or Even, if it is Odd, the checking bit will be changed as "0", otherwise it will be changed as "1", to keep the parity of data to be unchanged.

For example, if the data of "11001110" will be transited, it includes 5 Nos of "1", if we adopt Even Parity Checking, the Even Parity Checking bit is "1", if we adopt Odd Parity Checking, the Odd Parity Checking bit is "0", during the data transiting, parity check bit will be put to the checking bit of frame after calculating, the receive equipment will also do the parity checking, if the parity of the received data is different with the preset value, that means the communication error has happened.

#### 9.6.3 CRC checking

In RTU mode, messages include an error-checking field that is based on a CRC method. The CRC field checks the contents of the entire message. The CRC field is two bytes, containing a 16-bit binary value. The CRC value is calculated by the transmitting device, which appends the CRC to the message. The receiving device recalculates a CRC during receipt of the message, and compares the calculated value to the actual value received in the CRC field. If the two values are not equal, an error results.

The CRC is started by 0xFFFF. Then a process begins of applying successive eight-bit bytes of the message

to the current contents of the register. Only the eight bits of data in each character are used for generating the CRC. Start and stop bits, and the parity bit, do not apply to the CRC.

During generation of the CRC, each eight-bit character is exclusive ORed with the register contents. Then the result is shifted in the direction of the least significant bit (LSB), with a zero filled into the most significant bit (MSB) position. The LSB is extracted and examined. If the LSB was a 1, the register is then exclusive ORed with a preset, fixed value. If the LSB was a 0, no exclusive OR takes place. This process is repeated until eight shifts have been performed. After the last (eighth) shift, the next eight-bit byte is exclusive ORed with the register's current value, and the process repeats for eight more shifts as described above. The final contents of the register, after all the bytes of the message have been applied, is the CRC value.

When the CRC is appended to the message, the low byte is appended first, followed by the high byte. The following are C language source code for CRC-16.

```
unsigned int crc cal value(unsigned char *data value, unsigned char data length)
{
     int i;
  unsigned int crc value = 0xffff;
  while(data_length--)
  {
     crc value ^= *data value++;
     for(i=0;i<8;i++)
          {
             if(crc value&0x0001)
               crc value = (crc value>>1)^0xa001;
               else
                 crc_value = crc_value>>1;
          }
     }
     return(crc value);
}
```

### 9.6.4 Address definition of communication parameter

Here is about address definition of communication parameter. It's used to control the inverter operation, status and related parameter setting.

1	I) holding register	addrose list: C	command data (	both write and	road are available)
Ľ		auuress list. C	onninanu uala (	bour write and	reau are available)

Register Address	BIT display	content	
	Address of Running Command		
	0	1: Forward running	
	1	1: Reverse Running	
	2	1: Make 3# external terminal close	
0000H	3	1: Make 4# external terminal close	
000011	4	1: Make 5# external terminal close	
	5	1: Make 6# external terminal close	
	6	1: Make 7# external terminal close	
	7	1: Make 8# external terminal close	
	8-F	Not used	
0001H	Address of frequency reference		
0002H-0005H	Not used		
0006H	Address of PID target value		

micno		KE200 Inverter
0007H	Setting address of Ana H4-01 is 1F)	alog output 1 (-11V/-726 valid when the setting of
0008H	Setting address of Analog output 2 (-11V/-726 valid when the setting of H4-01 is 1F)	
	Terminals output setting address	
	0	1: Terminal output (terminal 9, 10) close
	1	1: PHC1 (terminal 25, 27) close
	2	1: PHC2 (terminal 26, 27) close
0009H	3-5	Not used
	6	1: Fault terminal (terminal 18, 20) Determined by 7 <sup>th</sup> Bit
	7	1: Fault terminal close
	8-F	Not used
000EH	Not used	000EH
	Command selection setting address	
	0	0: frequency / detection unit is 0.01HZ
		<ol> <li>frequency / detection unit is Determined by 01- 03</li> </ol>
	1	0: the PID target value which is sent from the dataway is invalid
		1: the PID target value which is sent from the dataway is valid
000FH	2-B	Not used
	С	1: the terminal 5 which is transmitting the data at the same time is valid
	D	1: the terminal 6 which is transmitting the data at the same time is valid
	E	1: the terminal 7 which is transmitting the data at the same time is valid
	F	1: the terminal 8 which is transmitting the data at the same time is valid

	Address of KE200 status		
	0	1: running	
	1	1: 0 speed running	
	2	1: reverse running	
0010	3	1: the reset signal is inputting	
001011	4	1: speed matching	
	5	1: KE200 is ready	
	6	1: Minor fault	
	7	1: major fault	
	8-F	Not used	
	Address of operator status		
	0	1: OPE happening	
	1	1: ERR happening	
	2	1: PRG state	
0011	3	1CN state	
		00: JVOP-130	
	4	01: JVOP-132	
	4	10: JVOP-100	
		11: computer	
	5-F	Not used	
0012H	Address of OPE serial numb	per	
0013H	Not used address		
	Address of fault 1		
	0	FU fuse burn-out	
	1	UV1 under voltage of main power	
	2	UV2 under voltage of control power	
	3	UV3 MC fault	
	4	SC load short-circuit	
	5	GF short-circuit to ground	
	6	OC over current	
0014H	7	OV over voltage	
	8	OH KE200 over heat	
	9	OH1 KE200 over heat	
	A	OL1 motor over load	
	_	OL2 KE200 over load	
	В		
	B C	OL3 over torque 1	
	B C D	OL3 over torque 1 OL4 over torque 2	
	B C D E	OL3 over torque 1 OL4 over torque 2 RR braking transistor fault	

	Address of fault 2		
	0	EF3 external fault 3	
	1	EF4 external fault 4	
	2	EF5 external fault 5	
	3	EF6 external fault 6	
	4	EF7 external fault 7	
	5	EF8 external fault 8	
	6	FAN cooling fan fault	
0015H	7	OS over speed	
	8	DEV speed deviation is too large	
	9	PGO PG disconnection	
	A	PF input phase failure	
	В	LF output phase failure	
	С	Not used	
	D	OPR operator is pulled out	
	E	ERR EEPROM write fault	
	F	Not used	
	Address of fault 3		
	0	CE MEMOBUS communication fault	
0016H	1-3	Not used	
001011	4	CF control fault	
	5	SVE zero servo fault	
	6-F	F not used	
	Address of CPF	- 1	
	0	Not used	
	1	Not used	
	2	CPF02 happening	
0017H	3	CPF03 happening	
	4	CPF04 happening	
	5	CPF05 happening	
	6	CPF06 happening	
	7	F not used	
	Address of CPF	2	
	0	CPF20 happening	
0018H	1	CPF21 happening	
	2	CPF22 happening	
	3	CPF23 happening	
	4	F not used	

	Address of minor fault 1		
	0	UV under voltage detecting	
	1	OV over voltage detecting	
	2	OH KE200 over heat	
	3	OH2 warning of INV over heat	
	4	OL3 over torque 1 detecting	
	5	OL4 over torque 2 detecting	
	6	EF 2 line input fault	
0019H	7	BB external BB block	
	8	EF3 external fault 3	
	9	EF4 external fault 4	
	A	EF5 external fault 5	
	В	EF6 external fault 6	
	С	EF7 external fault 7	
	D	EF8 external fault 8	
	E	FAN cooling fan fault	
	F	OS over speed	
	Address of minor fault 2		
	0	EV speed deviation is too large	
	1	PGO PG disconnection	
	2	OPR operator is pulled out	
0014H	3	CE MODBUS communication fault	
001/11	4	Not used	
	5	Not used	
	6	OL1 motor overload	
	7	OL2 KE200 over load	
	8	F not used	



### (II) U1-XX Monitor Display

Register address	Parameters	Content
0020H	U1-01	Frequency reference
0021H	U1-02	Output frequency
0022H	U1-03	Output current
0023H	U1-04	Control method
0024H	U1-05	Motor speed
0025H	U1-06	Output voltage
0026H	U1-07	DC bus voltage
0027H	U1-08	Output power
0028H	U1-09	Torque reference
		Input terminal status:
		bit0 set as 1 T1 "Closed"
		bit1 set as 1 T2 "Closed"
		bit2 set as 1 T3 "Closed"
0029H	U1-10	bit3 set as 1 T4 "Closed"
		bit4 set as 1 T5 "Closed"
		bit5 set as 1 T6 "Closed"
		bit6 set as 1 T7 "Closed"
		bit7 set as 1 T8 "Closed"
	11-11	Output terminals status
		bit0 set as 1 T9~T10 "Closed"
002AH		bit1 set as 1 T25 "Closed"
		bit2 set as 1 T26 "Closed"
		bit3-6 Not used
		bit7 Fault output terminal T18 "Closed"
		Running status
		0 1: During running
		1 1: During zero speed
		2 1: During reverse
002BH	U1-12	3 1: During reset signal input
		4 1: During speed agree
		5 1: Inverter operation ready
		6 1: Minor fault
		7 1: Major fault
002CH	U1-13	Elapsed time
002DH	U1-14	Software No. (BLINK)
002EH	U1-15	Input current of control circuit terminal 13

Register address	Parameters	Content
002FH	U1-16	Input current of control circuit terminal 14
0030H	U1-17	Input current of control circuit terminal 16
0031H	U1-18	Motor secondary current
0032H	U1-19	Motor excitation current
0033H	U1-20	Output frequency after soft-start
0034H	U1-21	ASR input
0035H	U1-22	ASR output
0036H	U1-23	Speed deviation
0039H	U1-26	Output voltage reference Vg
003AH	U1-27	Output voltage reference Vd
003BH	U1-28	Software No. (CPU)

(III) U2-XX Monitor Display

0080H	U2-01	Current fault
0081H	U2-02	Last fault
0082H	U2-03	Frequency reference at fault
0083H	U2-04	Output frequency at fault
0084H	U2-05	Output current at fault
0085H	U2-06	Motor speed at fault
0086H	U2-07	Output voltage at fault
0087H	U2-08	DC bus voltage at fault
0088H	U2-09	Output power at fault
0089H	U2-10	Torque reference at fault
		Input terminal status at fault
		0 1: TI "Closed"
		1 1: T2 "Closed"
		2 1: T3 "Closed"
008AH	U2-11	3 1: T4 "Closed"
		4 1: T5 "Closed"
		5 1: T6 "Closed"
		6 1: T7 "Closed"
		7 1: T8 "Closed"
	U2-12	Output terminal status at fault
		0 1: T9~T10 "Closed"
008BH		1 1: T25 "Closed"
		2 1: T26 "Closed"
		3-6 Not used
		7 1: Fault output terminal T18 "Closed"
		Running status at fault
		0 1: During running
		1 1: During zero speed
		2 1: During reverse
008CH	U2-13	3 1: During reset signal input
		4 1: During speed agree
		5 1: Inverter operation ready
		6 1: Minor fault
		7 1: Major
008DH	U2-14	Elapsed operation time at fault

(IV) U3-XX Monitoring Display

Register address	Parameters	Content
0090H	U3-01	Most recent fault
0091H	U3-02	Second most recent fault
0092H	U3-03	Third most recent fault
0093H	U3-04	Forth / Oldest fault
0094H	U3-05	Elapsed operation time at fault
0095H	U3-06	Elapsed time of second fault
0096H	U3-07	Elapsed time of third fault
0097H	U3-08	Elapsed time of forth / oldest fault

Fault No. of 0080, 0081, 0090~93

Display	Meaning	Fault No.
FU	Fuse burn-out	01H01H
UV1	Main circuit under voltage	02H
UV2	Control circuit under voltage	03H
UV3	MC fault	04H
SC	load short-circuit	05H
GF	Short-circuit to ground	06H
OC	Over current	07H
OV	Over voltage	08H
ОН	Inverter over heat	09H
OH1	Inverter over heat	ОАН
OL1	Motor over heat	ОВН
OL2	Inverter over load	ОСН
OL3	Over torque 1	ODH
OL4	Over torque 2	OEF
RR	Braking transistor failure	OFH
RH	Braking resistor over heat	10H
EF3	External fault 3	11H
EF4	External fault 4	12H
EF5	External fault 5	13H
EF6	External fault 6	14H
EF7	External fault 7	15H

KE200 Inverter

EF8	External fault 8	16H
FAN	Cooling fan fault	17H
OS	Over speed	18H
DEV	Speed deviation is too large	19H
PGO	PG open circuit	1AH
PF	Input open-phase	1BH
LF	Output open-phase	1CH
OPR	Operator is pulled out	1EH
ERR	EEPROM writing fault	1FH
CE	MODBUS communication fault	21H
CF	Control fault	25H
SVE	Zero servo fault	26H

 $(\,V\,)\,$  parameters data (both write and read are available), please refer to the manual for the setting range details.

Register address	Function codes	Name
0100H	A1-00	Language selection
0101H	A1-01	Access level
0102H	A1-02	Control method selection
0103H	A1-03	Initialize
0104H	A1-04	Password 1
0105H	A1-05	Password 2
0106H 0125H	A2-01-A2-32	User setting parameters
0180H	B1-01	Reference selection
0181H	B1-02	Operation method selection
0182H	B1-03	Stop method selection
0183H	B1-04	Reverse operation prohibit
0184H	B1-05	operation selection for setting or E1-09 or less
0185H	B1-06	Digital input scan time

Register address	Function codes	Name
0196H	B5-03	integration time (1)
0197H	B5-04	Integral (1) limit
0198H	B5-05	Derivative time (D)
0199H	B5-06	PID limit
019AH	B5-07	PID offset adjustment
019BH	B5-08	PID primary delay time
019CH	B6-01	DOWEL frequency at start
019DH	B6-02	DOWEL time at start
019EH	B6-03	DOWEL frequency at stop
019FH	B6-04	DOWEL time at stop
01A0H	B7-01	Droop control gain
01A1H	B7-02	Droop control delay time
01A2H	B8-01	Energy-saving gain
01A3H	B8-02	Energy-saving frequency
0186H	B1-07	Operation selection after switching to remote mode
0187H	B2-01	DC injection braking start frequency
0188H	B2-02	DC injection current
0189H	B2-03	DC injection time at start
018AH	B2-04	DC injection braking time at stop
018BH	B2-05	DC braking proportion multiples
018CH	B2-06	DC braking integration time
018DH	B2-07	DC braking limit
018EH	B3-01	Speed search selection at start
018FH	B3-02	Speed search operation current
0190H	B3-03	Speed search deceleration time
0191H	B3-04	V/F value during speed searching
0192H	B4-01	Timer function On-delay time
0193H	B4-02	Timer function Off-delay time
0194H	B5-01	PID control mode selection
0195H	B5-02	Proportional gain

01A4H	B9-01	Zero-servo gain
01A5H	B9-01	Zero-servo completion width
0200H	C1-01	Acceleration time 1
0201H	C1-02	Deceleration time 1
0202H	C1-03	Acceleration time 2
0203H	C1-04	Deceleration time 2
0204H	C1-05	Acceleration time 3
0205H	C1-06	Deceleration time 3
0206H	C1-07	Acceleration time 4
0207H	C1-08	Deceleration time 4
0208H	C1-09	Emergency stop time
0209H	C1-10	ACC / DEC time set unit
020AH	C1-11	ACC / DEC time switching frequency
020BH	C2-01	S-curve characteristic time at acceleration start
020CH	C2-02	S-curve characteristic time at acceleration end
020DH	C2-03	S-curve characteristic time at deceleration start
020EH	C2-04	S-curve characteristic time at deceleration end
020FH	C3-01	Slip compensation gain
0210H	C3-02	Slip compensation primary delay time
0211H	C3-03	Slip compensation limit
0212H	C3-04	Slip compensation selection during regeneration
0242H	C3-05	Slip compensation of V/F characteristic
0213H	C4-01	Torque compensation gain
0214H	C4-02	Torque compensation time
0215H	C5-01	ASR proportional gain 1
0216H	C5-02	ASR integral gain 1
0217H	C5-03	ASR proportional gain 2
0218H	C5-04	ASR integral gain 2
0219H	C5-05	ASR limit
021AH	C5-06	ASR primary delay
021BH	C5-07	ASR switching frequency
0241H	C5-08	ASR integral limit
021CH	C6-01	Carrier frequency upper limit
021DH	C6-02	Carrier frequency lower limit

KE200 Inverter

021EH	C6-03	Carrier frequency proportional gain
021FH	C7-01	Hunting prevention selection
0210H	C7-02	Hunting prevention gain
0221H	C7-03	Hunting prevention parameter
0222H	C7-04	Hunting prevention limit

Register address	Function codes	Name
0229H	C8-07	ACRd limit
022AH	C8-08	AFR gain
022BH	C8-09	AFR parameter
022CH	C8-10	AFR limit
022DH	C8-11	Voltage DROP compensation parameter
022EH	C8-12	Parameter during AVR
022FH	C8-13	PWM adjustment method selection
0230H	C8-14	
0231H	C8-15	QN delay time
0232H	C8-16	QN delay time adjusted value
0233H	C8-17	Delay time of current detection
0234H	C8-18	COS detection filter 1
0235H	C8-19	COS detection filter 2
0236H	C8-20	Testing (simulating) mode
0237H	C8-21	OBSERVER selection
0238H	C8-22	Observer output phase compensation gain
0239H	C8-23	Observer output phase compensation filter
023AH	C8-24	Observer output voltage compensation gain
023BH	C8-25	Observer proportional value during speed detection
023CH	C8-26	Observer gain
023DH	C8-27	Inverter rated current
023EH	C8-28	DCCT gain
023FH	C8-29	PWM2 phase / 3 phase switching level
0223H	C8-01	Current feedback gain
0224H	C8-02	ACRq multiples
0225H	C8-03	ACRq integral time
0226H	C8-04	ACRq limit

KE200 Inverter

0227H	C8-05	ACRd multiples
0228H	C8-06	ACRd integral time
0240H	C8-30	Carrier frequency selection during Auto-Tuning
0280H	D1-01	Frequency reference 1
0281H	D1-02	Frequency reference 2
0282H	D1-03	Frequency reference 3
0283H	D1-04	Frequency reference 4
0284H	D1-05	Frequency reference 5
0285H	D1-06	Frequency reference 6
0286H	D1-07	Frequency reference 7
0287H	D1-08	Frequency reference 8
0288H	D1-09	Jog frequency reference
0289H	D2-01	Frequency reference upper limit
028AH	D2-02	Frequency reference lower limit
028BH	D3-01	Jump frequency 1
028CH	D3-02	Jump frequency 2
028DH	D3-03	Jump frequency 3
028EH	D3-04	Jump frequency width
028FH	D4-01	Frequency reference hold function selection
0290H	D4-02	$\pm$ speed limit
0291H	D5-01	Torque control selection
0292H	D5-02	Torque reference delay time
0293H	D5-03	Speed limit selection
0294H	D5-04	Speed limit
0295H	D5-05	Speed limit bias
0296H	D5-06	Speed / torque control switching timer
0300H	E1-01	Input voltage setting
0301H	E1-02	Motor selection
0302H	E1-03	V/F curve selection
0303H	E1-04	Max. output frequency
0304H	E1-05	Max. voltage
0305H	E1-06	Max. voltage frequency
0306H	E1-07	Mid. output frequency
0307H	E1-08	Mid. output frequency voltage
0308H	E1-09	Min. output frequency
KE200 Inverter

0309H	E1-10	Min. output frequency voltage
030AH	E1-11	Mid. output frequency 2
030BH	E1-12	Min. output frequency voltage 2
030CH	E1-13	Base voltage
030EH	E2-01	Motor rated current
030FH	E2-02	Motor rated slip
0310H	E2-03	Motor no-load current
0311H	E2-04	Number of motor poles
0312H	E2-05	Motor line-to-line resistance
0313H	E2-06	Motor leak inductance
0314H	E2-07	Motor iron-core saturation coefficient 1
0315H	E2-08	Motor iron-core saturation coefficient 2
0316H	E2-09	Motor mechanical loss
0317H	E3-01	Motor 2 control method selection
0318H	E4-01	Motor 2 Max. output frequency
0319H	E4-02	Motor 2 Max. voltage
031AH	E4-03	Motor 2 Max. voltage frequency
031BH	E4-04	Motor 2 Mid. output frequency
031CH	E4-05	Motor 2 Mid. output frequency voltage
031DH	E4-06	Motor 2 Min. output frequency
031EH	E4-07	Motor 2 Min. output frequency voltage
031FH	E5-01	Motor 2 rated current
0320H	E5-02	Motor 2 rated slip
0321H	E5-03	Motor 2 no-load current
0322H	E5-04	Motor 2 number of poles
0323H	E5-05	Motor 2 line-to-line resistance
0324H	E5-06	Motor 2 leak inductance
0380H	F1-01	PG constant
0381H	F1-02	PG operation selection at PG open circuit
0382H	F1-03	PG operation selection at over speed
0383H	F1-04	PG operation selection at speed deviation is too large
0384H	F1-05	PG rotation
0385H	F1-06	PG division rate
0386H	F1-07	Integral value during ACC / DEC

KE200 Inverter

0387H	F1-08	Over speed detection level	
0388H	F1-09	Over speed detection delay time	
0389H	F1-10	Excessive speed deviation detection level	
038AH	F1-11	Excessive speed deviation detection delay time	
038BH	F1-12	Number of PG gear teeth 1	
038CH	F1-13	Number of PG gear teeth 2	
0397H	F1-14	PGO detection time	
038DH	F2-01	AI-14B card input selection	
038EH	F3-01	Digital input selection	
038FH	F4-01	Channel 1 monitor selection	
0390H	F4-02	Channel 1 gain	
0391H	F4-03	Channel 2 monitor selection	
0392H	F4-04	Channel 2 gain	
0393H	F5-01	Channel 1 output selection	
0394H	F5-02	Channel 2 output selection	
0395H	F6-01	Output mode selection	
0396H	F7-01	Frequency multiple selection	
0400H	H1-01	Terminal 3 selection	
0401H	H1-02	Terminal 4 selection	
0402H	H1-03	Terminal 5 selection	
0403H	H1-04	Terminal 6 selection	
0404H	H1-05	Terminal 7 selection	
0405H	H1-06	Terminal 8 selection	
0406H	H2-01	Terminal 9-10 selection	
0407H	H2-02	Terminal 25 selection	
0408H	H2-03	Terminal 26 selection	
0409H	H3-01	Terminal 13 signal level selection	
040AH	H3-02	Terminal 13 gain	
040BH	H3-03	Terminal 13 bias	
040CH	H3-04	Terminal 16 signal level selection	
040DH	H3-05	Terminal 16 function selection	
040EH	H3-06	Terminal 16 gain	
040FH	H3-07	Terminal 16 bias	
0410H	H3-08	Terminal 14 signal level selection	
0411H	H3-09	Terminal 14 function selection	

KE200 Inverter

0412H	H3-10	Terminal 14 gain
0413H	H3-11	Terminal 14 bias
0414H	H3-12	Analog input filter time constant
0415H	H4-01	Terminal 21 monitor selection
0416H	H4-02	Terminal 21 output gain
0417H	H4-03	Terminal 21 output bias
0418H	H4-04	Terminal 23 monitor selection
0419H	H4-05	Terminal 23 output gain
041AH	H4-06	Terminal 23 output bias
041BH	H4-07	Analog output signal selection
041CH	H5-01	Station address
041DH	H5-02	Communication speed selection
041EH	H5-03	Communication parity selection
041FH	H5-04	Stopping method after communication error
0420H	H5-05	Timeover detection
0480H	L1-01	Motor protection selection
0481H	L1-02	Motor protection time constant
0482H	L2-01	Momentary power loss detection
0483H	L2-02	Momentary power loss ride through
0484H	L2-03	Min. base-block time
0485H	L2-04	Voltage recovery time
0486H	L2-05	Under voltage detection level
0487H	L2-06	KEB deceleration rate
0488H	L3-01	Stall prevention during acceleration
0489H	L3-02	Stall prevention level during acceleration
048AH	L3-03	Stall prevention limit during acceleration
048BH	L3-04	Stall prevention during deceleration
048CH	L3-05	Stall prevention during running
048DH	L3-06	Stall prevention level during running
048EH	L3-07	Stall prevention function P gain
048FH	L3-08	Stall prevention function integral time
04A4H	L8-01	Internal dynamic braking resistor protection selection
04A5H	L8-02	Over hear pre-alarm level
04A6H	L8-03	Operation selection after over heat pre-alarm

micno		KE200 Inverter
04A7H	L8-04	Over hear detection level
04A8H	L8-05	Input phase loss protection
04A9H	L8-06	Input phase loss detection level
04AAH	L8-07	Output phase loss protection
04ABH	L8-08	Output phase loss detection level
04ACH	L8-09	Short-circuit protection selection at load side
04ADH	L8-10	Short-circuit protection selection for grounding
04AEH	L8-11	Inverter overload protection selection
0490H	L4-01	Frequency detection level
0491H	L4-02	Frequency detection width
0492H	L4-03	Frequency detection level (+/-)
0493H	L4-04	Frequency detection width (+/-)
0494H	L4-05	Frequency reference loss detection selection
0495H	L5-01	Number of auto restart attempts
0496H	L5-02	Auto restart operation selection
0497H	L5-03	Retry interval time after fault
0498H	L6-01	Over torque detection selection 1
0499H	L6-02	Over torque detection level 1

0499H	L6-02	Over torque detection level 1
049AH	L6-03	Over torque detection time 1
049BH	L6-04	Over torque detection selection 2
049CH	L6-05	Over torque detection level 2
049DH	L6-06	Over torque detection time 2
049EH	L7-01	Forward torque limit
049FH	L7-02	Reverse torque limit
04A0H	L7-03	Forward regenerative torque limit
04A1H	L7-04	Reverse regenerative torque limit
04A2H	L7-05	Torque limit proportion
04A3H	L7-06	Torque limit integral time

04AFH	L8-12	AVR function selection	
04B0H	L8-13	Testing method while leaving factory	
04B1H	L8-14	UV3 detection	
0500H	01-01	Display selection at detection mode	
0501H	01-02	Detection selection while switch on the power	

**KE200** Inverter

0502H	01-03	Frequency reference / detection setting / display unit
0503H	01-04	Setting unit of parameters which are related to frequency
0504H	01-05	Meaning selection of function codes
0505H	02-01	Function selection of LOCAL/REMOTE button
0506H	02-02	Function selection of STOP button
0507H	02-03	Customer defined initial value selection
0508H	02-04	Inverter capacity selection
0509H	02-05	Frequency reference setting method selection
050AH	02-06	Operation selection after operator disconnection
050BH	02-07	Accumulated operation time setting
050CH	02-08	Accumulated operation time selection
050DH	02-09	Initial method

#### $(\ensuremath{\operatorname{VI}})$ ENTER command

Register address	Function codes	Name
FFFDH	ENTER	Write the data to EEPROM

ENTER command the master to use communication mode, write the parameters into the internal RAM data area of KE200, ENTER command is to write the data in the RAM into the internal nonvolatile memory of KE200. Write "0" to the register of FFFDH, that command will be activated. Cause the internal nonvolatile memory of KE200 can be written not more than 100,000 times, so that don't use the ENTER command frequently. It is not to use ENTER command to write the data into internal nonvolatile memory while setting parameters by the operator.

#### ENTER command

Slave inverter address		01H
The function No.		10H
initial address	superior	FFH
	inferior	FDH
Numbers	inferior	00H
	inferior	01H
Data numbers		02H
ENTER correspond data	inferior	00H
	inferior	00H
CRC-16	inferior	BCH
	inferior	B2H

#### Response for error messages

While the slave equipment gives response, it uses a function code or fault address to indicate whether it is a correct response or not. For correct response, the slave inverter gives the related function codes and data address or subsidiary function codes. For incorrect response, the slave equipment feeds back a code which is the same as normal code, but the logic of the first place is 1.

For example, the signal which is sent from master equipment to slave equipment is requested to read the address data of inverter function codes, the function code is as below:

0 0 0 0 0 0 1 1 (hexadecimal 03H)

For correct response, the slave equipment feeds back the same function code, for incorrect response, it will feed back the function code as below:

1000011 (hexadecimal 83H)

Except for the function code is modified due to the mistake, the slave equipment will feed back a 1 bit abnormal code, it defines the reason of abnormal. After the master equipment gets the abnormal response, it needs to resent the massage in normal condition, or to make command modification for the correspond fault.

#### Meaning of incorrect codes

Code	Name	Meaning	
01H	Illegal command	Error of function codes	
	incgai command	* The function codes from PLC are not 01H,08H,10H	
		Error of register address	
02H	Illegal data address	* The register addresses which will be stored are not registered	
		* The start address which are transmitting at the same time are not	
		0000H, 0001H, 0002H	
03H	Operation failure	Numbers are error	
0011		* Read or write data numbers are not in the range of 1-16	
		Data setting error	
	Illegal data or over limitation data	* Control data or parameters only have the upper and lower	
21H		limitation while writing.	
		* Related parameters setting is not correct while writing the	
		parameters.	
	Data frame error	Write method error	
		* PLC is trying to write parameters while running.	
22H		* PLC output ENINT write command while running	
		* PLC is trying to write parameters besides A1-00-05,E1-03,02-04	
		after " CPF03" appearing	
		* Try to write private data for reading	
		Write into UV	
23H	Parameters are read only	* while "UV" fault happening, PLC is trying to write data	
		* while "UV" fault happening, PLC is trying to output ENINT	
		command	
24H	FEPROM busy	Writing while the parameters are in the deal processing	
		* during the data processing, PLC is trying to write data.	

#### About the reset of communication error "CE"

To reset "CE" fault, before 2 second to get the reset signal, the inverter should receive a normal data at least one time. The "CE fault cannot be reset if the inverter is not in the communication status.

# Appendix 1 Wiring of KE200 PG Card

PG card is required for KE200 close loop vector control mode, KE200 PG card model: PG-B2

(1) The specifications of PG-B2 (special for close-loop vector control) terminals

PG-B2 terminals and specifications				
Terminal	NO.	Content	Specification	
	1		DC+12V(±5%)Max.200mA	
	2	generator	DC0V (Ground grounding connection terminals for power)	
TA1	3	A phase pulse input terminal	H:+8 $\sim$ 12V L: Below +1V (The maximum response frequency is 30KHz)	
	4		Pulse input COM	
	5	B phase pulse input terminal	H:+8∼12V L: Below +1V (The maximum response frequency is 30KHz)	
	6		Pulse input COM	
	1 A phase pulse monitor		Open collector output DC24V Max.30mA	
TA2	2	output terminal	A phase pulse monitor output COM	
	3	B phase pulse monitor	Open collector output DC24V Max.30mA	
	4	output terminal	B phase pulse monitor output COM	
ТАЗ	(E)	Shielded wire connection terminal	—	

#### (2) The two connection modes between PG-B2 and encoder.



 $\% Signal \ cable, \ must \ use \ twisted \ shielded \ cable.$ 

% PG power, can only be used for PG (encoder). Being used as other power will cause fault because of interference.

%PG wiring length<100m.

%The direction of rotation of PG is set by F1-05, the factory default is A phase advance when the motor forwards.

The wiring diagram of differential encoder and PG-B2



\* PG wiring length < 100m.

※ The direction of rotation of PG is set by F1-05, the factory default is A phase advance when the motor forwards.

The wiring diagram of collector encoder and PG-B2



 $\bullet$  The frequency dividing ratio of pulse monitoring is adjustable by F1-06

# Appendix 2 Comparison Table of LED Display & English Letter

LED Display	English Letter	LED Display	English Letter
	A		Ο
	b		Т
	С		U
	d		r
	E		Р
	F		S
	Н		V
	L		G



Scan QR code for more information .....

# ADD:6th Floor, Building 8, Shiling Industrial Park, Xinwei, Xili, Nanshan District, Shenzhen, China TEL: +86-755-2167 5210 WEB: www.micno.com.cn

FAX: +86-755-2167 5200

E-mail: overseas@micno.com.cn

MICNO copyright. Information maybe subject to change without notice during product improving.